



Supported YANG Models in NCS 1014

- [Supported Yang Models, on page 1](#)

Supported Yang Models

The following is the list of supported config, oper, and act YANG models for NCS 1014:

Table 1: Native Models

Config Models	Oper Models
Cisco-IOS-XR-osa-linesystem-cfg.yang	Cisco-IOS-XR-osa-hwmod-linesys-oper.yang
Cisco-IOS-XR-controller-ots-cfg.yang	Cisco-IOS-XR-controller-ots-oper.yang
Cisco-IOS-XR-ots-och-cfg.yang	Cisco-IOS-XR-controller-ots-och-oper.yang
Cisco-IOS-XR-controller-oms-cfg	Cisco-IOS-XR-controller-oms-oper.yang
Cisco-IOS-XR-controller-och-cfg	Cisco-IOS-XR-controller-och-oper.yang
Cisco-IOS-XR-controller-osc-cfg.yang	Cisco-IOS-XR-controller-osc-oper.yang
Cisco-IOS-XR-controller-dfb-cfg.yang	Cisco-IOS-XR-controller-dfb-oper.yang
Cisco-IOS-XR-pmengine-cfg.yang	Cisco-IOS-XR-pmengine-oper.yang
Cisco-IOS-XR-olc-cfg.yang	Cisco-IOS-XR-olc-oper.yang
Cisco-IOS-XR-fpd-infra-cfg.yang	
Cisco-IOS-XR-osa-ct-cfg.yang	Cisco-IOS-XR-osa-controller-optics-oper.yang
Cisco-IOS-XR-osa-sp-cfg.yang	Cisco-IOS-XR-osa-hwmod-linesys-oper.yang
Cisco-IOS-XR-osa-cfg.yang	Cisco-IOS-XR-osa-oper.yang
Cisco-IOS-XR-ikev2-cfg.yang	Cisco-IOS-XR-ikev2-oper.yang
Cisco-IOS-XR-controller-optics-cfg.yang	Cisco-IOS-XR-controller-optics-oper.yang
Cisco-IOS-XR-ethernet-lldp-cfg.yang	Cisco-IOS-XR-ethernet-lldp-oper.yang
Cisco-IOS-XR-telemetry-model-driven-cfg.yang	Cisco-IOS-XR-telemetry-model-driven-oper.yang

Config Models	Oper Models
Cisco-IOS-XR-ifmgr-cfg.yang	Cisco-IOS-XR-envmon-oper.yang
Cisco-IOS-XR-fpd-infra-cfg.yang	Cisco-IOS-XR-show-fpd-loc-ng-oper.yang
Cisco-IOS-XR-invproxy-hwmodule-cfg.yang	Cisco-IOS-XR-procfind-oper.yang
Cisco-IOS-XR-syncc-controller-cfg.yang	Cisco-IOS-XR-procthreadname-oper.yang
Cisco-IOS-XR-drivers-media-eth-gl-pfc-wd-cfg.yang	Cisco-IOS-XR-invmgr-oper.yang
Cisco-IOS-XR-drivers-media-eth-cfg.yang	Cisco-IOS-XR-plat-chas-invmgr-ng-oper.yang
Cisco-IOS-XR-drivers-icpe-ethernet-cfg.yang	Cisco-IOS-XR-platform-oper.yang
Cisco-IOS-XR-drivers-media-eth-cfg.yang	Cisco-IOS-XR-invmgr-diag-oper.yang
Cisco-IOS-XR-drivers-media-eth-gl-pfc-wd-cfg.yang	Cisco-IOS-XR-nto-misc-oper.yang
Cisco-IOS-XR-sysmgr-cfg.yang	Cisco-IOS-XR-wd-oper.yang
Cisco-IOS-XR-um-ncs-hw-module-osa-cfg.yang	Cisco-IOS-XR-ledmgr-oper.yang
	Cisco-IOS-XR-shellutil-filesystem-oper.yang
	Cisco-IOS-XR-shellutil-oper.yang
	Cisco-IOS-XR-drivers-media-eth-oper.yang
	Cisco-IOS-XR-mediasvr-linux-oper.yang
	Cisco-IOS-XR-drivers-media-eth-oper.yang
	Cisco-IOS-XR-sysmgr-oper.yang
	Cisco-IOS-XR-procmem-oper.yang
	Cisco-IOS-XR-procfind-oper.yang
Act Models	
Cisco-IOS-XR-upgrade-fpd-ng-act.yang	
Cisco-IOS-XR-shellutil-delete-act.yang	
Cisco-IOS-XR-drivers-media-eth-act.yang	
Cisco-IOS-XR-shellutil-copy-act.yang	
Cisco-IOS-XR-shellutil-copy-act.yang	
Cisco-IOS-XR-drivers-media-eth-act.yang	
Cisco-IOS-XR-sysmgr-act.yang	
Cisco-IOS-XR-system-reboot-act	
Cisco-IOS-XR-install-act.yang	

Config Models	Oper Models
Cisco-IOS-XR-install-augmented-act	

The following is the list of supported Open Config models:

Table 2: OpenConfig Models

openconfig-platform.yang
openconfig-platform-transceiver.yang
openconfig-terminal-device.yang
openconfig-interfaces.yang
openconfig-system.yang
openconfig-network-instance
openconfig-procmmon.yang

See <https://cfnng.cisco.com/ios-xr/yang-explorer/view-data-model> for the list of Yang models supported by NCS 1014.

