



Preface

The *Cisco IOS XR Interface and Hardware Component Configuration Guide for the Cisco XR 12000 Series Router* provides information and procedures related to router interface and hardware configuration.

The preface contains the following sections:

- [Changes to This Document](#)
- [Obtaining Documentation and Submitting a Service Request](#)

Changes to This Document

[Table 1](#) lists the technical changes made to this document since it was first printed.

Table 1 *Changes to This Document*

Revision	Date	Change Summary
OL-28390-02	May 2013	Republished with documentation updates for Cisco IOS XR Release 4.3.1 features.
OL-28390-01	December 2012	Initial release of this document.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.

