

INDEX

A

aaa accounting default command [2](#)
aaa authentication login console command [3](#)
aaa authentication login default command [5](#)
aaa authentication login error-enable command [7](#)
aaa authentication login mschap command [8](#)
aaa authorization commands default command [9](#)
aaa authorization config-commands default command [11](#)
aaa group server radius command [13](#)
aaa user default-role command [14](#)
access-class command [15](#)
action command [17](#)
arp access-list command [19](#)

C

clear access-list counters command [20](#)
clear accounting log command [21](#)
clear ip arp command [22](#)
clear ip arp inspection log command [23](#)
clear ip arp inspection statistics vlan command [24](#)
clear ip dhcp snooping binding command [25](#)
clear ip dhcp snooping statistics command [27](#)

D

deadtime command [28](#)
deny (ARP) command [30](#)
deny (IPv4) command [32](#)
description (user role) command [42](#)

E

enable command [43](#)
enable secret command [44](#)

F

feature (user role feature group) command [46](#)
feature dhcp command [47](#)
feature privilege command [49](#)
feature tacacs+ command [50](#)

H

hardware profile tcam region command [51](#)
hardware profile tcam syslog-threshold command [54](#)

I

interface policy deny command [55](#)
ip access-class command [56](#)
ip access-group command [58](#)
ip access-list command [60](#)
ip arp event-history errors command [62](#)
ip arp inspection log-buffer command [63](#)
ip arp inspection trust command [68](#)
ip arp inspection validate command [64](#)
ip arp inspection vlan command [66](#)
ip dhcp packet strict-validation command [69](#)
ip dhcp snooping command [72](#)
ip dhcp snooping information option command [73](#)
ip dhcp snooping trust command [74](#)
ip dhcp snooping verify mac-address command [75](#)

ip dhcp snooping vlan command [76](#)
 ip port access-group command [77](#)
 ip source binding command [79](#)
 ipv6 access-list command [83](#)
 ipv6 address command [81](#)
 ipv6 traffic-filter command [84](#)
 ipv6 verify unicast source reachable-via command [85](#)
 ip verify unicast source reachable-via command [86](#)

M

mac port access-group command [88](#)
 match command [90](#)

P

permit (ARP) command [92](#)
 permit (IPv4) command [94](#)
 permit interface command [104](#)
 permit vlan command [106](#)
 permit vrf command [108](#)
 permit vsan command [109](#)

R

radius-server deadtime command [110](#)
 radius-server directed-request command [111](#)
 radius-server host command [112](#)
 radius-server key command [114](#)
 radius-server retransmit command [115](#)
 radius-server timeout command [116](#)
 remark command [117](#)
 resequence command [119](#)
 role feature-group name command [121](#)
 role name command [122](#)
 rule command [124](#)

S

server command [126](#)
 show aaa accounting command [128](#)
 show aaa authentication command [129](#)
 show aaa authorization command [130](#)
 show aaa groups command [131](#)
 show aaa user command [132](#)
 show access-lists command [133](#)
 show accounting log command [134](#)
 show arp access-lists command [137](#)
 show hardware profile tcam region command [138](#)
 show ip access-lists command [140](#)
 show ip arp command [142](#)
 show ip arp inspection command [143](#)
 show ip arp inspection interfaces command [144](#)
 show ip arp inspection log command [145](#)
 show ip arp inspection statistics command [146](#)
 show ip arp inspection vlan command [147](#)
 show ip dhcp snooping binding command [149](#)
 show ip dhcp snooping command [148](#)
 show ip dhcp snooping statistics command [151](#)
 show ip verify source command [154](#)
 show platform afm info tcam command [155](#)
 show privilege command [157](#)
 show radius-server command [158](#)
 show role command [160](#)
 show role feature command [161](#)
 show role feature-group command [162](#)
 show running-config aaa command [163](#)
 show running-config aclmgr command [164](#)
 show running-config arp command [166](#)
 show running-config dhcp command [167](#)
 show running-config radius command [168](#)
 show running-config security command [169](#)
 show ssh key command [170](#)
 show ssh server command [171](#)
 show startup-config aaa command [172](#)
 show startup-config aclmgr command [173](#)

show startup-config arp command [175](#)
show startup-config dhcp command [176](#)
show startup-config radius command [177](#)
show startup-config security command [178](#)
show tacacs-server command [179](#)
show telnet server command [181](#)
show user-account command [182](#)
show users command [183](#)
show vlan access-list command [184](#)
show vlan access-map command [185](#)
show vlan filter command [186](#)
ssh6 command [187](#)
ssh command [188](#)
ssh key command [189](#)
ssh server enable command [191](#)
statistics per-entry command [192](#)
storm-control level command [194](#)

vlan filter command [215](#)
vlan policy deny command [217](#)
vrf policy deny command [218](#)
vsan policy deny command [219](#)

T

tacacs-server deadtime command [196](#)
tacacs-server directed-request command [198](#)
tacacs-server host command [199](#)
tacacs-server key command [201](#)
tacacs-server timeout command [203](#)
telnet6 command [204](#)
telnet command [205](#)
telnet server enable command [206](#)
terminal log-all command [207](#)

U

username command [210](#)
use-vrf command [208](#)

V

vlan access-map command [213](#)

