



| | |
|--|------------|
| Preface | 1 |
| Audience | 1 |
| Document Conventions | 1 |
| Related Documentation | 2 |
| Documentation Feedback | 3 |
| Obtaining Documentation and Submitting a Service Request | 13 |
| | 13 |
| New and Changed Information | 115 |
| System Management Commands | 11 |
| abort (Call Home) | 12 |
| abort (session) | 13 |
| action cli | 14 |
| action counter | 16 |
| action event-default | 18 |
| action policy-default | 110 |
| action reload | 112 |
| action snmp-trap | 114 |
| action syslog | 116 |
| alert-group (Call Home) | 118 |
| callhome | 120 |
| callhome send diagnostic | 121 |
| callhome test | 122 |
| clear counters mpls strip | 123 |
| clear logging logfile | 125 |
| clear logging nvram | 126 |
| clear logging onboard | 127 |
| clear logging session | 128 |
| clear mpls strip label dynamic | 129 |
| clear ntp session | 131 |
| clear ntp statistics | 132 |

Send comments to nexus3k-docfeedback@cisco.com

| | |
|--|-----|
| clear ptp counters | 133 |
| clear scheduler logfile | 134 |
| clear sflow statistics | 135 |
| clock protocol | 136 |
| commit (Call Home) | 137 |
| commit (session) | 138 |
| contract-id (Call Home) | 139 |
| customer-id (Call Home) | 140 |
| description | 141 |
| description (SPAN, ERSPAN) | 142 |
| destination ip (ERSPAN) | 144 |
| destination interface (ERSPAN) | 145 |
| destination-profile (Call Home) | 146 |
| diagnostic bootup level | 149 |
| duplicate-message throttle (Call Home) | 150 |
| email-contact (Call Home) | 151 |
| enable (Call Home) | 152 |
| event cli | 154 |
| event counter | 155 |
| event fanabsent | 157 |
| event fanbad | 158 |
| event manager applet | 159 |
| event manager environment | 160 |
| event manager policy | 161 |
| event manager policy internal | 162 |
| event memory | 163 |
| event oir | 164 |
| event policy-default | 165 |
| event snmp | 166 |
| event storm-control | 169 |
| event syslog | 170 |
| event sysmgr | 172 |
| event temperature | 174 |
| event track | 175 |
| feature ntp | 176 |

Send comments to nexus3k-docfeedback@cisco.com

| | |
|--|------|
| feature ptp | 177 |
| feature scheduler | 179 |
| feature sflow | 180 |
| filter access-group | 181 |
| hardware profile buffer info port-threshold | 182 |
| hardware profile parity-error | 183 |
| hardware profile tap-aggregation | 185 |
| hardware profile unicast syslog host-table-detail | 186 |
| ip access-list (session) | 188 |
| ip domain-list | 189 |
| ip domain-lookup | 191 |
| ip domain-name | 192 |
| ip host | 194 |
| ip name-server | 195 |
| ip port access-group (session) | 197 |
| logging abort | 198 |
| logging commit | 199 |
| logging console | 1100 |
| logging distribute | 1101 |
| logging event | 1102 |
| logging event port | 1103 |
| logging ip access-list cache entries num_entries | 1104 |
| logging ip access-list cache interval seconds | 1105 |
| logging ip access-list cache threshold num_packets | 1106 |
| logging level | 1107 |
| logging logfile | 1109 |
| logging module | 1111 |
| logging monitor | 1112 |
| logging server | 1113 |
| logging source-interface | 1115 |
| logging timestamp | 1117 |
| mode tap-aggregation | 1118 |
| monitor erspan origin ip-address | 1119 |
| monitor session | 1120 |
| mpls strip dest-mac | 1122 |

Send comments to nexus3k-docfeedback@cisco.com

| | |
|------------------------------------|-------------|
| mpls strip | 1123 |
| mpls strip label | 1124 |
| mpls strip label-age | 1126 |
| ntp | 1127 |
| ntp abort | 1129 |
| ntp access-group | 1130 |
| ntp authenticate | 1132 |
| ntp authentication-key | 1134 |
| ntp broadcast | 1135 |
| ntp broadcastdelay | 1136 |
| ntp commit | 1137 |
| ntp disable | 1138 |
| ntp distribute | 1139 |
| ntp logging | 1140 |
| ntp master | 1142 |
| ntp multicast | 1144 |
| ntp multicast client | 1146 |
| ntp peer | 1148 |
| ntp server | 1149 |
| ntp source | 1150 |
| ntp source-interface | 1151 |
| ntp sync-retry | 1152 |
| ntp trusted-key | 1153 |
| periodic-inventory (Call Home) | 1154 |
| phone-contact (Call Home) | 1156 |
| ptp | 1157 |
| ptp announce | 1158 |
| ptp delay-request minimum interval | 1160 |
| ptp domain | 1162 |
| ptp priority1 | 1163 |
| ptp priority2 | 1164 |
| ptp source | 1165 |
| ptp sync interval | 1167 |
| ptp vlan | 1169 |
| rmon alarm | 1171 |

Send comments to nexus3k-docfeedback@cisco.com

| | |
|--|------|
| rmon event | 1173 |
| rmon hcalarm | 1175 |
| scheduler | 1177 |
| sflow agent-ip | 1179 |
| sflow collector-ip | 1180 |
| sflow collector-port | 1181 |
| sflow counter-poll-interval | 1182 |
| sflow data-source | 1183 |
| sflow max-datagram-size | 1185 |
| sflow max-sampled-size | 1186 |
| sflow sampling-rate | 1187 |
| show callhome | 1188 |
| show callhome destination-profile | 1189 |
| show callhome transport-email | 1191 |
| show callhome user-def-cmds | 1192 |
| show diagnostic bootup level | 1193 |
| show diagnostic result | 1194 |
| show event manager environment | 1195 |
| show event manager event-types | 1197 |
| show event manager history events | 1200 |
| show event manager policy-state | 1202 |
| show event manager script system | 1204 |
| show event manager system-policy | 1205 |
| show forwarding mpls stats | 1208 |
| show hardware forwarding memory health summary | 1209 |
| show hosts | 1210 |
| show logging console | 1211 |
| show logging info | 1212 |
| show logging last | 1213 |
| show logging level | 1214 |
| show logging logfile | 1216 |
| show logging module | 1217 |
| show logging monitor | 1218 |
| show logging nvram | 1219 |
| show logging onboard | 1220 |

Send comments to nexus3k-docfeedback@cisco.com

| | |
|---------------------------------------|-------------|
| show logging pending | 1224 |
| show logging pending-diff | 1225 |
| show logging session status | 1226 |
| show logging server | 1227 |
| show logging status | 1228 |
| show logging timestamp | 1229 |
| show monitor session | 1230 |
| show mpls strip labels | 1233 |
| show ntp access-groups | 1235 |
| show ntp authentication-keys | 1236 |
| show ntp authentication-status | 1237 |
| show ntp logging-status | 1238 |
| show ntp peers | 1239 |
| show ntp peer-status | 1240 |
| show ntp pending-diff | 1241 |
| show ntp pending peers | 1242 |
| show ntp session status | 1243 |
| show ntp status | 1244 |
| show ntp source | 1245 |
| show ntp source-interface | 1246 |
| show ntp statistics | 1247 |
| show ntp status | 1248 |
| show ntp trusted-keys | 1249 |
| show ptp brief | 1250 |
| show ptp clock | 1251 |
| show ptp clock foreign-masters-record | 1253 |
| show ptp corrections | 1255 |
| show ptp parent | 1256 |
| show ptp port | 1258 |
| show ptp time-property | 1260 |
| show rmon | 1261 |
| show running-config | 1263 |
| show running-config callhome | 1265 |
| show running-config eem | 1266 |
| show running-config exclude-provision | 1268 |

Send comments to nexus3k-docfeedback@cisco.com

| | |
|---------------------------------------|------|
| show running-config interface | 1270 |
| show running-config monitor | 1271 |
| show running-config ptp | 1273 |
| show scheduler | 1275 |
| show sflow | 1277 |
| show sflow statistics | 1278 |
| show snmp community | 1279 |
| show snmp context | 1280 |
| show snmp engineID | 1281 |
| show snmp group | 1282 |
| show snmp host | 1283 |
| show snmp sessions | 1284 |
| show snmp trap | 1285 |
| show snmp user | 1286 |
| show startup-config | 1287 |
| show startup-config callhome | 1288 |
| show startup-config eem | 1289 |
| show startup-config exclude-provision | 1291 |
| show startup-config ptp | 1292 |
| show startup-config vtp | 1294 |
| show tech-support callhome | 1295 |
| shut (ERSPAN) | 1296 |
| site-id (Call Home) | 1297 |
| snmp-server community | 1298 |
| snmp-server contact | 1300 |
| snmp-server context | 1301 |
| snmp-server enable traps | 1303 |
| snmp-server enable traps link | 1306 |
| snmp-server enable traps vtp | 1308 |
| snmp-server globalEnforcePriv | 1309 |
| snmp-server host | 1310 |
| snmp-server location | 1312 |
| snmp-server mib community-map | 1313 |
| snmp-server tcp-session | 1315 |
| snmp-server user | 1316 |

Send comments to nexus3k-docfeedback@cisco.com

| | |
|--------------------------------------|------|
| snmp trap link-status | 1318 |
| source (SPAN, ERSPAN) | 1320 |
| source ip (ERSPAN) | 1322 |
| streetaddress (Call Home) | 1323 |
| switching-mode store-forward | 1324 |
| switchport mode monitor buffer-limit | 1325 |
| switch-priority (Call Home) | 1326 |
| tag | 1327 |
| terminal event-manager bypass | 1329 |
| transport email (Call Home) | 1330 |
| verify (session) | 1332 |
| vrf (ERSPAN) | 1333 |