



New and Changed Information

This chapter contains the following sections:

- [New and Changed Information for this Release, on page 1](#)

New and Changed Information for this Release

The following table provides an overview of the significant changes to this guide for this current release. The table does not provide an exhaustive list of all changes made to the configuration guides or of the new features in this release.

Table 1: New and Changed Features

Feature	Description	Added or Changed in Release	Where Documented
HTTP Put/Upload	You can now upload file into the HTTP server via default or management vrf interface.	6.0(2)U5(1)	Copying Files to the HTTP Server
POAP	You can now bypass password and basic POAP configuration by using the skip option at the POAP prompt.	6.0(2)U4(1)	Guidelines and Limitations for POAP
Copying files	Added support for using any valid character, such as ~, in the directory or filename. Also added support for the configuration of a non-default port when copying a file to an HTTP server.	6.0(2)U4(1)	Working with Configuration Files
Copy <i>file</i> start support	Added support for running the configuration file on startup.	6.0(2)U2(1)	Downloading the Startup Configuration From a Remote Server
PowerOn Auto Provisioning (POAP)	Added support for using first MAC address as client ID option for DHCP discovery	6.0(2)U1(1)	Using Power On Auto Provisioning

