



## New and Changed Information

This chapter provides release-specific information for each new and changed feature in the *Cisco Nexus 5000 Series NX-OS SAN Switching Configuration Guide*.

- [New and Changed Information, page 1](#)

## New and Changed Information

This chapter provides release-specific information for each new and changed feature in the *Cisco Nexus 5000 Series NX-OS SAN Switching Configuration Guide, Release #*.

The latest version of this document is available at the following Cisco website:

[http://www.cisco.com/en/US/products/ps9670/products\\_installation\\_and\\_configuration\\_guides\\_list.html](http://www.cisco.com/en/US/products/ps9670/products_installation_and_configuration_guides_list.html)

To check for additional information about Cisco NX-OS Release 4.2(1)N1(1), see the *Cisco Nexus 5000 Series NX-OS Release Notes* available at the following Cisco website:

[http://www.cisco.com/en/US/products/ps9670/prod\\_release\\_notes\\_list.html](http://www.cisco.com/en/US/products/ps9670/prod_release_notes_list.html)

This table summarizes the new and changed features documented in the *Cisco Nexus 5000 Series NX-OS SAN Switching Configuration Guide, Release 4.2(1)N1(1)*, and tells you where they are documented.

**Table 1: New and Changed SAN Switching Features for Cisco NX-OS Release 4.2(1)N1(1)**

Feature	Description	Changed in Release	Where to find it documented...
F Port Trunking	Added information about TF Ports and TNP Ports.	4.2(1)N1(1)	Configuring Fibre Channel Interfaces
F Port Channels	Added information about F and TF Port Channels.	4.2(1)N1(1)	Configuring SAN Port Channels

### Documentation Organization

As of Cisco NX-OS Release 4.2(1)N1(1), the Nexus 5000 Series configuration information is available in new feature-specific configuration guides for the following information:

- System Management

- Layer 2 Switching
- SAN Switching
- Fibre Channel over Ethernet
- Security
- Quality of Service

The information in these new guides previously existed in the *Cisco Nexus 5000 Series CLI Configuration Guide* which remains available on Cisco.com and should be used for all software releases prior to Cisco Nexus 5000 NX-OS Software Rel 4.1(3). Each new configuration guide addresses the features that are introduced in or are available in a particular release. Select and view the configuration guide that pertains to the software installed in your switch.

The information in the new *Cisco Nexus 5000 Series NX-OS SAN Switching Configuration Guide* previously existed in Part 7: SAN Switching of the *Cisco Nexus 5000 Series CLI Configuration Guide*.

For a complete list of Nexus 5000 Series document titles, see the list of Related Documentation in the "Preface."