



New and Changed Information

This chapter provides release-specific information for each new and changed feature in the *Cisco Nexus 5000 Series NX-OS SAN Switching Configuration Guide*.

- [New and Changed Information, page 1](#)

New and Changed Information

This chapter provides release-specific information for each new and changed feature in the *Cisco Nexus 5000 Series NX-OS SAN Switching Configuration Guide*.

The latest version of this document is available at the following Cisco website:

http://www.cisco.com/en/US/products/ps9670/products_installation_and_configuration_guides_list.html

To check for additional information about Cisco NX-OS, see the *Cisco Nexus 5000 Series NX-OS Release Notes* available at the following Cisco website:

http://www.cisco.com/en/US/products/ps9670/prod_release_notes_list.html

This table summarizes the new and changed features documented in the *Cisco Nexus 5000 Series NX-OS SAN Switching Configuration Guide, Release 5.0(2)N2(1)*, and tells you where they are documented.

Table 1: New and Changed SAN Switching Features for Cisco NX-OS Release 5.0(2)N2(1)

Feature	Description	Changed in Release	Where to find it documented...
VSAN Trunking	Added information about configuring virtual Fibre Channel interfaces in trunking mode.	5.0(2)N2(1)	Configuring VSAN Trunking
VE Port	Added information about configuring multi-hop FCoE fabric using VE ports.	5.0(2)N2(1)	Configuring Fibre Channel Interfaces

This table summarizes the new and changed features documented in the *Cisco Nexus 5000 Series NX-OS SAN Switching Configuration Guide, Release 4.2(1)N1(1)*, and tells you where they are documented.

Table 2: New and Changed SAN Switching Features for Cisco NX-OS Release 4.2(1)N1(1)

Feature	Description	Changed in Release	Where to find it documented...
F Port Trunking	Added information about TF Ports and TNP Ports.	4.2(1)N1(1)	Configuring Fibre Channel Interfaces
F Port Channels	Added information about F and TF Port Channels.	4.2(1)N1(1)	Configuring SAN Port Channels

Documentation Organization

As of Cisco NX-OS Release 4.2(1)N1(1), the Nexus 5000 Series configuration information is available in new feature-specific configuration guides for the following information:

- System Management
- Layer 2 Switching
- SAN Switching
- Fibre Channel over Ethernet
- Security
- Quality of Service

The information in these new guides previously existed in the *Cisco Nexus 5000 Series CLI Configuration Guide* which remains available on Cisco.com and should be used for all software releases prior to Cisco Nexus 5000 NX-OS Software Rel 4.1(3). Each new configuration guide addresses the features that are introduced in or are available in a particular release. Select and view the configuration guide that pertains to the software installed in your switch.

The information in the new *Cisco Nexus 5000 Series NX-OS SAN Switching Configuration Guide* previously existed in Part 7: SAN Switching of the *Cisco Nexus 5000 Series CLI Configuration Guide*.

For a complete list of Nexus 5000 Series document titles, see the list of Related Documentation in the "Preface."