



F Commands

This chapter describes the Cisco NX-OS virtual port channel (vPC) commands that begin with F.

feature vpc

To enable a virtual port channel (vPC), which allows links that are physically connected to two different Cisco Nexus 5000 Series devices to appear as a single port channel to a third device, use the **feature vpc** command. To disable vPC on the switch, use the **no** form of this command.

feature vpc

no feature vpc

Syntax Description This command has no arguments or keywords.

Command Default Disabled

Command Modes Global configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines In a vPC configuration, the third device can be a Cisco Nexus 2000 Series Fabric Extender, switch, server, or any other networking device.

Examples This example shows how to enable vPC on the switch:

```
switch(config)# feature vpc
```

Related Commands	Command	Description
	show vpc	Displays the vPC configuration status.
	show feature	Displays whether or not vPC is enabled on the switch.