



## X Commands

---

- [xml](#), on page 2
- [xml](#), on page 3
- [xml server max-session](#), on page 4
- [xml server terminate session](#), on page 5
- [xml server timeout](#), on page 6
- [xml server validate](#), on page 7
- [xml server xml-debug](#), on page 8
- [xmlin](#), on page 9
- [xmlin](#), on page 10
- [xmlin](#), on page 11
- [xmlin](#), on page 12
- [xmlout](#), on page 13

# xml

| xml

## Syntax Description

	Pipe command output to filter
xml	output in xml format (according to .xsd definitions)

## Command Mode

- /output

# xml

| xml

## Syntax Description

	Pipe command output to filter
xml	output in xml format (according to .xsd definitions)

## Command Mode

- /output

# xml server max-session

[no] xml server max-session <number>

## Syntax Description

no	(Optional) Negate a command or set its defaults
xml	xml agent
server	xml agent server
max-session	configure maximum number of xml sessions allowed
<i>number</i>	number of the sessions

## Command Mode

- /exec/configure

# xml server terminate session

xml server terminate session <session\_id>

## Syntax Description

xml	xml agent
server	xml agent server
terminate	command to terminate an XML session
session	terminate an XML session
<i>session_id</i>	sessions number

## Command Mode

- /exec

## xml server timeout

[no] xml server timeout <value> [ <session\_id> ]

### Syntax Description

no	(Optional) Negate a command or set its defaults
xml	xml agent
server	xml agent server
timeout	configure xml agent session timeout
<i>value</i>	timeout in seconds
<i>session_id</i>	(Optional) xml agent session id

### Command Mode

- /exec/configure

# xml server validate

[no] xml server validate { all | <session\_id> }

## Syntax Description

no	(Optional) Negate a command or set its defaults
xml	xml agent
server	xml agent server
validate	command to validate an XML session
all	all sessions
<i>session_id</i>	session number

## Command Mode

- /exec/configure

# xml server xml-debug

[no] xml server xml-debug

## Syntax Description

no	(Optional) Negate a command or set its defaults
xml	xml agent
server	xml server
xml-debug	xml server xml-debug

## Command Mode

- /exec/configure



# xmlin

xmlin

## Syntax Description

xmlin	Convert CLI commands to their XML formats
-------	---

## Command Mode

- /exec

# xmlin

| xmlin

## Syntax Description

	Pipe command output to filter
xmlin	Convert CLI show commands to their XML formats

## Command Mode

- /output

# xmlin

xmlin

## Syntax Description

xmlin	Convert CLI commands to their XML formats
-------	---

## Command Mode

- /exec

# xmlin

| xmlin

## Syntax Description

	Pipe command output to filter
xmlin	Convert CLI show commands to their XML formats

## Command Mode

- /output

# xmlout

| xmlout

## Syntax Description

	Pipe command output to filter
xmlout	output in xml format (according to the latest .xsd version)

## Command Mode

- /output

