



## INDEX

---

### A

aaa accounting dot1x command [2-1](#)  
aaa authentication dot1x command [2-3](#)  
AAA methods [2-3](#)  
access control entries  
    See ACEs  
access control lists  
    See ACLs  
access groups  
    IP [2-151](#)  
    MAC, displaying [2-539](#)  
    matching for QoS classification [2-287](#)  
access list, IPv6 [2-220](#)  
access mode [2-698](#)  
access ports [2-698](#)  
ACEs [2-91, 2-332](#)  
ACLs  
    as match criteria for QoS classes [2-287](#)  
    deny [2-89](#)  
    displaying [2-412](#)  
    for non-IP protocols [2-265](#)  
    IP [2-151](#)  
    on Layer 2 interfaces [2-151](#)  
    permit [2-330](#)  
action command [2-5](#)  
address aliasing [2-310](#)  
aggregate policers  
    applying [2-343](#)  
    creating [2-338](#)  
    displaying [2-574](#)  
    QoS [2-340](#)  
aggregate-port learner [2-319](#)

alarm-contact command [2-7](#)  
alarm-contact status, displaying [2-445](#)  
allowed VLANs [2-714](#)  
archive download-sw command [2-9](#)  
archive tar command [2-12](#)  
archive upload-sw command [2-15](#)  
arp (boot loader) command [A-2](#)  
arp access-list command [2-17](#)  
attaching policy maps to interfaces [2-393](#)  
authorization state of controlled port [2-105](#)  
autonegotiation of duplex mode [2-117](#)

---

### B

backup interfaces  
    configuring [2-691](#)  
    displaying [2-467](#)  
bandwidth, configuring for QoS [2-19](#)  
bandwidth command [2-19](#)  
boot (boot loader) command [A-3](#)  
boot config-file command [2-23](#)  
boot enable-break command [2-24](#)  
boot helper command [2-25](#)  
boot helper-config file command [2-26](#)  
booting  
    Cisco IOS image [2-29](#)  
    displaying environment variables [2-417](#)  
    interrupting [2-24](#)  
    manually [2-27](#)

## boot loader

- accessing [A-1](#)

- booting

- Cisco IOS image [A-3](#)

- helper image [2-25](#)

- directories

- creating [A-18](#)

- displaying a list of [A-8](#)

- removing [A-22](#)

- displaying

- available commands [A-13](#)

- memory heap utilization [A-14](#)

- version [A-29](#)

- environment variables

- described [A-23](#)

- displaying settings [A-23](#)

- location of [A-24](#)

- setting [A-23](#)

- unsetting [A-27](#)

- files

- copying [A-6](#)

- deleting [A-7](#)

- displaying a list of [A-8](#)

- displaying the contents of [A-5, A-19, A-26](#)

- renaming [A-20](#)

- file system

- formatting [A-11](#)

- initializing flash [A-10](#)

- running a consistency check [A-12](#)

- prompt [A-1](#)

- resetting the system [A-21](#)

- boot manual command [2-27](#)

- boot private-config-file command [2-28](#)

- boot system command [2-29](#)

- BPDU filtering, for spanning tree [2-636, 2-674](#)

- BPDU guard, for spanning tree [2-638, 2-674](#)

- broadcast storm control [2-684](#)

- bundling characteristics, UNI [2-127](#)

- burst bytes, in QoS policers [2-334, 2-339](#)

---

**C**

- cat (boot loader) command [A-5](#)

- CBWFQ, configuring [2-19](#)

- CDP, enabling protocol tunneling for [2-245](#)

- CFM [2-318](#)

- CFM as OAM protocol [2-318](#)

- channel-group command [2-30](#)

- channel-protocol command [2-34](#)

- child policy maps [2-395](#)

- class-based traffic shaping [2-410](#)

- class-based weighted fair queuing

- See CBWFQ

- class command [2-36](#)

- class-map command [2-38](#)

- class-map configuration mode [2-38](#)

- class maps

- creating [2-38](#)

- defining the match criteria [2-288, 2-290](#)

- displaying [2-421](#)

- matching in [2-38](#)

- class of service

- See CoS

- clear ip arp inspection log command [2-40](#)

- clear ip arp inspection statistics command [2-41](#)

- clear ipc command [2-44](#)

- clear ipv6 dhcp conflict command [2-45](#)

- clear l2protocol-tunnel counters command [2-46](#)

- clear lacp command [2-47](#)

- clear logging onboard command [2-48](#)

- clear mac address-table command [2-49, 2-50](#)

- clear pagp command [2-51, 2-55](#)

- clear policer cpu uni-eni counters command [2-52](#)

- clear port-security command [2-53](#)

- clear spanning-tree counters command [2-56](#)

- clear spanning-tree detected-protocols command [2-57](#)

- clear vmps statistics command [2-59](#)

- command modes defined [1-1](#)

- committed information rate in QoS policers [2-334, 2-338](#)

- configuration files
    - password recovery disable considerations [A-1](#)
    - specifying the name [2-23, 2-28](#)
  - configuring multiple interfaces [2-147](#)
  - conform-action command [2-60](#)
  - control-plane policer [2-52](#)
  - control-plane policer information, displaying [2-575](#)
  - control-plane security [2-345](#)
  - control plane statistics, clearing [2-52](#)
  - copy (boot loader) command [A-6](#)
  - copy logging onboard module command [2-62](#)
  - CoS
    - as match criteria for QoS groups [2-288](#)
    - for QoS classification [2-397](#)
    - setting value in policy maps [2-397](#)
  - CoS value, assigning to Layer 2 protocol packets [2-248](#)
  - CPU ASIC statistics, displaying [2-422](#)
  - CPU protection policers, displaying [C-26](#)
  - cpu traffic qos cos command [2-64](#)
  - cpu traffic qos dscp command [2-68](#)
  - cpu traffic qos precedence command [2-73](#)
  - cpu traffic qos qos-group command [2-76](#)
- 
- D**
- DC power supply [2-354](#)
  - debug backup command [B-2](#)
  - debug dot1x command [B-3](#)
  - debug etherchannel command [B-4](#)
  - debug interface command [B-7](#)
  - debug ip dhcp snooping command [B-8](#)
  - debug ip igmp filter command [B-9](#)
  - debug ip igmp max-groups command [B-10](#)
  - debug ip igmp snooping command [B-11](#)
  - debug ip sla error twamp connection command [B-12](#)
  - debug ip sla error twamp control reflector command [B-14](#)
  - debug ip sla error twamp control server command [B-16](#)
  - debug ip sla error twamp session command [B-18](#)
  - debug ip sla trace twamp connection command [B-20](#)
  - debug ip sla trace twamp control reflector command [B-22](#)
  - debug ip sla trace twamp control server command [B-24](#)
  - debug ip sla trace twamp session command [B-26](#)
  - debug ip verify source packet command [B-28](#)
  - debug lacp command [B-29](#)
  - debug mac-notification command [B-30](#)
  - debug matm command [B-31](#)
  - debug matm move update command [B-32](#)
  - debug monitor command [B-33](#)
  - debug mvrdbg command [B-34](#)
  - debug nvram command [B-35](#)
  - debug pagp command [B-36](#)
  - debug platform acl command [B-37](#)
  - debug platform backup interface command [B-38](#)
  - debug platform cfm command [B-39](#)
  - debug platform cpu-queues command [B-40](#)
  - debug platform dot1ad command [B-42](#)
  - debug platform dot1x command [B-43](#)
  - debug platform etherchannel command [B-44](#)
  - debug platform forw-tcam command [B-45](#)
  - debug platform ip arp inspection command [B-46](#)
  - debug platform ipc command [B-55](#)
  - debug platform ip dhcp command [B-47](#)
  - debug platform ip igmp snooping command [B-48](#)
  - debug platform ip multicast command [B-50](#)
  - debug platform ip source-guard command [B-52](#)
  - debug platform led command [B-56](#)
  - debug platform matm command [B-57](#)
  - debug platform messaging application command [B-58](#)
  - debug platform phy command [B-59](#)
  - debug platform pm command [B-61](#)
  - debug platform policer cpu uni-eni command [B-63](#)
  - debug platform port-asic command [B-64](#)
  - debug platform port-security command [B-65](#)
  - debug platform qos-acl-tcam command [B-66](#)
  - debug platform qos-manager command [B-67](#)
  - debug platform remote-commands command [B-68](#)
  - debug platform rep command [B-69](#)
  - debug platform resource-manager command [B-70](#)

- debug platform snmp command [B-71](#)
- debug platform span command [B-72](#)
- debug platform supervisor-asic command [B-73](#)
- debug platform sw-bridge command [B-74](#)
- debug platform team command [B-75](#)
- debug platform uddl command [B-77](#)
- debug platform vlan command [B-78](#)
- debug pm command [B-79](#)
- debug port-security command [B-81](#)
- debug qos-manager command [B-83](#)
- debug rep command [B-82](#)
- debug spanning-tree bpdu command [B-86](#)
- debug spanning-tree bpdu-opt command [B-87](#)
- debug spanning-tree command [B-84](#)
- debug spanning-tree mstp command [B-88](#)
- debug spanning-tree switch command [B-90](#)
- debug sw-vlan command [B-92](#)
- debug sw-vlan ifs command [B-93](#)
- debug sw-vlan notification command [B-94](#)
- debug uddl command [B-96](#)
- debug vqpc command [B-98](#)
- default policer configuration
  - NNIs [C-29](#)
  - UNIs [C-27](#)
- define interface-range command [2-78](#)
- delete (boot loader) command [A-7](#)
- delete command [2-80](#)
- deny (ARP access-list configuration) command [2-81](#)
- deny (IPv6) command [2-83](#)
- deny command [2-89](#)
- detect mechanism, causes [2-118](#)
- DHCP snooping
  - accepting untrusted packets from edge switch [2-176](#)
  - enabling
    - on a VLAN [2-182](#)
    - option 82 [2-174, 2-176](#)
    - trust on an interface [2-180](#)
  - error recovery timer [2-120](#)
  - rate limiting [2-179](#)
- DHCP snooping binding database
  - binding file, configuring [2-172](#)
  - bindings
    - adding [2-170](#)
    - deleting [2-170](#)
    - displaying [2-490](#)
  - clearing database agent statistics [2-42](#)
  - database agent, configuring [2-172](#)
  - displaying
    - binding entries [2-490](#)
    - database agent status [2-492, 2-494](#)
    - renewing [2-369](#)
- diagnostic monitor command [2-92](#)
- diagnostic schedule test command [2-94](#)
- diagnostic start test command [2-96](#)
- differentiated service code point
  - See DSCP
- Digital Optical Monitoring
  - see DoM
- dir (boot loader) command [A-8](#)
- directories, deleting [2-80](#)
- DoM
  - displaying supported transceivers [2-479, 2-626, 2-627](#)
- domains, CFM [2-318](#)
- dot1x default command [2-98](#)
- dot1x host-mode command [2-99](#)
- dot1x initialize command [2-101](#)
- dot1x max-req command [2-102, 2-104](#)
- dot1x port-control command [2-105](#)
- dot1x re-authenticate command [2-107](#)
- dot1x reauthentication command [2-108](#)
- dot1x supplicant force-multicast command [2-109](#)
- dot1x system-auth-control command [2-110](#)
- dot1x test eapol-capable command [2-111](#)
- dot1x test timeout command [2-112](#)
- dot1x timeout command [2-113](#)
- dot1x violation-mode command [2-115](#)
- drop eligibility indicator [2-399](#)
- drop eligibility indicator bit [2-290](#)

- dropping packets, with ACL matches [2-5](#)
- drop threshold, Layer 2 protocol tunneling [2-245](#)
- DSCP
  - as match criteria for QoS groups [2-292](#), [2-298](#)
  - for QoS traffic marking [2-401](#)
  - setting in policy maps [2-401](#)
- dual IPv4 and IPv6 templates [2-325](#)
- dual-purpose uplink ports, selecting the type [2-303](#)
- duplex command [2-116](#)
- dynamic-access ports
  - configuring [2-689](#)
  - restrictions [2-690](#)
- dynamic ARP inspection
  - ARP ACLs
    - apply to a VLAN [2-156](#)
    - define [2-17](#)
    - deny packets [2-81](#)
    - display [2-416](#)
    - permit packets [2-323](#)
  - clear
    - log buffer [2-40](#)
    - statistics [2-41](#)
  - display
    - ARP ACLs [2-416](#)
    - configuration and operating state [2-485](#)
    - log buffer [2-485](#)
    - statistics [2-485](#)
    - trust state and rate limit [2-485](#)
  - enable per VLAN [2-165](#)
  - error detection for [2-118](#)
  - error recovery timer [2-120](#)
  - log buffer
    - clear [2-40](#)
    - configure [2-160](#)
    - display [2-485](#)
  - rate-limit incoming ARP packets [2-158](#)
  - statistics
    - clear [2-41](#)
    - display [2-485](#)

- dynamic ARP inspection (continued)
  - trusted interface state [2-162](#)
  - type of packet logged [2-166](#)
  - validation checks [2-163](#)
- Dynamic Host Configuration Protocol (DHCP)
  - See DHCP snooping

---

## E

- EAP-request/identity frame
  - maximum number to send [2-104](#)
  - response time before retransmitting [2-113](#)
- E-LMI
  - enabling [2-125](#)
  - mapping [2-127](#)
- environment variables, displaying [2-417](#)
- errdisable detect cause command [2-118](#)
- errdisable recovery command [2-120](#)
- error conditions, displaying [2-449](#)
- error disable detection [2-118](#)
- error-disabled interfaces, displaying [2-467](#)
- EtherChannel
  - assigning Ethernet interface to channel group [2-30](#)
  - creating port-channel logical interface [2-145](#)
  - debug EtherChannel/PAgP, display [B-4](#)
  - debug platform-specific events, display [B-44](#)
  - displaying [2-453](#)
  - enabling Layer 2 protocol tunneling for
    - LACP [2-246](#)
    - PAgP [2-246](#)
    - UDLD [2-246](#)
  - interface information, displaying [2-467](#)

## EtherChannel (continued)

## LACP

- clearing channel-group information [2-47](#)
- debug messages, display [B-29](#)
- displaying [2-525](#)
- modes [2-30](#)
- port priority for hot-standby ports [2-249](#)
- restricting a protocol [2-34](#)
- system priority [2-251](#)

load-distribution methods [2-350](#)

## PAgP

- aggregate-port learner [2-319](#)
- clearing channel-group information [2-51](#)
- debug messages, display [B-36](#)
- displaying [2-570](#)
- error detection for [2-118](#)
- error recovery timer [2-120](#)
- learn method [2-319](#)
- modes [2-30](#)
- physical-port learner [2-319](#)
- priority of interface for transmitted traffic [2-321](#)

Ethernet controller, internal register display [2-424](#)ethernet dot1ad command [2-122](#)ethernet evc command [2-124](#)ethernet lmi ce-vlan map command [2-125, 2-127](#)ethernet lmi command [2-125](#)ethernet lmi global command [2-125](#)

## Ethernet Local Management Interface

See E-LMI

ethernet loopback interface configuration command [2-129](#)ethernet loopback privileged EXEC command [2-132](#)ethernet oam remote-failure command [2-134](#)

## Ethernet service

- debugging [B-5](#)
- displaying [2-458](#)

Ethernet service instance [2-389](#)Ethernet service interfaces [2-461](#)Ethernet statistics, collecting [2-385](#)Ethernet UNI configuration [2-136](#)ethernet uni id command [2-138](#)

## Ethernet virtual connections

See EVCs

EVC configuration mode [2-124](#)EVCs [2-124](#)

- and VLANs [2-136](#)
- service instances [2-389](#)
- UNI counts [2-737](#)

## EVC service

- point-to-multipoint [2-737](#)
- point-to-point [2-737](#)

exceed-action command [2-139](#)

## extended-range VLANs

- and allowed VLAN list [2-714](#)
- configuring [2-743](#)

extended system ID for STP [2-644](#)external alarms, configuring [2-7](#)


---

**F**

## failure logging data

- clearing [2-48](#)
- copying [2-62](#)

fan information, displaying [2-445](#)files, deleting [2-80](#)flash\_init (boot loader) command [A-10](#)

## Flex Links

- configuring [2-691](#)
- configuring preferred VLAN [2-693](#)
- displaying [2-467](#)

flowcontrol command [2-141](#)format (boot loader) command [A-11](#)forwarding packets, with ACL matches [2-5](#)forwarding results, display [C-8](#)frame forwarding information, displaying [C-8](#)front-end controller counter and status information [C-10](#)fsck (boot loader) command [A-12](#)

**G**

global configuration mode [1-2, 1-3](#)

**H**

hardware ACL statistics [2-412](#)  
 health-monitoring diagnostic testing [2-92](#)  
 help (boot loader) command [A-13](#)  
 host connection, port configuration [2-697](#)  
 host ports, private VLANs [2-701](#)  
 hw-module module logging onboard command [2-143](#)

**I**

IEEE 802.1ag Connectivity Fault Management

See CFM

IEEE 802.1Q trunk ports and native VLANs [2-748](#)

IEEE 802.1Q tunnel ports

configuring [2-698](#)  
 displaying [2-441](#)  
 limitations [2-699](#)

IEEE 802.1x

and switchport modes [2-699](#)  
 violation error recovery [2-120](#)

See also port-based authentication

IGMP filters

applying [2-185](#)  
 debug messages, display [B-9](#)

IGMP groups, setting maximum [2-187](#)

IGMP maximum groups, debugging [B-10](#)

IGMP profiles

creating [2-189](#)  
 displaying [2-497](#)

IGMP snooping

adding ports as a static member of a group [2-204](#)  
 displaying [2-498, 2-502, 2-504](#)  
 enabling [2-191](#)  
 enabling the configurable-leave timer [2-193](#)  
 enabling the Immediate-Leave feature [2-201](#)  
 flooding query count [2-199](#)  
 interface topology change notification behavior [2-200](#)  
 multicast table [2-500](#)  
 querier [2-195](#)  
 query solicitation [2-199](#)  
 report suppression [2-197](#)  
 switch topology change notification behavior [2-199](#)

images

See software images

Immediate-Leave feature, MVR [2-312](#)

immediate-leave processing [2-201](#)

Immediate-Leave processing, IPv6 [2-241](#)

input policy maps

and ACL classification [2-287](#)  
 and aggregate policers [2-340](#)  
 commands not supported in [2-348](#)  
 configuration guidelines [2-348](#)

interface command [2-149](#)

interface configuration mode [1-2, 1-4](#)

interface port-channel command [2-145](#)

interface range command [2-147](#)

interface-range macros [2-78](#)

interfaces

assigning Ethernet interface to channel group [2-30](#)  
 configuring [2-116](#)  
 configuring multiple [2-147](#)  
 creating port-channel logical [2-145](#)  
 debug messages, display [B-7](#)  
 disabling [2-621](#)  
 displaying the MAC address table [2-551](#)  
 restarting [2-621](#)

interface speed, configuring [2-682](#)

internal registers, displaying [2-424, 2-431](#)

## Internet Group Management Protocol

See IGMP

## invalid GBIC

error detection for [2-118](#)

error recovery timer [2-120](#)

ip address command [2-154](#)

IP addresses, setting [2-154](#)

IP address matching [2-285](#)

ip arp inspection filter vlan command [2-156](#)

ip arp inspection limit command [2-158](#)

ip arp inspection log-buffer command [2-160](#)

ip arp inspection trust command [2-162](#)

ip arp inspection validate command [2-163](#)

ip arp inspection vlan command [2-165](#)

ip arp inspection vlan logging command [2-166](#)

## IP DHCP snooping

See DHCP snooping

ip dhcp snooping binding command [2-170](#)

ip dhcp snooping command [2-169](#)

ip dhcp snooping database command [2-172](#)

ip dhcp snooping information option allow-untrusted command [2-176](#)

ip dhcp snooping information option command [2-174](#)

ip dhcp snooping information option format remote-id command [2-178](#)

ip dhcp snooping limit rate command [2-179](#)

ip dhcp snooping trust command [2-180](#)

ip dhcp snooping verify command [2-181](#)

ip dhcp snooping vlan command [2-182](#)

ip dhcp snooping vlan information option format-type circuit-id string command [2-183](#)

ip igmp filter command [2-185](#)

ip igmp max-groups command [2-187, 2-214, 2-216](#)

ip igmp profile command [2-189](#)

ip igmp snooping command [2-191](#)

ip igmp snooping last-member-query-interval command [2-193](#)

ip igmp snooping querier command [2-195](#)

ip igmp snooping report-suppression command [2-197](#)

ip igmp snooping tcn command [2-199](#)

ip igmp snooping tcn flood command [2-200](#)

ip igmp snooping vlan immediate-leave command [2-201](#)

ip igmp snooping vlan mrouter command [2-202](#)

ip igmp snooping vlan static command [2-204](#)

IP multicast addresses [2-309](#)

IP precedence, as match criteria for QoS groups [2-294](#)

ip sla responder twamp command [2-206](#)

ip sla server twamp command [2-208](#)

ip source binding command [2-210](#)

## IP source guard

disabling [2-218](#)

displaying

binding entries [2-511](#)

configuration [2-512](#)

enabling [2-218](#)

static IP source bindings [2-210](#)

IP source guard, displaying dynamic binding entries [2-490](#)

ip ssh command [2-212](#)

IPv6 access list, deny conditions [2-83](#)

ipv6 access-list command [2-220](#)

ipv6 address dhcp command [2-222](#)

ipv6 dhcp client request vendor command [2-223](#)

ipv6 dhcp ping packets command [2-224](#)

ipv6 dhcp pool command [2-225](#)

ipv6 dhcp server command [2-228](#)

ipv6 mld snooping command [2-230](#)

ipv6 mld snooping last-listener-query count command [2-232](#)

ipv6 mld snooping last-listener-query-interval command [2-234](#)

ipv6 mld snooping listener-message-suppression command [2-236](#)

ipv6 mld snooping robustness-variable command [2-237](#)

ipv6 mld snooping tcn command [2-239](#)

ipv6 mld snooping vlan command [2-241](#)

IPv6 SDM template [2-386](#)

ipv6 traffic-filter command [2-243](#)

ip verify source command [2-218](#)



**J**

jumbo frames

See MTU

**L**

l2protocol-tunnel command [2-245](#)

l2protocol-tunnel cos command [2-248](#)

LACP

See EtherChannel

lacp port-priority command [2-249](#)

lacp system-priority command [2-251](#)

Layer 2 mode, enabling [2-687](#)

Layer 2 protocol ports, displaying [2-523](#)

Layer 2 protocol-tunnel

error detection for [2-118](#)

error recovery timer [2-120](#)

Layer 2 protocol tunnel counters [2-46](#)

Layer 2 protocol tunneling error recovery [2-246](#)

Layer 2 traceroute

IP addresses [2-730](#)

MAC addresses [2-727](#)

Layer 3 mode, enabling [2-687](#)

line configuration mode [1-2, 1-4](#)

Link Aggregation Control Protocol

See EtherChannel

link flap

error detection for [2-118](#)

error recovery timer [2-120](#)

link state group command [2-253](#)

link state track command [2-255](#)

load-distribution methods for EtherChannel [2-350](#)

location (global configuration) command [2-256](#)

location (interface configuration) command [2-258](#)

logging event command [2-260](#)

logging file command [2-261](#)

logical interface [2-145](#)

loopback error

detection for [2-118](#)

recovery timer [2-120](#)

loop guard, for spanning tree [2-646, 2-650](#)

**M**

mac access-group command [2-263](#)

MAC access-groups, displaying [2-539](#)

MAC access list configuration mode [2-265](#)

mac access-list extended command [2-265](#)

MAC access lists [2-89](#)

MAC addresses

disabling MAC address learning per VLAN [2-268](#)

displaying

aging time [2-545](#)

all [2-543](#)

dynamic [2-549](#)

MAC address-table move updates [2-554](#)

notification settings [2-553, 2-556](#)

number of addresses in a VLAN [2-547](#)

per interface [2-551](#)

per VLAN [2-560](#)

static [2-558](#)

static and dynamic entries [2-541](#)

dynamic

aging time [2-267](#)

deleting [2-49](#)

displaying [2-549](#)

enabling MAC address notification [2-272](#)

enabling MAC address-table move update [2-270](#)

matching [2-285](#)

static

adding and removing [2-274](#)

displaying [2-558](#)

dropping on an interface [2-275](#)

tables [2-543](#)

MAC address notification, debugging [B-30](#)

mac address-table aging-time [2-263, 2-285](#)

- mac address-table aging-time command [2-267](#)
- mac address-table learning command [2-268](#)
- mac address-table move update command [2-270](#)
- mac address-table notification command [2-272](#)
- mac address-table static command [2-274](#)
- mac address-table static drop command [2-275](#)
- macro description command [2-279](#)
- macro global command [2-280](#)
- macro global description command [2-282](#)
- macro name command [2-283](#)
- macros
  - adding a description [2-279](#)
  - adding a global description [2-282](#)
  - applying [2-280](#)
  - creating [2-283](#)
  - displaying [2-572](#)
  - interface range [2-78, 2-147](#)
  - specifying parameter values [2-280](#)
  - tracing [2-280](#)
- maintenance end points [2-737](#)
- mapping tables, QoS [2-723](#)
- maps
  - class
    - creating [2-38](#)
  - VLAN
    - creating [2-746](#)
    - defining [2-285](#)
    - displaying [2-615](#)
- match access-group command [2-287](#)
- match cos command [2-288](#)
- match dot1ad dei command [2-290](#)
- match ip dscp command [2-292](#)
- match ip precedence command [2-294](#)
- match qos-group command [2-296](#)
- match vlan command [2-298](#)
- maximum transmission unit
  - See MTU
- mdix auto command [2-301](#)
- ME 3400EG-2CS switch policers [C-26](#)
- ME 3400E-24TS switch policers [C-26, C-27](#)
- ME 3400EG-12CS switch policers [C-26](#)
- media-type command [2-303](#)
- memory (boot loader) command [A-14](#)
- mgmt\_clr (boot loader) command [A-15](#)
- mgmt\_init (boot loader) command [A-16, A-17](#)
- mkdir (boot loader) command [A-18](#)
- MLD snooping
  - configuring [2-236, 2-237](#)
  - configuring queries [2-232, 2-234](#)
  - configuring topology change notification [2-239](#)
  - enabling [2-230](#)
- MLD snooping on a VLAN, enabling [2-241](#)
- mode, MVR [2-309](#)
- modes, commands [1-1](#)
- monitor session command [2-305](#)
- more (boot loader) command [A-19](#)
- MSTP
  - displaying [2-594](#)
  - interoperability [2-57](#)
  - link type [2-648](#)
  - MST region
    - aborting changes [2-654](#)
    - applying changes [2-654](#)
    - configuration name [2-654](#)
    - configuration revision number [2-655](#)
    - current or pending display [2-655](#)
    - displaying [2-594](#)
    - MST configuration mode [2-654](#)
    - VLANs-to-instance mapping [2-654](#)
  - path cost [2-656](#)
  - protocol mode [2-652](#)
  - restart protocol migration process [2-57](#)
  - root port
    - loop guard [2-646](#)
    - preventing from becoming designated [2-646](#)
    - restricting which can be root [2-646](#)
    - root guard [2-646](#)

## MSTP (continued)

## root switch

- affects of extended system ID [2-644](#)
- hello-time [2-659, 2-670](#)
- interval between BPDU messages [2-661](#)
- interval between hello BPDU messages [2-659, 2-670](#)
- max-age [2-661](#)
- maximum hop count before discarding BPDU [2-663](#)
- port priority for selection of [2-665](#)
- primary or secondary [2-670](#)
- switch priority [2-668](#)

## state changes

- blocking to forwarding state [2-677](#)
- enabling BPDU filtering [2-636, 2-674](#)
- enabling BPDU guard [2-638, 2-674](#)
- enabling Port Fast [2-674, 2-677](#)
- forward-delay time [2-658](#)
- length of listening and learning states [2-658](#)
- rapid transition to forwarding [2-648](#)
- shutting down Port Fast-enabled ports [2-674](#)

state information display [2-593](#)

## MTU

- configuring size [2-720](#)
- displaying global setting [2-601](#)

multicast group address, MVR [2-312](#)multicast groups, MVR [2-310](#)

## Multicast Listener Discovery

See MLD

- multicast router learning method [2-202](#)
- multicast router ports, configuring [2-202](#)
- multicast router ports, IPv6 [2-241](#)
- multicast storm control [2-684](#)
- multicast VLAN, MVR [2-310](#)
- multicast VLAN registration

See MVR

multiple hosts on authorized port [2-99](#)

## Multiple Spanning Tree Protocol

See MSTP

multiplexing, UNI [2-136](#)

## MVR

- and address aliasing [2-310](#)
- configuring [2-309](#)
- configuring interfaces [2-312](#)
- debug messages, display [B-34](#)
- displaying [2-564](#)
- displaying interface information [2-566](#)
- members, displaying [2-568](#)

mvr (global configuration) command [2-309](#)mvr (interface configuration) command [2-312](#)mvr vlan group command [2-313](#)

---

**N**native VLANs [2-714](#)native VLAN tagging [2-748](#)network node interface [2-352](#)no authentication logging verbose [2-315](#)no dot1x logging verbose [2-316](#)no mab logging verbose [2-317](#)nonegotiate, speed [2-682, 2-683](#)

## non-IP protocols

denying [2-89](#)forwarding [2-330](#)non-IP traffic access lists [2-265](#)

## non-IP traffic forwarding

denying [2-89](#)permitting [2-330](#)normal-range VLANs [2-743](#)no vlan command [2-743](#)

---

**O**OAM PDUs [2-134](#)OAM protocol [2-318](#)

oam protocol cfm svlan command [2-318](#)

on-board failure logging, displaying [2-535](#)

on-board failure logging, enabling [2-143](#)

online diagnostics

- enabling
  - scheduling [2-94](#)
- global configuration mode
  - clearing test-based testing schedule [2-94](#)
  - setting test-based testing [2-94](#)
  - setting up test-based testing [2-94](#)
- removing scheduling [2-94](#)
- scheduled switchover
  - disabling [2-94](#)
  - enabling [2-94](#)
  - setting test interval [2-94](#)
  - starting testing [2-96](#)

online diagnostic tests, displaying results [2-437](#)

online diagnostic tests, starting [2-96](#)

operation, administration, and maintenance protocol

- See OAM

output policy maps

- and QoS group classification [2-296](#)
- and traffic shaping [2-410](#)
- commands not supported in [2-348](#)
- configuration guidelines [2-348](#)
- priority in [2-357](#)
- queue limit in [2-364](#)

## P

### PAGP

See EtherChannel

pagp learn-method command [2-319](#)

pagp port-priority command [2-321](#)

parent policy maps [2-395](#)

password-recovery mechanism, enabling and disabling [2-391](#)

permit (ARP access-list configuration) command [2-323](#)

permit (IPv6) command [2-325](#)

permit command [2-330](#)

per-VLAN spanning-tree plus

- See STP

physical-port learner [2-319](#)

PID, displaying [2-483](#)

PIM-DVMRP, as multicast router learning method [2-202](#)

police

- multiple conform actions for a class [2-60](#)
- multiple exceed actions for a class [2-139](#)
- multiple violate actions for a class [2-741](#)
- with priority [2-333](#)

police aggregate command [2-343](#)

police command [2-333](#)

policer aggregate command [2-338](#)

policer configuration

- default for NNIs [C-29](#)
- default for UNIs [C-27](#)

policer cpu uni command [2-345](#)

policers

- aggregate [2-338, 2-343](#)
- for CPU protection [2-345](#)
- individual [2-333](#)

policy-map class, configuring multiple actions [2-60, 2-139, 2-741](#)

policy-map class configuration mode [2-36](#)

policy-map class police configuration mode [2-60, 2-336](#)

policy-map command [2-347](#)

policy-map configuration mode [2-347](#)

policy maps

- and CoS classification [2-288](#)
- and DSCP classification [2-292](#)
- and IP precedence classification [2-294](#)
- and policing [2-336](#)
- applying [2-393](#)
- applying to an interface [2-348, 2-393, 2-407](#)
- child [2-395](#)
- creating [2-347](#)
- displaying [2-578](#)
- hierarchical [2-395](#)

- policy maps 9(continued)
  - parent [2-395](#)
  - policers
    - for a single class [2-333](#)
    - for multiple classes [2-338, 2-343, 2-345, 2-395](#)
  - setting priority [2-356](#)
  - setting QoS group identifier [2-405](#)
  - traffic classification, defining [2-36](#)
  - traffic marking
    - setting CoS values [2-397](#)
    - setting DSCP values [2-399, 2-401](#)
    - setting IP precedence values [2-403](#)
- Port Aggregation Protocol
  - See EtherChannel
- port-based authentication
  - AAA method list [2-3](#)
  - configuring violation modes [2-115](#)
  - debug messages, display [B-3](#)
  - enabling 802.1x
    - globally [2-110](#)
    - per interface [2-105](#)
  - host modes [2-99](#)
  - IEEE 802.1x AAA accounting methods [2-1](#)
  - initialize an interface [2-101, 2-112](#)
  - manual control of authorization state [2-105](#)
  - multiple hosts on authorized port [2-99](#)
  - periodic re-authentication
    - enabling [2-108](#)
    - time between attempts [2-113](#)
  - quiet period between failed authentication exchanges [2-113](#)
  - re-authenticating 802.1x-enabled ports [2-107](#)
  - resetting configurable 802.1x parameters [2-98](#)
  - switch-to-authentication server retransmission time [2-113](#)
  - switch-to-client frame-retransmission number [2-102 to 2-104](#)
  - switch-to-client retransmission time [2-113](#)
  - test for IEEE 802.1x readiness [2-111](#)
- port-channel load-balance command [2-350](#)
- Port Fast, for spanning tree [2-677](#)
- port ranges, defining [2-48, 2-62, 2-78](#)
- ports, debugging [B-79](#)
- ports, protected [2-712](#)
- port security
  - aging [2-708](#)
  - debug messages, display [B-81](#)
  - enabling [2-704](#)
  - violation error recovery [2-120](#)
- port shaping [2-411](#)
- port-type command [2-352](#)
- port types, MVR [2-312](#)
- power information, displaying [2-445](#)
- power-supply alarm indications, configuring [2-354](#)
- power-supply dual command [2-354](#)
- power-supply status, displaying [2-445](#)
- precedence
  - for QoS traffic marking [2-403](#)
  - setting in policy maps [2-403](#)
- priority command [2-356](#)
- priority queuing, QoS [2-356](#)
- priority with police, QoS [2-356](#)
- private-vlan command [2-359](#)
- private-vlan mapping command [2-362](#)
- private VLANs
  - association [2-710](#)
  - configuring [2-359](#)
  - configuring ports [2-701](#)
  - displaying [2-610](#)
  - host ports [2-701](#)
  - mapping
    - configuring [2-710](#)
    - displaying [2-467](#)
  - promiscuous ports [2-701](#)
- privileged EXEC mode [1-2, 1-3](#)
- product identification information, displaying [2-483](#)
- promiscuous ports, private VLANs [2-701](#)
- PVST+
  - See STP

**Q**

## QoS

## aggregate policers

applying [2-343](#)creating [2-338](#)displaying [2-574](#)

## class maps

creating [2-38](#)defining the match criteria [2-288, 2-290](#)displaying [2-421](#)conform actions, configuring [2-61](#)displaying statistics for [2-578, C-36](#)exceed actions, configuring [2-140](#)

## policy maps

applying an aggregate policer [2-338, 2-343, 2-345, 2-395](#)applying to an interface [2-393, 2-407](#)creating [2-347](#)defining policers [2-333](#)displaying policy maps [2-578](#)setting CoS values [2-397](#)setting DSCP values [2-399, 2-401](#)setting IP precedence values [2-403](#)setting QoS group identifier [2-405](#)traffic classifications [2-36](#)

## table maps

configuring [2-723](#)displaying [2-603](#)violate actions, configuring [2-742](#)

## QoS groups

as match criteria [2-296](#)for QoS traffic classification [2-405](#)setting in policy maps [2-405](#)

## QoS match criteria

ACLs [2-287](#)CoS value [2-288](#)DSCP value [2-292, 2-298](#)precedence value [2-294](#)

## QoS match criteria (continued)

QoS group number [2-296](#)

## quality of service

See QoS

querytime, MVR [2-309](#)queue-limit command [2-364](#)**R**

## rapid per-VLAN spanning-tree plus

See STP

## rapid PVST+

See STP

re-authenticating 802.1x-enabled ports [2-107](#)

## re-authentication

periodic [2-108](#)time between attempts [2-113](#)receiver ports, MVR [2-312](#)receiving flow-control packets [2-141](#)

## recovery mechanism

causes [2-120](#)display [2-419, 2-447, 2-451](#)timer interval [2-121](#)remote-span command [2-367](#)

## Remote Switched Port Analyzer

See RSPAN

rename (boot loader) command [A-20](#)renew ip dhcp snooping database command [2-369](#)rep admin vlan command [2-370](#)rep block port command [2-371](#)rep lsl-age-timer command [2-375](#)rep preempt delay command [2-377](#)rep preempt segment command [2-379](#)rep segment command [2-380](#)rep stcn command [2-383](#)reset (boot loader) command [A-21](#)resource templates, displaying [2-591](#)rmdir (boot loader) command [A-22](#)rmon collection stats command [2-385](#)

root guard, for spanning tree [2-646](#)

routed ports

IP addresses on [2-155](#)

number supported [2-155](#)

RSPAN

configuring [2-305](#)

displaying [2-562](#)

filter RSPAN traffic [2-305](#)

remote-span command [2-367](#)

sessions

add interfaces to [2-305](#)

displaying [2-562](#)

start new [2-305](#)

## S

scheduled switchover

disabling [2-94](#)

enabling [2-94](#)

scheduling diagnostic tests [2-94](#)

sdm prefer command [2-386](#)

SDM templates

allowed resources [2-387](#)

displaying [2-591](#)

dual IPv4 and IPv6 [2-386](#)

secure ports, limitations [2-706](#)

sending flow-control packets [2-141](#)

service instance command [2-389](#)

service instances, displaying [2-459](#)

service password-recovery command [2-391](#)

service policy (policy-map class configuration) command [2-395](#)

service-policy interface configuration command [2-393](#)

service-policy policy-map class configuration command [2-395](#)

set (boot loader) command [A-23](#)

set cos command [2-397](#)

set dot1ad dei command [2-399](#)

set dscp command [2-401](#)

set precedence command [2-403](#)

set qos-group command [2-405](#)

setup command [2-407](#)

SFPs, displaying information about [2-483](#)

shape average command [2-410](#)

show access-lists command [2-412](#)

show aggregate-policer command [2-603](#)

show archive status command [2-415](#)

show arp access-list command [2-416](#)

show boot command [2-417](#)

show class-map command [2-421](#)

show controllers cpu-interface command [2-422](#)

show controllers ethernet-controller command [2-424](#)

show controllers team command [2-431](#)

show controllers utilization command [2-433](#)

show controller utilization command [2-433](#)

show cpu traffic qos command [2-435](#)

show diagnostic command [2-437](#)

show dot1q-tunnel command [2-441](#)

show dot1x command [2-442](#)

show env command [2-445](#)

show errdisable detect command [2-447](#)

show errdisable flap-values command [2-449](#)

show errdisable recovery command [2-451](#)

show etherchannel command [2-453](#)

show ethernet loopback command [2-456](#)

show ethernet service evc command [2-458](#)

show ethernet service instance command [2-459](#)

show ethernet service interface command [2-461](#)

show flowcontrol command [2-463](#)

show idprom command [2-465](#)

show interface rep command [2-477](#)

show interfaces command [2-467](#)

show interfaces counters command [2-475](#)

show interfaces rep command [2-477](#)

show interface transceivers command [2-479](#)

show inventory command [2-483](#)

show ip arp inspection command [2-485](#)

show ipc command [2-514](#)

- show ip dhcp snooping binding command [2-490](#)
- show ip dhcp snooping command [2-489](#)
- show ip dhcp snooping database command [2-492, 2-494](#)
- show ip igmp profile command [2-497](#)
- show ip igmp snooping command [2-498](#)
- show ip igmp snooping command querier detail [2-504](#)
- show ip igmp snooping groups command [2-500](#)
- show ip igmp snooping mrouter command [2-502](#)
- show ip igmp snooping querier command [2-504](#)
- show ip igmp snooping querier detail command [2-504](#)
- show ip sla standards command [2-506](#)
- show ip sla twamp connection [2-435](#)
- show ip sla twamp connection command [2-507](#)
- show ip sla twamp session command [2-509](#)
- show ip source binding command [2-511](#)
- show ipv6 access-list command [2-518](#)
- show ipv6 dhcp conflict command [2-520](#)
- show ipv6 route updated command [2-521](#)
- show ip verify source command [2-512](#)
- show l2protocol-tunnel command [2-523](#)
- show lacp command [2-525](#)
- show link state group command [2-529](#)
- show lldp command [2-531](#)
- show location command [2-532](#)
- show logging onboard command [2-535](#)
- show mac access-group command [2-539](#)
- show mac address-table address command [2-543](#)
- show mac address-table aging time command [2-545](#)
- show mac address-table command [2-541](#)
- show mac address-table count command [2-547](#)
- show mac address-table dynamic command [2-549](#)
- show mac address-table interface command [2-551](#)
- show mac address-table learning command [2-553](#)
- show mac address-table move update command [2-554](#)
- show mac address-table notification command [2-50, 2-556, B-32](#)
- show mac address-table static command [2-558](#)
- show mac address-table vlan command [2-560](#)
- show monitor command [2-562](#)
- show mvr command [2-564](#)
- show mvr interface command [2-566](#)
- show mvr members command [2-568](#)
- show pagp command [2-570](#)
- show parser macro command [2-572](#)
- show platform acl command [C-2](#)
- show platform backup interface command [C-3](#)
- show platform cfm command [C-4](#)
- show platform configuration command [C-5](#)
- show platform dl command [C-6](#)
- show platform etherchannel command [C-7](#)
- show platform forward command [C-8](#)
- show platform frontend-controller command [C-10](#)
- show platform igmp snooping command [C-11](#)
- show platform ipc trace command [C-16](#)
- show platform ip multicast command [C-13](#)
- show platform ip unicast command [C-14](#)
- show platform ipv6 unicast command [C-17](#)
- show platform l2pt dm command [C-19](#)
- show platform layer4op command [C-20, C-43](#)
- show platform mac-address-table command [C-21](#)
- show platform messaging command [C-22](#)
- show platform monitor command [C-23](#)
- show platform mvr table command [C-24](#)
- show platform pm command [C-25](#)
- show platform policer cpu command [C-26](#)
- show platform port-asic command [C-30](#)
- show platform port-security command [C-35](#)
- show platform qos command [C-36](#)
- show platform resource-manager command [C-39](#)
- show platform snmp counters command [C-41](#)
- show platform spanning-tree synchronization command [C-42](#)
- show platform stp-instance command [C-44](#)
- show platform team command [C-45](#)
- show platform vlan command [C-48](#)
- show platform vlan mapping command [C-49](#)
- show policer aggregate command [2-574](#)
- show policer cpu uni-eni command [2-575](#)



- show policy-map command [2-578](#)
- show policy-map interface output fields [2-582](#)
- show port security command [2-583](#)
- show port-type command [2-586](#)
- show rep topology command [2-588](#)
- show sdm prefer command [2-591](#)
- show spanning-tree command [2-593](#)
- show storm-control command [2-599](#)
- show system mtu command [2-601](#)
- show udd command [2-605](#)
- show version command [2-608](#)
- show vlan access-map command [2-615](#)
- show vlan command [2-610](#)
- show vlan command, fields [2-612](#)
- show vlan filter command [2-616](#)
- show vlan mapping command [2-617](#)
- show vmpls command [2-619](#)
- shutdown command [2-621](#)
- shutdown threshold, Layer 2 protocol tunneling [2-245](#)
- shutdown vlan command [2-622](#)
- SNMP host, specifying [2-628](#)
- SNMP informs, enabling the sending of [2-624](#)
- snmp mib rep trap-rate command [2-623](#)
- snmp-server enable traps command [2-624](#)
- snmp-server host command [2-628](#)
- snmp trap mac-notification change command [2-632](#)
- SNMP traps
  - enabling MAC address notification trap [2-632](#)
  - enabling the MAC address notification feature [2-272](#)
  - enabling the sending of [2-624](#)
- software images
  - deleting [2-80](#)
  - downloading [2-9](#)
  - upgrading [2-9](#)
  - uploading [2-15](#)
- software version, displaying [2-608](#)
- source ports, MVR [2-312](#)
- SPAN
  - configuring [2-305](#)
  - debug messages, display [B-33](#)
  - displaying [2-562](#)
  - filter SPAN traffic [2-305](#)
  - sessions
    - add interfaces to [2-305](#)
    - displaying [2-562](#)
    - start new [2-305](#)
  - spanning-tree bpdudfilter command [2-634, 2-636](#)
  - spanning-tree bpduguard command [2-638](#)
  - spanning-tree cost command [2-640](#)
  - spanning-tree etherchannel command [2-642](#)
  - spanning-tree extend system-id command [2-644](#)
  - spanning-tree guard command [2-646](#)
  - spanning-tree link-type command [2-648](#)
  - spanning-tree loopguard default command [2-650](#)
  - spanning-tree mode command [2-652](#)
  - spanning-tree mst configuration command [2-654](#)
  - spanning-tree mst cost command [2-656](#)
  - spanning-tree mst forward-time command [2-658](#)
  - spanning-tree mst hello-time command [2-659](#)
  - spanning-tree mst max-age command [2-661](#)
  - spanning-tree mst max-hops command [2-663](#)
  - spanning-tree mst port-priority command [2-665](#)
  - spanning-tree mst pre-standard command [2-667](#)
  - spanning-tree mst priority command [2-668](#)
  - spanning-tree mst root command [2-670](#)
  - spanning-tree portfast (global configuration) command [2-674](#)
  - spanning-tree portfast (interface configuration) command [2-677](#)
  - spanning-tree port-priority command [2-672](#)
  - Spanning Tree Protocol
    - See STP
  - spanning-tree vlan command [2-679](#)
  - speed command [2-682](#)
  - SSH, configuring version [2-212](#)
  - static-access ports, configuring [2-689](#)
  - statistics, Ethernet group [2-385](#)

- sticky learning, enabling [2-704](#)
  - storm-control command [2-684](#)
  - STP
    - counters, clearing [2-56](#)
    - debug messages, display
      - MSTP [B-88](#)
      - optimized BPDUs handling [B-87](#)
      - spanning-tree activity [B-84](#)
      - switch shim [B-90](#)
      - transmitted and received BPDUs [B-86](#)
    - enabling on ENIs [2-634](#)
    - enabling protocol tunneling for [2-245](#)
    - EtherChannel misconfiguration [2-642](#)
    - extended system ID [2-644](#)
    - path cost [2-640](#)
    - protocol modes [2-652](#)
    - root port
      - loop guard [2-646](#)
      - preventing from becoming designated [2-646](#)
      - restricting which can be root [2-646](#)
      - root guard [2-646](#)
    - root switch
      - affects of extended system ID [2-644, 2-680](#)
      - hello-time [2-679](#)
      - interval between BDPUs messages [2-679](#)
      - interval between hello BDPUs messages [2-679](#)
      - max-age [2-679](#)
      - port priority for selection of [2-672](#)
      - primary or secondary [2-679](#)
      - switch priority [2-679](#)
    - state changes
      - blocking to forwarding state [2-677](#)
      - enabling BDPUs filtering [2-636, 2-674](#)
      - enabling BDPUs guard [2-638, 2-674](#)
      - enabling Port Fast [2-674, 2-677](#)
      - enabling timer to recover from error state [2-120](#)
      - forward-delay time [2-679](#)
      - length of listening and learning states [2-679](#)
      - shutting down Port Fast-enabled ports [2-674](#)
  - STP (continued)
    - state information display [2-593](#)
    - VLAN options [2-668, 2-679](#)
  - SVIs, creating [2-149](#)
  - Switched Port Analyzer
    - See SPAN
  - switching characteristics
    - modifying [2-687](#)
    - returning to interfaces [2-687](#)
  - switchport access command [2-689](#)
  - switchport backup interface command [2-691](#)
  - switchport block command [2-695](#)
  - switchport command [2-687](#)
  - switchport host command [2-697](#)
  - switchport mode command [2-698](#)
  - switchport mode private-vlan command [2-701](#)
  - switchport port-security aging command [2-708](#)
  - switchport port-security command [2-704](#)
  - switchport private-vlan command [2-710](#)
  - switchport protected command [2-712](#)
  - switchports, displaying [2-467](#)
  - switchport trunk command [2-714](#)
  - switchport vlan mapping command [2-716](#)
  - system env temperature threshold yellow command [2-719](#)
  - system message logging, save message to flash [2-261](#)
  - system mtu command [2-720](#)
  - system resource templates [2-386](#)
- 
- T**
  - table-map command [2-723](#)
  - table-map configuration mode [2-723](#)
  - table maps
    - configuring [2-723](#)
    - displaying [2-603](#)
    - QoS [2-723](#)
  - tar files, creating, listing, and extracting [2-12](#)
  - TDR, running [2-725](#)
  - temperature information, displaying [2-445](#)

temperature status, displaying [2-445](#)  
 templates, system resources [2-386](#)  
 test cable-diagnostics tdr command [2-725](#)  
 traceroute mac command [2-727](#)  
 traceroute mac ip command [2-730](#)  
 traffic shaping, QoS [2-410](#)  
 trunking, VLAN mode [2-698](#)  
 trunk mode [2-698](#)  
 trunk ports [2-698](#)  
 tunnel ports, Layer 2 protocol, displaying [2-523](#)  
 type (boot loader) command [A-26](#)

## U

### UDLD

aggressive mode [2-732, 2-734](#)  
 debug messages, display [B-96](#)  
 enable globally [2-732](#)  
 enable per interface [2-734](#)  
 error recovery timer [2-120](#)  
 message timer [2-732](#)  
 normal mode [2-732, 2-734](#)  
 reset a shutdown interface [2-736](#)  
 status [2-605](#)

udld command [2-732](#)

udld port command [2-734](#)

udld reset command [2-736](#)

### UNI

bundling and multiplexing [2-136](#)  
 Ethernet [2-136](#)

unicast storm control [2-684](#)

uni count command [2-737](#)

### UniDirectional Link Detection

See UDLD

UNI ID, Ethernet [2-138](#)

uni-vlan command [2-739](#)

unknown multicast traffic, preventing [2-695](#)

unknown unicast traffic, preventing [2-695](#)

unset (boot loader) command [A-27](#)

upgrading

software images [2-9](#)

monitoring status of [2-415](#)

user EXEC mode [1-2](#)

user network interface [2-352](#)

## V

version (boot loader) command [A-29](#)

violate-action command [2-741](#)

vlan access-map command [2-746](#)

VLAN access map configuration mode [2-746](#)

### VLAN access maps

actions [2-5](#)

displaying [2-615](#)

vlan command [2-743](#)

### VLAN configuration mode

commands [2-743](#)

description [1-4](#)

entering [2-743](#)

summary [1-2](#)

vlan dot1q tag native command [2-748](#)

vlan filter command [2-750](#)

VLAN filters, displaying [2-616](#)

VLAN ID range [2-743](#)

### VLAN ID translation

See VLAN mapping

### VLAN mapping

configuring [2-716](#)

described [2-717](#)

displaying [2-617](#)

### VLAN maps

applying [2-750](#)

creating [2-746](#)

defining [2-285](#)

displaying [2-615](#)

### VLAN Query Protocol

See VQP

## VLANs

- adding [2-743](#)
- configuring [2-743](#)
- debug messages, display
  - activation of [B-94](#)
  - VLAN IOS file system error tests [B-93](#)
  - VLAN manager activity [B-92](#)
- displaying configurations [2-610](#)
- extended-range [2-743](#)
- MAC addresses
  - displaying [2-560](#)
  - number of [2-547](#)
- normal-range [2-743](#)
- private [2-701](#)
  - configuring [2-359](#)
  - displaying [2-610](#)
  - See also private VLANs
- restarting [2-622](#)
- saving the configuration [2-743](#)
- shutting down [2-622](#)
- suspending [2-622](#)

## VMPS

- configuring servers [2-755](#)
- displaying [2-619](#)
- error recovery timer [2-121](#)
- reconfirming dynamic VLAN assignments [2-752](#)
- vmips reconfirm (global configuration) command [2-753](#)
- vmips reconfirm (privileged EXEC) command [2-752](#)
- vmips retry command [2-754](#)
- vmips server command [2-755](#)

## VQP

- and dynamic-access ports [2-690](#)
  - clearing client statistics [2-59](#)
  - displaying information [2-619](#)
  - per-server retry count [2-754](#)
  - reconfirmation interval [2-753](#)
  - reconfirming dynamic VLAN assignments [2-752](#)
- VTP, enabling tunneling for [2-245](#)

---

**W**

## Weighted Tail Drop

See WTD

WTD, queue-limit command [2-364](#)