



CHAPTER 1

Introduction

This chapter introduces you to the Cisco Driver Installer Utility 3.1(2). This chapter discusses the following topics:

- [Overview of the Cisco Driver Installer Utility](#)
- [Supported Operating Systems and Versions](#)
- [Supported Hardware Platforms](#)

Overview of the Cisco Driver Installer Utility

The Cisco Driver Installer utility enables you to install or update drivers for all Cisco supported devices. This utility is released with the Cisco UCS Server Configuration Utility (SCU) 3.1(2) release and is also available on the Cisco Flexible Flash card of the servers.

The Graphical User Interface (GUI) of the utility lists all the Cisco supported device drivers that are installed in the server. It lists the installed driver version and the most recent driver version that is available. The **Action** column lists the action that you can take on each device driver. The value displayed can be either Install, Update, or Force Update. The **Action** column displays the value Install when no driver is installed for a device. The **Action** column displays the value Update when a more recent version of a driver is available. The **Action** column displays the value Forced Update when the version of the driver that is installed and most recently available version is the same, or when the installed driver version is more recent than what is available. Based on the values displayed in the **Action** column, you can install the driver updates. You can install the updates individually on each driver, or you can select all the drivers and initiate an update.

By using this utility, you can install updates for the drivers from vMedia or the Cisco Flexible Flash card, from the network or from <http://www.cisco.com>. For a few device drivers, you might have to restart the server for the most recent changes to take effect. In such instances, you are prompted to decide whether or not you would like to restart the system immediately for the changes to take effect. Until you restart your system, the most recent driver updates will not be used.

Supported Operating Systems and Versions

The Cisco Driver Installer utility supports the following operating systems:

- Microsoft Windows Server 2012
- Microsoft Windows Server 2008 R2 (64-bit)
- Microsoft Windows Server 2008 R2 with SP1

Send document comments to ucs-docfeedback@cisco.com

For an updated list of supported operating systems, see the *Release Notes for Cisco UCS Server Configuration Utility 3.1(2)*, available at the following location:

http://www.cisco.com/en/US/products/ps10493/prod_release_notes_list.html

Supported Hardware Platforms

The Cisco Driver Installer utility is supported on the following hardware platform:

- Cisco UCS C22 M3
- Cisco UCS C24 M3
- Cisco UCS C220 M3 Series
- Cisco UCS C240 M3 Series
- Cisco UCS C260 M2
- Cisco UCS C420 M3
- Cisco UCS C460 M2

For an updated list of supported hardware platforms, see the *Release Notes for Cisco UCS Server Configuration Utility 3.1(2)*, available at the following location:

http://www.cisco.com/en/US/products/ps10493/prod_release_notes_list.html