



Requirements and Support

This chapter contains the following topics:

- [Requirements, page 1](#)
- [Support, page 2](#)

Requirements



Important

Separate ISO containers are released for each server platform. Be sure to download the correct ISO container for the server.



Note

If you are downgrading from 2.0(x) to a version before 1.5.4, you need to downgrade to 1.5.4 first and then downgrade to a version that you want to downgrade to.

Server	Container	Minimum CIMC and BIOS Version Requirements
C22	1.5.4	CIMC version: 1.5(4) BIOS version: 1.5.4f.0
C24	1.5.4	CIMC version: 1.5(4) BIOS version: 1.5.4f.0

Server	Container	Minimum CIMC and BIOS Version Requirements
C220	1.5.4	<p>For CPUs with Intel Xeon(C) 26XX series or Intel Xeon(C) 24XX series processors</p> <p>CIMC version: 1.5(4) BIOS version: 1.5.4f.0</p> <p>For CPUs with Intel Xeon(C) 26XX V2 series processors</p> <p>CIMC version: 1.5(4) BIOS version: 1.5.4f.0</p>
C240	1.5.4	<p>For CPUs with Intel Xeon(C) 26XX series or Intel Xeon(C) 24XX series processors</p> <p>CIMC version: 1.5(4) BIOS version: 1.5.4f.0</p> <p>For CPUs with Intel Xeon(C) 26XX V2 series processors</p> <p>CIMC version: 1.5(4) BIOS version: 1.5.4f.0</p>

Support

The Cisco Host Upgrade Utility checks for and then updates the firmware for LOM and LSI controller devices on Cisco UCS C-series servers. For a complete list of supported LOM and LSI controller devices on the supported servers, see the *Release Notes for Cisco UCS C-Series Software* available at the following location:

http://www.cisco.com/en/US/products/ps10739/prod_release_notes_list.html