



# Configure Failover

Revised: May 4, 2015  
OL-15762-05

Failover Configuration    Failover Status

---

**Failover Settings**

**Digital Media Suite Cluster Settings**

Name\*:

Set as Master:

Master FQDN:

**Digital Media Manager Failover Settings**

<b>Management Interface</b>	<b>Replication Interface</b>
	<input type="radio"/> Crossover <input type="radio"/> Switched
Primary FQDN*: <input type="text"/>	Primary IP*: <input type="text"/>
Secondary FQDN*: <input type="text"/>	Secondary IP*: <input type="text"/>
Virtual FQDN*: <input type="text"/>	Subnet Mask*: <input type="text"/>

.....

  

---

**Control Panel**

Clustering Status    Unconfigured

Activate Cluster   

---

Failover Configuration    Failover Status

---

**Digital Media Manager Failover Status**

Time of last event: N/A

Server Time: 07/13/2021 03:25:18 PM PDT

N/A (Primary Server): Not Clustered

N/A (Secondary Server): Not Clustered

See *Failover Configuration Guide for Cisco Digital Media Suite 5.4.x* on Cisco.com.

