



Numerics

- 10/100BASE-T data port [1-4](#)
- 10/100BASE-T hub [1-4](#)
- 10BASE-T uplink Ethernet port [1-4](#)
- 802.1Q VLAN ID [3-4](#)
- 802.1Q VLAN ID configuration [5-11](#)

A

- alphanumeric values [3-22](#)
- ata.txt file [3-10](#)
- atadefault.cfg configuration file [3-17](#)
- atadefault.cfg file [3-12](#)
- atapname.exe Tool [3-11](#)
- ata unique configuration file [3-3](#), [3-17](#)
- AudioMode parameter [5-20](#), [6-2](#), [6-6](#)
- audio operating mode configuration [5-20](#)

B

- binary configuration file creation [3-10](#)
- bootload
 - process [3-2](#)
- brackets for IP address of endpoint identifier setting [5-25](#)
- BusyTone [5-37](#)

C

- CA0UID [5-13](#)
- CA1UID [5-14](#)
- cabling requirements [2-3](#)
- Call Agent

- configuration of alternate [5-13](#)
- configuration of primary [5-12](#)
- overview [1-2](#), [1-3](#)
- services [1-8](#)
- specifying ID of alternate [5-14](#)
- specifying ID of primary [5-13](#)
- Caller ID format configuration [5-21](#)
- caller ID method [5-21](#)
- CallerIdMethod parameter [5-21](#)
- call-progress toes [5-29](#)
- Call-Progress tone parameters [5-30](#), [5-36](#)
- call-progress tones
 - configuration [5-29](#)
 - parameters [5-29](#)
- call waiting period configuration [5-26](#)
- call-waiting tone [5-38](#)
- CallWaitTone [5-38](#)
- CDP discovery setting [5-27](#)
- CED tone detection
 - disabling [5-20](#)
 - enabling [5-20](#)
- cfgfmt.exe tool [3-10](#), [3-15](#)
- CFGID [5-43](#)
- CfgInterval parameter [5-5](#)
- Cisco ATA-specific configuration file [3-3](#)
- Cisco Discovery Protocol (CDP) [3-2](#)
- CodecName [5-19](#)
- codec names
 - configuration [5-19](#)
- codec negotiation in sending fax [5-25](#)
- codecs [4-2](#)
 - LBRCCodec [5-15](#)
 - supported [1-5](#)

- common parameters
 - configuration 3-9
- conference connection mode setting 5-25
- conferences 1-2
- configuration 5-27
 - 802.1Q VLAN ID 5-11
 - alternate Call Agent 5-13
 - atadefault.cfg file 3-12
 - audio operating mode 5-20
 - brackets for IP address of endpoint identifier setting 5-25
 - Caller ID format 5-21
 - call-progress tones 5-29
 - syntax 5-29
 - call waiting period 5-26
 - CDP discovery setting 5-27
 - CED tone detection
 - disabling 5-20
 - cfgfmt.exe tool 3-10, 3-15
 - codec names 5-19
 - conference connection mode setting 5-25
 - connection mode 5-24
 - default values 5-2
 - domain-name portion of endpoint ID 5-18
 - DtmfMethod 5-20
 - endpoint identifiers 5-14
 - fax pass-through redundancy setting 5-24
 - G.711 μ -law setting for fax pass-through 5-25
 - G.711A-law setting for fax pass-through 5-25
 - G.711 silence suppression 5-20
 - G.729 codec setting by port 5-25
 - hook flash time 5-26
 - listening port 5-16
 - low-bit-rate codecs 5-20
 - maximum retransmission of commands 5-17
 - methods
 - using TFTP and DHCP servers 3-8, 3-9
 - Web-based 3-23
 - Wed-based 3-25
 - NCS-compliant Session Description Protocol (SDP) setting 5-25
 - NSE payload type 5-24
 - parameters
 - AudioMode 5-20, 6-2, 6-6
 - CA0UID 5-13
 - CA1UID 5-14
 - CallerIdMethod 5-21
 - CfgInterval 5-5
 - CodecName 5-19
 - ConnectMode 6-3
 - DHCP 5-8
 - DNS2IP 5-11
 - EncryptKey 5-6, 8-14
 - MediaPort 5-17
 - MGCPPort 5-16
 - MGCPVer 5-18
 - NumTxFrames 5-21
 - OpFlags 5-27
 - RetxIntv 5-17
 - RetxLim 5-17
 - SigTimer 5-26
 - StaticIp 5-9
 - StaticNetMask 5-10
 - StaticRoute 5-9
 - TftpURL 5-5
 - TraceFlags 5-41
 - UIPassword 5-3, 8-14
 - persistent hook-flash events setting 5-25
 - persistent on-hook and off-hook events setting 5-25
 - PING period 5-26
 - preferred codec 5-15
 - primary Call Agent 5-12
 - quarantine handling mode setting 5-25
 - refresh interval 4-2
 - required parameters 4-2
 - retransmission interval 5-17
 - ring cadence pattern 5-40
 - RSIP*@ipaddress syntax setting 5-25

- RTP media port [5-17](#)
- RTP packet size [5-21](#)
- static network router probing [5-27](#)
- text file template [5-2](#)
- TFTP filename setting [5-27](#)
- tones [5-29](#)
- VLAN CoS bit value (802.1P priority) for TCP packets [5-11](#)
- VLAN ID specifications setting [5-27](#)
- VLAN IP encapsulation setting [5-27](#)
- configuration changes taking effect [3-6](#)
- configuration files generated [3-13](#)
- configuration in a non-TFTP server environment [3-7](#)
- configuration in a TFTP server environment [3-5](#)
- congestion tone [5-37](#)
- connection mode configuration [5-24](#)
- ConnectMode parameter [6-3](#)
- converting MAC address to hexadecimal format [3-11](#)
- convert unique configuration file to binary format [3-6](#)
- creating a text configuration file [3-9](#)

D

- debugging [8-4](#)
- debugging with prserv program [8-4](#)
- default configuration file [3-17](#)
- default values [3-9](#)
- DHCP
 - disabling use of [5-8](#)
 - enabling use of [5-8](#)
- DHCP option 150 [3-18](#)
- DHCP option 66 [3-18](#)
- DHCP options [3-19](#)
- DHCP parameter [5-8](#)
- DHCP server
 - configuration without using DHCP [3-20](#)
 - if not under control of Cisco ATA administrator [3-19](#)
- DHCP server usage [3-18](#)
- diagnostics

- SyslogCtrl [5-42](#)
- SyslogIP [5-41](#)
- types of messages to trace [5-42](#)
- DialTone [5-36](#)
- disabling CDP discovery [3-4](#)
- disabling use of DHCP server [3-21](#)
- disabling VLAN encapsulation [3-4](#)
- disabling VLAN IP encapsulation [3-3](#)
- DNS2IP parameter [5-11](#)
- domain-name portion of endpoint ID configuration [5-18](#)
- downloading Cisco ATA software from CCO [3-7, 3-8](#)
- DtmfMethod configuration [5-20](#)
- duplexity [1-4](#)
- dynamic payload type [5-24](#)

E

- electrical specifications [B-2](#)
- enabling user-specified voice VLAN ID [3-4](#)
- EncryptKeyEx parameter [5-7](#)
- encryption [3-12](#)
- encryption examples [3-15](#)
- encryption key [5-6](#)
- EncryptKey parameter [5-6, 8-14](#)
- endpoint identifiers [4-2](#)
- endpoint identifiers configuration [5-14](#)
- endpoints and connections [4-3](#)
 - configuration example [4-3](#)
 - configuration parameters [4-3](#)
- entering alphanumeric values [3-22](#)
- environmental specifications [B-2](#)
- establishing IP connectivity [3-20](#)
- Ethernet ports [1-4](#)

F

- factory default reset [3-23](#)
- fax

debugging [6-7](#)
 services [1-7, 6-1](#)
 fax mode [6-1, 6-6](#)
 configuration [6-6, 6-7](#)
 definition [1-7](#)
 description [6-1](#)
 fax pass-through [5-25](#)
 redundancy setting [5-24](#)
 fax pass-through mode [6-1](#)
 configuration [6-2](#)
 definition [1-7](#)
 description [6-1](#)
 enabling [6-4, 6-5](#)
 fax relay disabling [6-5](#)
 fax services
 debugging [6-9](#)
 Foreign Exchange Station ports [1-4](#)
 frequently asked questions [8-14](#)
 function button [1-4, 1-5, 3-3, 7-1, 8-2](#)
 FXSInputLevel [5-23](#)
 FXSOutputLevel [5-23](#)
 FXS ports [1-4](#)

G

G.711 μ -law setting for fax pass-through [5-25](#)
 G.711A-law setting for fax pass-through [5-25](#)
 G.711 silence suppression configuration [5-20](#)
 G.729 codec setting by port [5-25](#)
 generated configuration files [3-13](#)
 generating binary configuration file [3-10](#)

H

hook flash time configuration [5-26](#)
 HTTP refresh [5-27](#)
 HTTP reset [5-27](#)

impedance [1-4](#)
 Include command [3-10](#)
 input level of FXS ports [5-23](#)
 input ports [2-5](#)
 installation
 instructions [2-1](#)
 procedure [2-3](#)

L

listening port configuration [5-16](#)
 local connection options [4-7](#)
 local tone playout reporting [8-9](#)
 low-bit-rate codec [5-20](#)
 low-bit-rate codecs
 configuration [5-20](#)

M

MAC address [3-11](#)
 making configuration changes after boot up [3-11](#)
 maximum retransmission of commands [5-17](#)
 MediaPort parameter [5-17](#)
 message waiting indicator [5-22](#)
 MGCP
 capabilities [1-2](#)
 Cisco ATA-supported commands [4-10](#)
 Cisco ATA-supported software packages [4-8](#)
 connection modes [4-7](#)
 description [1-2](#)
 endpoint device type
 description [4-4](#)
 example [4-4](#)
 overview [1-1](#)
 registration process [4-4](#)
 services
 complete listing [4-5](#)

- related parameters 4-5
- signals and events 4-7
- version 1-5
- versions 1-5

mgcp_example.txt file 3-10

mgcp_example.txt sample configuration file 3-9

mgcp_example.txt text file 5-2

MGCPPort 5-16

MGCPVer 5-18

MGCP version string configuration 5-18

N

NCS-compliant Session Description Protocol (SDP) setting 5-25

network configuration parameters 5-8

network requirements 2-2

network status 8-10, 8-11

non-dotted hexadecimal MAC address location 3-10

NSE payload type configuration 5-24

NumTxFrames parameter 5-21

O

obtaining network status 8-10, 8-11

obtaining non-dotted hexadecimal MAC address of Cisco ATA 3-10

OpFlags parameter 5-27

output level of FXS ports 5-23

P

parameters

- required 4-2

parameters and defaults 5-1

parameter types 5-1

password

- forgotten 5-3
- setting 5-3

persistent events 4-8

persistent hook-flash events setting 5-25

persistent on-hook and off-hook events setting 5-25

physical interfaces B-2

physical specifications B-1

PING period configuration 5-26

port for debug messages

- configuration 5-40

power

- adaptor cable 2-5
- connector 2-5

power-down procedure 2-6

preferred-codec configuration 5-15

primary domain name server 5-10

priority value 8-6

prserv 6-8, 6-9

Q

quarantine handling mode setting 5-25

R

refreshing the Cisco ATA 3-26

refresh interval 4-2

refresh interval configuration 5-5

refresh-interval configuration 3-6

refresh procedure 3-11

registration process with MGCP 4-4

Reorder Tone 5-37

reorder tone 5-32, 5-37

ReorderTone parameter 5-32

reorder tone parameter example 5-34, 5-35

reporting

- local tone playout 8-9
- RTP statistics 8-13

resetting the Cisco ATA 3-26

resetting the Cisco ATA to factory defaults 3-23

retransmission interval configuration [5-17](#)
 RetxIntv [5-17](#)
 RetxLim [5-17](#)
 reviewing default router for Cisco ATA to use [3-22](#)
 reviewing subnet mask of Cisco ATA [3-22](#)
 review IP address of Cisco ATA [3-21](#)
 Ringback Tone [5-38](#)
 ringer cadence pattern configuration [5-40](#)
 ringing characteristics [B-3](#)
 ring loads [8-14](#)
 RJ-11 telephone ports [1-4](#)
 RJ-45 LED
 Cisco ATA 186 [1-4](#)
 Cisco ATA 188 [1-4](#)
 RSIP*@ipaddress syntax setting [5-25](#)
 RTP
 frames [6-12](#)
 media port configuration [5-17](#)
 packets [6-12](#)
 packet size configuration [5-21](#)
 statistics [6-12](#)
 rtpcatch [6-12, 6-13, 6-15, 6-16, 6-17, 6-20](#)
 RTP payload type [5-24](#)
 RTP statistics reporting [8-13](#)

S

safety recommendations [2-2](#)
 sample configuration text file [3-9](#)
 secondary domain name server [5-11](#)
 Session Description Protocol (SDP) [1-2](#)
 session management [1-2](#)
 setting the codec [4-2](#)
 signaling
 definition [1-2](#)
 signaling image upgrade [3-26](#)
 SigTimer parameter [5-26](#)
 software download from CCO [3-7, 3-8](#)
 software features [1-5](#)

software specifications (all protocols) [B-3](#)
 specifying a preconfigured VLAN ID [3-3](#)
 specifying VLAN CoS bit value (802.1P priority) for UDP packets [3-4](#)
 specifying VLAN CoS bit value for TCP packets [3-4](#)
 standard payload type [5-24](#)
 statically configuring
 Cisco ATA assigned route [5-9](#)
 IP address of Cisco ATA [5-9](#)
 subnet mask [5-10](#)
 statically configuring various IP addresses [3-2](#)
 StaticIP [3-20](#)
 StaticIP parameter [5-9](#)
 StaticNetMask [3-20](#)
 StaticNetMask parameter [5-10](#)
 static network router probing setting [5-27](#)
 StaticRoute [3-20](#)
 StaticRoute parameter [5-9](#)
 strongest encryption key [5-7](#)
 syslog [8-6](#)
 IP address [8-6](#)
 priority value [8-6](#)
 tag [8-6](#)
 time_offset [8-6](#)
 SyslogCtrl [5-42](#)
 SyslogIP [5-41](#)
 system diagnostics [8-6](#)

T

target endpoint [1-2](#)
 TFTP configuration filename configuration setting [5-27](#)
 TFTP server
 configuring to not use [5-4](#)
 configuring to use [5-4](#)
 statically configuring [5-5](#)
 TFTP server IP address [3-18](#)
 TFTP server name [3-18](#)
 TftpURL parameter [5-5](#)

tone
 reorder [5-32](#)
 tone parameters [5-30, 5-31](#)
 tone parameter syntax
 basic format [5-30](#)
 extended formats [5-31](#)
 tones [5-29](#)
 syntax [5-30](#)
 TOS bits [5-29](#)
 TraceFlags parameter [5-41](#)
 troubleshooting
 general tips [8-1](#)
 installation [8-3](#)
 upgrade issues [8-3](#)
 type of service bits [5-29](#)

U

UIPassword parameter [5-3, 8-14](#)
 unique configuration file [3-10, 3-17](#)
 upgrading software
 from TFTP server [7-1](#)
 using executable file [7-2](#)
 upgrading software from TFTP server [7-1](#)
 upgrading the signaling image [3-26](#)
 User Interface (UI) Parameters [5-3](#)
 UseTFTP parameter [5-4](#)

V

version parameter [5-43](#)
 version parameter for configuration file [5-43](#)
 visual message waiting indicator [5-22](#)
 VLAN
 CoS bit value (802.1P priority) for TCP packets [5-11](#)
 ID specification setting [5-27](#)
 IP encapsulation setting [5-27](#)
 VLAN ID example [3-4](#)

VLAN-related parameters [3-3](#)
 VLAN tagging [3-2](#)
 voice configuration menu [3-21](#)
 voice menu codes
 configuration parameters [A-2](#)
 information options [A-1](#)
 software upgrade [A-3](#)
 voice ports [1-1](#)

W

warnings
 circuit breaker (15A) [2-5](#)
 installation [2-2](#)
 lightning activity [2-2](#)
 main disconnecting device [2-2](#)
 No. 26 AWG [2-5](#)
 product disposal [2-2](#)
 web-based configuration setting [5-27](#)

