



## show process

This chapter describes the output of the **show process** command.

- [show process status, on page 1](#)

## show process status

Displays process listings in the system. The process listing information can be viewed for a card or CPU (or both).

**Table 1: show process status Command Output Descriptions for Card or CPU**

Field	Description
USER	Indicates the internal Linux system user, that is, either "root" or "cli". <b>Note</b> The "user" referred here is not the same as context users, local users, or TACACS+ users that are configured in the system.
PID	Indicates the process ID.
PPID	Indicates the parent process ID.
STARTED	Indicates the process starting time.
%CPU	Indicates the CPU percentage that the process has used.
%MEM	Indicates the memory percentage that the process has used.
COMMAND	Displays the command that was used to start the process, along with the arguments used.

