



# Hardware Crypto Assist for ePDG

This chapter describes the following topics:

- [Feature Summary and Revision History, on page 1](#)
- [Feature Changes, on page 1](#)

## Feature Summary and Revision History

### Summary Data

|  |   |
|--|---|
| Applicable Product(s) or Functional Area | ePDG  |
| Applicable Platform(s)                   | <ul style="list-style-type: none"><li>• VPC-DI</li><li>• VPC-SI</li></ul> |
| Feature Default                          | Enabled - Always-on (if Coletto Creek Card is present)                    |
| Related Changes in This Release          | Not applicable  |
| Related Documentation                    | <i>ePDG Administration Guide</i>  |

### Revision History

| Revision Details  | Release |
|-------------------|---------|
| First introduced. | 21.5    |

## Feature Changes



### Important

The *ePDG Hardware Crypto Assist* feature is not fully qualified in this release. It is available only for testing purposes. For more information, contact your Cisco Accounts representative.

ePDG supports Hardware Crypto assist on VPC-DI and VPC-SI. This support is applicable only if an optional accelerator card (Coletto Creek Card) is present.