



Feature Defaults Quick Reference

- [Feature Defaults](#), on page 1

Feature Defaults

The following table indicates what features are enabled or disabled by default.

Feature	Default
5GS Interworking using N26 Interface Support	Disabled - Configuration Required
Adding ECPD Identification and Account Numbers to Pilot Packets	Disabled - Configuration Required
Cinder Volume Multi-Attach	Enabled - Always-on
DNS Client KPI Enhancement	Disabled - Configuration Required
EPS to 5GS Mobility Enhancement	Disabled - Configuration Required
Handling Uneven Resource Distribution Notifications on Session Managers	Disabled - Configuration Required
LTE to Wi-Fi Success Rate	Disabled - Configuration Required
IMSI not Included in LRR	Disabled - Configuration Required
Reject Paging Request for Active Emergency VoLTE Call	Enabled - Always-on
Sending EMM Information during Periodic TAU	Disabled - Configuration Required
Suppressing Handover Request for VoWiFi IR Subscribers	Disabled - Configuration Required
Support for Tariff-Time-Change in Fast Path	Enabled - Always-on
TCP Reset with Invalid Sequence Number should not Trigger Connection Close	Disabled - Configuration Required
Video Shaping Tethered Data	Disabled - Configuration Required
VPP Metric Enhancement	Disabled - Configuration Required

