



# MSISDN Group Configuration Mode Commands

The MSISDN Group Configuration Mode provides commands to configure discrete list and range of Mobile Station International Subscriber Directory Number (MSISDN) numbers.

---

## Command Modes

Exec > Global Configuration > MSISDN Group Configuration

**configure** > **msisdn-group** *group\_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(msisdn-group) #
```



---

## Important

Available commands or keywords/variables vary based on platform type, product version, and installed license(s).



---

## Important

For information on common commands available in this configuration mode, refer to the [Common Commands](#) chapter.

- [msisdn cc, on page 1](#)
- [range, on page 2](#)

## msisdn cc

This command configures the discrete list of MSISDN numbers.

---

## Product

MME  
SGSN

---

## Privilege

Administrator

---

## Command Modes

Exec > Global Configuration > MSISDN Group Configuration

**configure**

Entering the above command sequence results in the following prompt:

```
[local]host_name(msisdn-group)#
```

**Syntax Description**

```
msisdn cc cc_value number value  
no msisdn cc cc_value number value
```

**no**

Deletes the specified MSISDN numbers.

**cc** *cc\_value*

**cc** is the country code of the subscriber. *cc\_value* is a three digit number between 1 and 999.

**number** *value*

This keyword allows up to 500 MSISDNs to be configured per group. *value* is 1 to 14 digit MSISDN number.

**Usage Guidelines**

Use this command to specify the discrete list of MSISDN numbers (Combination of discrete and range line is 20 per group).

**Example**

The following command configures the CC as *334* and MSISDN as *12345678901234*:

```
msisdn cc 334 number 12345678901234
```

## range

This command configures the range of MSISDN numbers.

**Product**

MME  
SGSN

**Privilege**

Administrator

**Command Modes**

Exec > Global Configuration > MSISDN Group Configuration

**configure**

Entering the above command sequence results in the following prompt:

```
[local]host_name(msisdn-group)#
```

**Syntax Description**

```
range cc cc_value number first start_range last end_range  
no range cc cc_value number first start_range last end_range
```

**no**

Deletes the specified MSISDN numbers.

**cc *cc\_value***

*cc* is the country code of the subscriber. *cc\_value* is a three digit number between 1 and 999.

**number first *start\_range* last *end\_range***

Specifies the MSISDN range. *start\_range* and *end\_range* are 1 to 14 digit MSISDN numbers.

**Usage Guidelines**

Use this command to configure the MSISDN range.

**Example**

The following command configures the CC as *334* and MSISDN range as *12345678901234* and *23456789012341*:

```
range cc 334 number first 12345678901234 last 23456789012341
```

range