Feature Defaults Quick Reference

Feature Defaults

The following table indicates what features are enabled or disabled by default.

Feature	Default
Addition of Server Unreachable Field in CDR	Disabled - Configuration Required
Capability to Record and Produce Call Transactions	Disabled - Configuration Required
Cloud Initialization Support for Elastic Services Controller	Enabled - Always-on
Configuring Access-Link Fastpath to Enforce APN MTU for IPv4 Traffic	Enabled - Always-on
Configuring SRP Checkpoint	Disabled - Configuration Required
Deprecated CLI for MME Initiated PDN Disconnection	Disabled - Configuration Required
ePDG Support on VPC-D	Disabled - Configuration Required
ePDG Interworking with SMF+P-GW-IWK Support	Disabled - License Required
Enable mme clear-route-multipath-zero in CLI	Disabled - Configuration Required
Enforcing Detach on Last PDN Deactivation	Disabled - Configuration Required
IKEv2 Authentication Failure Counters	Disabled - Configuration Required
LTE-M RAT Indication Support	Disabled - Configuration Required
No IMSI or MSISDN Included in LRR for VoLTE EM Call from User of Foreign Network	Disabled - Configuration Required
SaMOG Support on VPC-DI	Disabled - Configuration Required
Support for 187 and 188 Information Element Types on S2b Interface	Disabled - Configuration Required

Feature	Default
Support for 187 and 188 Information Element Types on S5 and S8 Interfaces	Disabled - Configuration Required
TCP RESET Support	Disabled - Configuration Required
Timestamp Accuracy Improvement	Disabled - Configuration Required
VLR Round-Robin Load Balancing	Disabled - Configuration Required