



# Preface

---

- [Preface, page i](#)

## Preface

### Audience

This document is for network administrators who configure Cisco Connected Mobile Experiences (Cisco CMX) services.

### Conventions

This document uses the following conventions:

**Table 1: Conventions**

| Convention                | Indication   |
|---------------------------|--|
| <b>bold font</b>          | Commands and keywords and user-entered text appear in <b>bold font</b> .   |
| <i>italic font</i>        | Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .                      |
| [ ]                       | Elements in square brackets are optional.  |
| {x   y   z }              | Required alternative keywords are grouped in braces and separated by vertical bars.  |
| [ x   y   z ]             | Optional alternative keywords are grouped in brackets and separated by vertical bars.  |
| string                    | A nonquoted set of characters. Do not use quotation marks around the string. Otherwise, the string will include the quotation marks. |
| <code>courier font</code> | Terminal sessions and information the system displays appear in <code>courier font</code> .  |

| Convention | Indication  |
|------------|---|
| <>         | Nonprinting characters such as passwords are in angle brackets.   |
| []         | Default responses to system prompts are in square brackets.   |
| !, #       | An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line. |




---

**Note** Means reader take note. Notes contain helpful suggestions or references to material not covered in the manual.

---




---

**Tip** Means the following information will help you solve a problem.

---




---

**Caution** Means reader be careful. In this situation, you might perform an action that could result in equipment damage or loss of data.

---

## Related Documentation

For more information about Cisco Mobility Services Engine and related products, see:

<http://www.cisco.com/c/en/us/support/wireless/mobility-services-engine/tsd-products-support-series-home.html>

For more information about Cisco Connected Mobile Experiences (Cisco CMX), see:

<http://www.cisco.com/c/en/us/solutions/enterprise-networks/connected-mobile-experiences/index.html>

For more information about Cisco CMX Cloud, see:

<https://support.cmx.cisco.com/hc/en-us>

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see [What's New in Cisco Product Documentation](#).

To receive new and revised Cisco technical content directly to your desktop, you can subscribe to the [What's New in Cisco Product Documentation RSS feed](#). RSS feeds are a free service.