



## Preface

---

This preface contains the following sections:

- [Objectives, page xv](#)
- [Audience, page xv](#)
- [Conventions, page xv](#)
- [Related Documentation, page xvi](#)
- [Obtaining Documentation and Submitting a Service Request, page xvi](#)

## Objectives

This guide describes how to use the Cisco Prime Infrastructure to configure and manage the Cisco 3300 series mobility services engine and the Context-Aware Service, that resides on the mobility services engine.

## Audience

The purpose of this guide is to help you configure and manage the Context-Aware Service. Before you begin, you should be familiar with network structures, terms, and concepts.

## Conventions

This guide uses the following conventions to convey instructions and information:

- Commands and keywords appear in **boldface**.
- *Italics* indicate arguments for which you supply values.
- Series of menu options appear as **option > option**.

Examples use the following conventions:

- Examples depict page displays and the command line in *screen* font.
- Information you need to enter in examples is shown in **bold screen** font.
- Variables for which you must supply a value are shown in *italic screen* font.

**Note**

Means *reader take note*. Notes contain helpful suggestions or references to materials not contained in the manual.

**Tip**

Means the following information will help you solve a problem.

**Caution**

Means *reader be careful*. In this situation, you might do something that can result in equipment damage or loss of data.

## Related Documentation

See the *Cisco 3310 Mobility Services Engine Getting Started Guide* or *Cisco 3350 Mobility Services Engine Getting Started Guide* for mobility services engine installation and setup information.

These documents are available on Cisco.com at the following URL:

[http://www.cisco.com/en/US/products/ps9742/tsd\\_products\\_support\\_install\\_and\\_upgrade.html](http://www.cisco.com/en/US/products/ps9742/tsd_products_support_install_and_upgrade.html)

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, that also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as an RSS feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service. Cisco currently supports RSS Version 2.0.