



Numerics

- 802.1X
 - authentication types
 - in ACU [4-16](#)
 - defined [4-16](#)

A

- ACAU [2-1 to 2-10](#)
 - configuration file [1-8](#)
 - configuration tabs [1-7](#)
 - file menu [1-7](#)
 - global settings [3-1](#)
 - Global Settings tab [3-2](#)
 - help [1-8](#)
 - obtaining software [1-3](#)
 - operating systems supported [1-2](#)
 - overview [1-2](#)
 - security options [1-8](#)
- access point
 - reporting those that fail LEAP authentication [4-19, 4-21](#)
 - security settings [4-20 to 4-22](#)
- ad hoc network
 - selecting in ACAU [4-8](#)
- advanced ad hoc parameters
 - described [4-3](#)
- advanced infrastructure parameters
 - described [4-3](#)
- Aironet Desktop Utility (ADU)
 - Properties screens, overview [4-3](#)
- Allow Association to Mixed Cells parameter [4-13 to 4-14, 4-15](#)

- antenna
 - gains
 - IEEE 802.11a [B-4](#)
 - IEEE 802.11b [B-4, B-5](#)
- ASTU [3-8 to 3-10](#)
- audience [viii](#)
- authentication
 - process [4-17](#)
- auto profile selection
 - including a profile in [4-33 to 4-34](#)
 - prioritizing profiles [4-34](#)
 - restrictions [4-33](#)

B

- broadcast key rotation
 - described [4-20](#)
 - setting on client and access point [4-22](#)
- broadcast SSIDs [4-4](#)

C

- Canadian compliance statement [A-3](#)
- Caution, defined [ix](#)
- Channel parameter [4-10, 4-12](#)
- channels, supported by regulatory domains
 - IEEE 802.11a [B-2](#)
 - IEEE 802.11b [B-3](#)
- CiscoAdminConfig.dat file [2-4, 3-10](#)
- Client Name parameter [4-4](#)
- configuration file [1-8, 3-10](#)
 - creating [2-2](#)
 - modifying [2-4](#)

retrieving from registry [2-8](#)
 configuration tabs [1-7](#)
 configuring [3-4, 3-6, 3-7](#)
 configuring settings [3-8 to 3-10](#)
 Constantly Awake Mode (CAM) [4-7](#)
 conventions [ix](#)

D

declarations of conformity
 European community, Switzerland, Norway, Iceland,
 and Liechtenstein [A-3](#)
 FCC [A-2](#)
 RF exposure [A-7](#)
 documentation
 additional publications and information [xii](#)
 how to obtain [ix](#)
 ordering [x](#)
 document organization [viii](#)
 domain name
 specifying for saved user name and password [4-26](#)
 dynamic WEP keys, overview [4-16 to 4-17](#)

E

EAP authentication
 overview [4-16 to 4-17](#)
 EAP-Cisco Wireless
 See LEAP authentication
 EAP-TLS authentication
 described [4-16 to 4-17](#)
 enabling
 through ACU [4-26, 4-28, 4-32](#)
 EIRP, maximum [B-4, B-5](#)
 Error messages [C-2 to C-4](#)

F

Fast PSP [4-7](#)

fast reassociation
 described [4-18](#)
 setting on client and access point [4-21](#)
 FCC
 declaration of conformity statement [A-2](#)
 File menu
 contents of [1-7](#)
 frequencies [B-2, B-3](#)
 frequency
 setting [4-10, 4-12](#)

G

Global Settings Tab [3-2](#)

H

host-based EAP authentication
 described [4-16 to 4-17](#)
 enabling [4-26 to 4-30](#)
 requirements [4-26](#)

I

including in auto profile selection [2-7](#)
 infrastructure network
 selecting in ACAU [4-8](#)

J

Japan, guidelines for operating client adapters [A-7 to A-8](#)

L

LEAP authentication
 described [4-16, 4-17](#)
 enabling [4-24 to 4-26](#)
 requirements [4-24](#)

setting on client and access point [4-20](#)
 LEAP Authentication Timeout Value parameter [4-26](#)
 long radio headers, using [4-8](#)

M

Max Power Savings
 See Max PSP
 Max PSP [4-7](#)
 message integrity check (MIC)
 described [4-19](#)
 setting on client and access point [4-22](#)

N

network
 security parameters
 described [4-3, 4-13, 4-14](#)
 setting [4-13, 4-14](#)
 Network Security Type parameter [4-22, 4-23](#)
 Network Type parameter [4-8](#)
 No Network Connection Unless User Is Logged In
 parameter [4-26](#)
 Note, defined [ix](#)

P

PEAP authentication
 described [4-17](#)
 enabling
 through ACU [4-26 to 4-30](#)
 RADIUS servers supported [4-17](#)
 setting on client and access point [4-21](#)
 peer-to-peer network [4-8](#)
 power level
 maximum [B-4 to ??, B-5 to ??](#)
 profile [2-5, 2-7](#)
 including in auto profile selection [2-7](#)
 profile management settings [3-7](#)

Profile Manager
 ACAU menu option [4-2](#)
 auto profile selection feature [4-33](#)
 exporting a profile [2-6](#)
 icon [2-5, 2-6, 2-7, 4-2](#)
 importing a profile [2-5](#)
 overview [4-2](#)
 screen
 displayed [2-5, 4-2](#)
 profiles
 importing and exporting [2-5](#)
 Protected EAP
 See PEAP authentication

R

RADIUS servers
 additional information [4-17](#)
 defined [4-16](#)
 supported [4-16 to 4-17](#)
 range [4-6](#)
 registry [2-8](#)
 reading a file from [2-8](#)
 regulatory [4-10, 4-12](#)
 domains
 IEEE 802.11a [B-2](#)
 IEEE 802.11b [B-3](#)
 information [A-8, A-9](#)
 related publications [ix](#)
 removing [2-5](#)
 ACAU software [1-8](#)
 retrieving configuration file from [2-8](#)
 RF network parameters
 described [4-5](#)

S

saving and retrieving [3-10](#)

security features

- overview [4-15 to ??](#)
- synchronizing [4-20 to 4-22](#)

Security paramters

- setting [4-13](#)

Setup Settings [3-4](#)

short radio headers

- using [4-8](#)

Smart Card or other Certificate Properties screen [4-31](#)

SSID1 parameter [4-4](#)

SSID2 parameter [4-4](#)

static WEP

- procedures [4-22, 4-23](#)
- with open authentication, setting on client and access point [4-20](#)
- with shared key authentication, setting on client and access point [4-20](#)

static WEP keys

- guidelines for entering
 - in ACU [4-23](#)
- overview [4-16](#)
- overwriting [4-23](#)
- selecting transmit key [4-23](#)
- size of [4-23](#)

system parameters

- described [4-3](#)
- setting [4-3 to 4-5](#)

T

Taiwan, administrative rules for client adapters [A-9](#)

technical assistance [x](#)

Technical Assistance Center [xi](#)

Temporal Key Integrity Protocol (TKIP)

- described [4-20](#)

throughput [4-7, 4-8](#)

transmit key [4-23](#)

U

Upgrading ACAU software [1-5](#)

user settings [3-6](#)

using [2-1 to 2-10](#)

W

WEP

- keys
 - additional security features [4-19 to ??](#)
 - defined [4-15](#)
 - size of [4-15](#)
 - types of [4-15](#)
 - parameter [4-22, 4-23, 4-25](#)
- WEP Key Entry Method parameter [4-22](#)
- WEP key hashing [4-20](#)