

# Line Configuration Mode Commands

Line configuration mode commands allow you to configure the virtual terminal line settings. To configure the virtual terminal line settings and access line configuration mode, use the **line vty** command in configuration mode. The CLI prompt changes to (config-line). For information about the commands in line configuration mode, see the following commands.

Use the **no** form of the **line vty** command to reset the line configuration mode parameter to its default setting.

**line vty**

**no line vty**

## Syntax Description

There are no keywords or arguments for this command.

## Command Modes

Configuration mode

Admin context only

## Command History

Release	Modification
A1(7)	This command was introduced.

## Usage Guidelines

The commands in this mode have no user role feature restrictions. For details about role-based access control (RBAC) and user roles, see the *Cisco 4700 Series Application Control Engine Appliance Virtualization Configuration Guide*.

## Examples

To enter the line configuration mode, enter:

```
host1/Admin(config)# line vty
host1/Admin(config-line)#
```

## Related Commands

[clear line](#)  
[show line](#)

## (config-line) session-limit

To configure the maximum number of terminal sessions per line, use the **session-limit** command. Use the **no** form of the command to disable a setting for the configured virtual terminal line.

**session-limit** *number*

**no session-limit** *number*

Syntax Description	<i>number</i>	Maximum number of terminal sessions per line. Enter an integer from 1 to 251.
--------------------	---------------	---

Command Modes	Line configuration mode Admin context only
---------------	---

Command History	Release	Modification
	A1(7)	This command was introduced.

Usage Guidelines	This command has no usage guidelines.
------------------	---------------------------------------

Examples	<p>For example, to configure a virtual terminal line, enter:</p> <pre>host1/Admin# <b>config</b> Enter configuration commands, one per line. End with CNTL/Z host1/Admin(config)# host1/Admin(config)# <b>line vty</b> host1/Admin(config-line)# <b>session-limit 23</b></pre> <p>To disable a setting for the configured virtual terminal line, enter:</p> <pre>host1/Admin(config-line)# <b>no session-limit 23</b></pre>
----------	---

Related Commands	<p><a href="#">clear line</a>  <a href="#">show line</a>  <a href="#">(config) line vty</a></p>
------------------	---

