



CLI COMMAND SUMMARY BY MODE

DDoS Module Configuration Mode Commands 267

- (config-ddos) disable-as 269
- (config-ddos) dproxy 271
- (config-ddos) enable 273
- (config-ddos) global-domain 275
- (config-ddos) max-database-entries 277
- (config-ddos) mitigation-rule 279
- (config-ddos) peacetime database 281
- (config-ddos) rate-limit 282
- (config-ddos) scaling-factor 284
- (config-ddos) script play-config 286
- (config-ddos) show 287
- (config-ddos) show attacks 288
- (config-ddos) show ddos-config 293
- (config-ddos) show dproxy 289
- (config-ddos) show failed-dns 290
- (config-ddos) show rate-limit 292
- (config-ddos) show statistics 294
- (config-ddos) show status 295

DRP Agent Configuration Mode Commands 297

- (config-drp) authentication key 298
- (config-drp) enable 299
- (config-drp) probe icmp-rtt 300
- (config-drp) probe path-rtt 302

- (config-drp) probe tcp-rtt 312
- (config-drp-icmp-rtt) timeout 301
- (config-drp-path-rtt) burst-size 305
- (config-drp-path-rtt) destination-port 307
- (config-drp-path-rtt) init-ttl 309
- (config-drp-path-rtt) max-failure-ttl 310
- (config-drp-path-rtt) max ttl 311
- (config-drp-path-rtt) probe-type 304
- (config-drp-path-rtt) sourceport 308
- (config-drp-path-rtt) timeout 306
- (config-drp-tcp-rttprobe)
destination-port 313
- (config-drp-tcp-rttprobe) sourceport 314
- (config-drp-tcp-rttprobe) timeout 315

General Commands 2

- ? 4
- cd 6
- clear ddos config 9
- clear statistics 7
- clock 10
- cnr 16
- cnr access-mode enable 18
- cnr backup-time edit 20
- cnr install/uninstall 22
- cnr security-kit 24

- cnr shell **26**
- configure **27**
- copy **28**
- ddos peacetime **30, 31**
 - database erase **32**
 - save **33**
 - show **34**
 - start **35**
 - stop **36**
- ddos restore defaults **37**
- del **38**
- dir **39**
- disable **41**
- dnslookup **42**
- enable **43**
- enable-passwd **44**
- end **46**
- exit **47**
- ftp **48**
- gss **49**
- gssm **54**
- gss tech-report **53**
- help **57**
- install **58**
- license **59**
- lls **60**
- ls **62**
- lsof **63**
- no **65**
- ping **66**
- proximity database delete **67**
- proximity database dump **69**
- proximity database load **72**
- proximity database periodic-backup **75**
- proximity group-summary dump **76**
- proximity play-config **77**
- proximity start **79**
- proximity statistics group-summary dump **80**
- proximity stop **81**
- pwd **82**
- refresh-gssmesh-statistics **83**
- reload **85**
- rename **86**
- reset-gui-admin-password **87**
- restore-factory-defaults **88**
- rotate-logs **90**
- scp **91**
- setup **93**
- show access-group **96**
- show access-list **97**
- show arp **98**
- show boot-config **99, 105, 106**
- show clock **100**
- show cnr access-mode **101**
- show cnr aslb **102**
- show cnr backup-time **103**
- show cnr security-kit **104**
- show ddos

- drpoxy 107
- failed-dns 108
- rate-limit 110
- status 112
- show ddos-config 111
- show disk 113
- show ftp 114
- show glsb-config 115
- show glsb-errors 118
- show interface 119
- show inventory 120
- show ip routes 121
- show license 122
- show logging 123
- show logs 124
- show memory 125
- show ntp 126
- show processes 127
- show properties 128
- show proximity 129
- show proximity database 130
- show proximity group-name 132, 133
- show running-config 134
- show services 135
- show snmp 136
- show ssh 137
- show startup-config 138
- show statistics 139
 - boomerang 140
 - ddos 144
 - dns 141
 - drpagent 145
 - gss-mesh all dns 146
 - keepalive 148
 - proximity 150
 - sticky 152, 154, 158
 - tacacs 153
- show sticky database 155
- show sticky global 157
- show sticky-group summary 159
- show sticky mesh 160
- show supportpass-status 161
- show system-status 162
- show tacacs 163
- show tech-support 164
- show telnet 165
- show terminal-length 166
- show uptime 167
- show user 168
- show users 169
- show version 170
- shutdown 171
- sticky database delete 172
- sticky database dump 175
- sticky database load 178
- sticky database periodic-backup 180
- sticky start 181
- sticky stop 182

- supportpass **184**
- tail **185**
- tcpdump **187**
- telnet **190**
- traceroute **192**
- type **193**
- write **195**
- Global Configuration Mode Commands **196**
 - (config) aaa **197**
 - (config) access-group **200**
 - (config) access-list **201**
 - (config) certificate set-attributes **204**
 - (config) clock **206**
 - (config) cnr aslb enable **212**
 - (config) cnr enable **214**
 - (config) exec-timeout **215**
 - (config) ftp-client enable **217**
 - (config) ftp enable **216**
 - (config) gslb **218**
 - (config) hostname **219**
 - (config) interface ethernet **221**
 - (config) ip **224**
 - (config) logging **227**
 - (config) no **231**
 - (config) ntp enable **233**
 - (config) ntp server **234**
 - (config) snmp **236**
 - (config) snmp-server **239**
 - cpu-falling-threshold **241**
 - cpu-rising-threshold **243**
 - enable traps **245**
 - host **247**
 - trap limit **249**
 - trap-source ethernet **250**
 - (config) ssh enable **251**
 - (config) ssh keys **253**
 - (config) ssh protocol version 1 **255**
 - (config) tacacs-server host **257**
 - (config) tacacs-server keepalive-enable **259**
 - (config) tacacs-server timeout **261**
 - (config) terminal-length **263**
 - (config) username **264**
- Global Server Load-Balancing Configuration Mode Commands **329**
 - (config-gslb) answer cra **332**
 - (config-gslb) answer-group **352**
 - (config-gslb) answer ns **335**
 - (config-gslb) answer vip **338**
 - (config-gslb) dns rule **362**
 - (config-gslb) domain-list **365**
 - (config-gslb) keepalive-properties cra **369**
 - (config-gslb) keepalive-properties http-head **371**
 - (config-gslb) keepalive-properties icmp **375**
 - (config-gslb) keepalive-properties kalap **377**
 - (config-gslb) keepalive-properties ns **383**
 - (config-gslb) keepalive-properties scripted-kal **380**
 - (config-gslb) keepalive-properties tcp **385**

- (config-gslb) location **388**
 - (config-gslb) manual-reactivation **390**
 - (config-gslb) no **392**
 - (config-gslb) owner **394**
 - (config-gslb) proximity assign **396**
 - (config-gslb) proximity group **399**
 - (config-gslb) proximity-properties **402**
 - (config-gslb) region **403**
 - (config-gslb) script play-config **405**
 - (config-gslb) shared-keepalive http-head **407**
 - (config-gslb) shared-keepalive icmp **409**
 - (config-gslb) shared-keepalive kalap **411**
 - (config-gslb) shared-keepalive scripted-kal **414**
 - (config-gslb) shared-keepalive tcp **419**
 - (config-gslb) source-address-list **421**
 - (config-gslb) sticky group **425**
 - (config-gslb) sticky-properties **427**
 - (config-gslb) zone **428**
 - (config-gslb-agcra) answer-add **354**
 - (config-gslb-agns) answer-add **356**
 - (config-gslb-agns) auth-domain **360**
 - (config-gslb-agvip) answer-add **358**
 - (config-gslb-ansvip) keepalive type http-head **341**
 - (config-gslb-ansvip) keepalive type icmp **344**
 - (config-gslb-ansvip) keepalive type kalap **346**
 - (config-gslb-ansvip) keepalive type scripted-kal **348**
 - (config-gslb-ansvip) keepalive type tcp **349**
 - (config-gslb-dl) domain **367**
 - (config-gslb-sal) ip address **423**
 - Interface Configuration Mode Commands **316**
 - (config-eth) autosense **319**
 - (config-eth) duplex **321**
 - (config-eth) gss-communications **323**
 - (config-eth) gss-tcp-keepalives **324**
 - (config-eth) ip address **325**
 - (config-eth) no **327**
 - (config-eth) speed **328**
-
- ## Level1IX
- Proximity Properties Configuration Mode Commands **430**
 - (config-gslb-proxprop) acceptable-rtt **431**
 - (config-gslb-proxprop) acceptable-zone **433**
 - (config-gslb-proxprop) authentication drp enable **435**
 - (config-gslb-proxprop) discovery-sequence **437**
 - (config-gslb-proxprop) enable **439**
 - (config-gslb-proxprop) equivalence **440**
 - (config-gslb-proxprop) fallback-probe-method **441**
 - (config-gslb-proxprop) key drp **443**
 - (config-gslb-proxprop) mask **445**
 - (config-gslb-proxprop) no **447**
 - (config-gslb-proxprop) refresh-interval **449**

- (config-gslb-proxprop) timeout **450**
- (config-gslb-proxprop) wait enable **451**
- refreshing GSS mesh statistics **83**
- Rule Configuration Mode Commands **452**
 - (config-gslb-rule) clause number
cra-group **455**
 - (config-gslb-rule) clause number
ns-group **459**
 - (config-gslb-rule) clause number
vip-group **463**
 - (config-gslb-rule) no **468**
 - (config-gslb-rule) sticky method **469**
 - (config-gslb-rule) sticky timeout **471**
- SNMP
 - server notifications **241, 243**
- SNMP server notifications
 - enabling **241, 243**
 - snmp-server cpu-rising-threshold
command **241, 243**
- Sticky Properties Configuration Mode
Commands **473**
 - (config-gslb-stkyprop) enable **474**
 - (config-gslb-stkyprop) encryption **476**
 - (config-gslb-stkyprop) favored-peer **478**
 - (config-gslb-stkyprop) no **482**
 - (config-gslb-stkyprop) timeout **483**