



A

activity logs, database capacity and [3-1](#)
activity logs, purging [3-4](#)
Administration Console, commands not functioning [5-23](#)
Authentication.log [2-2](#)
authorization error after server installation [5-5](#)
Auto Update, adjusting [3-3](#)

B

backup log, incorrect display [5-31](#)
bar_act.log [2-12](#)
browser
404 error [5-29](#)
cannot connect to server after installing Cisco IPICS [5-4](#)
refreshing [5-1](#)
refreshing window [5-27](#)

C

cablelength router command [5-12](#)
CallManager, documentation [xiv](#)
catalina.out [2-12](#)

caution, described [xvi](#)
changing password with passwd command [A-1](#)
channel
Cisco IP Phone cannot access [5-28](#)
feedback noise [5-11](#)
PMC deactivates by itself [5-10](#)
channel, choosing codec for [5-10](#)
ChannelStatistics.log [2-2](#)
characters, language, incorrect display of [5-31](#)
Cisco IOS, documentation [xv](#)
Cisco IP Phone
cannot access channel [5-28](#)
no power [5-16](#)
Cisco IP Phones, documentation [xiv](#)
Cisco Land Mobile Radio (LMR),
documentation [xv](#)
Cisco Linux
checking database status [1-8](#)
checking Tomcat service status [1-2](#)
Informix database procedures [1-7](#)
starting database [1-10](#)
starting Tomcat service [1-5, 1-7](#)
stopping CSA [1-14](#)
stopping database [1-9](#)
stopping Tomcat service [1-3](#)

- Tomcat service procedures [1-2](#)
 - Cisco Security Agent, documentation [xv, 2-14](#)
 - clear counters router command [5-12](#)
 - clear line router command [5-18](#)
 - clock source router command [5-12](#)
 - codec, voice quality and [5-10](#)
 - Command failed error [5-30](#)
 - communication issue
 - some PMCs cannot talk on channel [5-9](#)
 - VTG participants cannot hear each other [5-9](#)
 - communication issues, VTGs and SIP PMCs [5-12](#)
 - configuration, T1, sample [5-14](#)
 - controller, limiting number of DS0s [5-17](#)
 - conventions, document [xv](#)
 - CSA
 - about CSA logs [2-12](#)
 - Security Events Log
 - opening in Cisco Linux [2-14](#)
 - opening in CSA utility [2-13](#)
 - shutting down with ssh [1-14, 1-15](#)
 - stopping in Cisco Linux [1-14](#)
 - stopping with CSA utility [1-13](#)
-
- D**
- Database % Full indicator [5-26](#)
 - database, Informix
 - checking [5-5](#)
 - checking status in Cisco Linux [1-8](#)
 - checking status with ssh [1-8](#)
 - database full message displays [5-26](#)
 - manually starting [5-7](#)
 - performing procedures [1-7](#)
 - shutting down [1-9](#)
 - starting [1-10](#)
 - starting manually with ssh [1-10](#)
 - stopping [1-9](#)
 - database, stopped [5-23](#)
 - database capacity [3-1](#)
 - database log [2-12](#)
 - date and time, changing system [5-2](#)
 - deactivating RMS, to edit router details [5-19](#)
 - DEBUG error type [3-2](#)
 - debugging Cisco IPICS [5-28](#)
 - debugging PMC [2-5](#)
 - DebugLog.txt [2-2](#)
 - digit password, setting minimum length in Options window [4-3](#)
 - documentation
 - CallManager [xiv](#)
 - Cisco IOS [xv](#)
 - Cisco IP Phones [xiv](#)
 - Cisco Land Mobile Radio (LMR) [xv](#)
 - Cisco Security Agent [xv, 2-14](#)
 - conventions [xv](#)
 - MCS servers [xiv](#)
 - DS0, limiting number on router [5-17](#)
 - DSCP [5-11](#)
 - DSPs, insufficient [5-9](#)

E

- echoes, in conferences [5-22](#)
- error
 - 404, in browser [5-29](#)
 - authorization after server installation [5-5](#)
 - command failed [5-30](#)
 - notifications, activating in Options window [4-2](#)
 - PMC gets unknown response [5-32](#)
 - undefined javascript [5-30](#)
 - viewing in System Status window [3-2](#)
- ERROR error type [3-2](#)
- error messages [6-19](#)
- error notification message [3-3](#)
- Ethernet ports, in Network Device Control window [5-3](#)

F

- FATAL error type [3-3](#)
- feedback, in conferences [5-22](#)
- feedback, on VTG or channel [5-11](#)
- finding troubleshooting information [ix](#)

G

- G711 codec, voice quality and [5-10](#)
- G729 codec, voice quality and [5-10](#)

I

- INFO error type [3-2](#)
 - information
 - accessing additional [xiii](#)
 - where to find Cisco IPICS troubleshooting [ix](#)
 - Informix database [1-10](#)
 - checking [5-5](#)
 - checking status in Cisco Linux [1-8](#)
 - checking status with ssh [1-8](#)
 - database full message displays [5-26](#)
 - manually starting [5-7](#)
 - shutting down [1-9](#)
 - starting manually with ssh [1-10](#)
 - stopping [1-9](#)
 - informix password, manually changing [5-23](#)
 - installation, cannot connect to server after [5-4](#)
 - IP address, verifying Cisco IPICS [5-5](#)
 - ipics.log
 - about [2-12](#)
 - downloading [3-6](#)
 - error types [3-2](#)
 - ipics.rms.log file [2-12](#)
 - ipics_audit.log file [2-12](#)
-
- J**
- javascript error, undefined [5-30](#)

L

language characters, incorrect display of [5-31](#)

Linux, Cisco

- checking database status [1-8](#)
- checking Tomcat service status [1-2](#)
- Informix database procedures [1-7](#)
- starting database [1-10](#)
- starting Tomcat service [1-5, 1-7](#)
- stopping CSA [1-14](#)
- stopping database [1-9](#)
- stopping Tomcat service [1-3](#)
- Tomcat service procedures [1-2](#)

location

- incorrectly configured [5-28](#)
- in VTG, one cannot hear others [5-8](#)

log4j.properties file [5-28](#)

Log Entries pane, Recent System [3-2](#)

logical logs, Cisco IPICS [5-26](#)

logs

- backup, incorrectly displaying [5-31](#)
- catalina.out [2-12](#)
- Cisco IPICS, location of [2-11](#)
- Cisco IPICS activity [3-1](#)
- CSA, about [2-12](#)
- PMC, modifying [2-1](#)
- purging activity [3-4](#)
- setting debugging for ipics.log [5-28](#)
- system, downloading [3-6](#)

loopback, indicator lights for [5-21](#)

M

Maximum Activity Logs, setting in Options window [4-4](#)

MCS servers, documentation [xiv](#)

Media category, PMC DebugLog.txt [2-4, 2-8](#)

Microsoft QoS Packet Scheduler [5-11](#)

Minimum Digit Password Length setting, Options window [4-3](#)

Minimum Password Length setting, Options window [4-3](#)

multicast information, accessing [xiii](#)

N

Network Device Control window [5-3](#)

no prompt router command [5-18](#)

note, described [xv](#)

Notepad, log displaying incorrectly in [5-31](#)

O

ops views, activating in Options window [4-2](#)

Options window [4-1](#)

P

packets, IP marked incorrectly [5-11](#)

- Packet Scheduler, Microsoft QoS [5-11](#)
- passwd command, Cisco Linux [A-1](#)
- password
 - changing for root after installation [A-1](#)
- password length, setting minimum in Options window [4-3](#)
- PIM, sparse and sparse-dense modes [5-9](#)
- ping command, using to verify Cisco IPICS IP address [5-5](#)
- pins, mapping for a T1 on router [5-21](#)
- PMC
 - deactivates channel by itself [5-10](#)
 - poor voice quality [5-10](#)
 - setting log level in User Details [2-10](#)
 - SIP-connected voice communication interrupted [5-12](#)
 - some cannot communicate on channel [5-9](#)
 - troubleshooting
 - application [6-1](#)
 - audio settings [6-5](#)
 - caveats [6-19](#)
 - channel activation issues [6-17](#)
 - Cisco Security Agent [6-7](#)
 - codec misconfiguration [6-18](#)
 - coexistence [6-8](#)
 - configuration file changes [6-4](#)
 - connectivity issues [6-12](#)
 - DNS issues [6-17](#)
 - error messages [6-19](#)
 - execution [6-2](#)
 - headset [6-6](#)
 - headset issues [6-9](#)
 - microphone [6-6](#)
 - multicast connections [6-15](#)
 - one-way audio [6-8](#)
 - optional settings menu [6-5](#)
 - resolving IP address changes [6-10](#)
 - unknown response error [5-32](#)
 - voice quality [6-11](#)
 - VPN issues [6-12](#)
 - VTG not appearing on [5-27](#)
 - winssock corruption [6-16](#)
 - using debugging log level [2-5](#)
 - voice quality degrades for SIP user [5-11](#)
- PMC Activity Log Update, setting frequency [4-3](#)
- PMC log files [2-2](#)
- PMC log levels, modifying [2-1](#)
- PMC Log Upload Frequency setting [4-6](#)
- PMC Send Logs on Rollover setting [4-4](#)
- PMC Update Poll setting [4-5](#)
- PMC Versions to Keep setting [4-6](#)
- POE module [5-16](#)
- policy, VTG not activating in [5-27](#)
- Policy Checker process, setting interval [4-3](#)
- pop-up blocker software, using in Administration Console [5-2](#)
- ports, Ethernet in Network Device Control window [5-3](#)
- preferences, system, setting in Options window [4-1](#)

purging activity logs [3-4](#)

Q

QoS, Microsoft Packet Scheduler [5-11](#)

R

Recent System Log Entries pane [3-2](#)

refreshing browser window [5-27](#)

refreshing the browser [5-1](#)

Refresh Now button [3-2](#)

remote installation, error when starting [5-7](#)

restore, PMC gets error after [5-32](#)

RMS

- configuration, long wait after restarting Cisco IPICS [5-17](#)

- deactivating [5-19](#)

- failing [5-18](#)

- limiting DS0s on router [5-17](#)

- log entries [2-12](#)

- no loopbacks displayed on new [5-19](#)

- updating login information causes Unreachable state [5-19](#)

RMS Polling Frequency, setting interval [4-4](#)

root

- changing password after installation [A-1](#)

- logging in as, GNOME login window [5-3](#)

router

- clear line command [5-18](#)

- configuration shows wrong information [5-22](#)

- insufficient DSPs on [5-9](#)

- IOS software version [5-16](#)

- log wait for restart after configuring [5-17](#)

- mapping pins for T1 [5-21](#)

- no green indicator lights [5-21](#)

- no loopbacks displayed on new RMS [5-19](#)

- no prompt command [5-18](#)

- PIM modes [5-9](#)

- POE module [5-16](#)

- show users command [5-18](#)

- slow VTG activation [5-18](#)

- T1 configuration [5-12](#)

- Unreachable state [5-18](#), [5-19](#)

- updating configuration in Cisco IPICS [5-22](#)

- VTY lines [5-18](#)

S

Security Events Log, CSA

- opening in Cisco Linux [2-14](#)

- opening in CSA utility [2-13](#)

Show Configuration feature [5-22](#)

show controllers router command, sample output [5-15](#)

Show Error Notifications, activating in Options window [4-2](#)

show users router command [5-18](#)

Signaling category, PMC DebugLog.txt [2-4](#), [2-7](#)

ssh

- checking Informix database with [1-8](#)
 - shutting down CSA [1-14, 1-15](#)
 - shutting down Informix database [1-9](#)
 - starting Informix database [1-10](#)
 - starting [1-10](#)
 - status
 - checking database in Cisco Linux [1-8](#)
 - checking Tomcat service [1-2](#)
 - Status, System window [3-1, 5-26](#)
 - system logs, downloading [3-6](#)
 - system preferences, setting in Options window [4-1](#)
 - System Status window [3-1, 5-26](#)
 - Auto Update setting [3-3](#)
 - downloading system logs [3-6](#)
 - purging activity logs [3-4](#)
-
- T**
- T1
 - configuration [5-12](#)
 - loopbacks not displayed on new RMS [5-19](#)
 - mapping pins on router [5-21](#)
 - sample configuration [5-14](#)
 - TAC Case Collection Tool [6-12](#)
 - time and date, changing system [5-2](#)
 - Tomcat service
 - checking status [1-2, 5-4](#)
 - performing procedures [1-2](#)
 - starting [1-5, 1-7](#)
 - stopping [1-3](#)
 - TRACE error type [3-2](#)
 - troubleshooting
 - Administration Console not functioning [5-23](#)
 - authorization error after installation [5-5](#)
 - authorization error on login [5-5](#)
 - backup log displays incorrectly [5-31](#)
 - cannot connect to server [5-4](#)
 - cannot reach server from browser [5-4](#)
 - Cisco IP Phone cannot access channel [5-28](#)
 - Command failed error [5-30](#)
 - communication disrupted [5-12](#)
 - database full message [5-26](#)
 - database not running [5-5](#)
 - database stopped [5-23](#)
 - displaying loopbacks in Add Router window [5-19](#)
 - error when starting remote installation [5-7](#)
 - feedback noise on VTG, channel [5-11](#)
 - incorrect username or password [5-5](#)
 - language characters display incorrectly [5-31](#)
 - new RMS has no loopbacks [5-19](#)
 - no Cisco IPICS access in browser [5-29](#)
 - no Ethernet ports listed [5-3](#)
 - no green lights on router [5-21](#)
 - non-activating policy [5-27](#)
 - no power to Cisco IP Phones [5-16](#)
 - no table data [5-30](#)
 - one location cannot hear others in VTG [5-8](#)
 - PMC deactivates channel by itself [5-10](#)

PMCs cannot communicate on channel [5-9](#)
poor PMC voice quality [5-10](#)
poor voice quality for SIP-based PMC [5-11](#)
power for Cisco IP Phones [5-16](#)
RMS fails [5-18](#)
router configuration shows wrong
information [5-22](#)
slow VTG activation [5-18](#)
Tomcat service not running [5-4](#)
undefine javascript error [5-30](#)
Unreachable RMS state after updating
login [5-19](#)
Unreachable router state [5-18](#)
unresponsive Cisco IP Phone channel [5-28](#)
unresponsive PMC channel [5-9](#)
user cannot save data [5-26](#)
voice loops in conferences [5-22](#)
VTG activating itself [5-26](#)
VTG audio [5-8](#)
VTG feedback [5-11](#)
VTG not appearing on PMC [5-27](#)
VTG participants cannot communicate [5-9](#)
troubleshooting the PMC application [6-1](#)

U

Unreachable state on router [5-18, 5-19](#)
Update Configuration feature [5-22](#)
user ID, two for same user [5-27](#)
UserInterface.log [2-2](#)

User Interface category, PMC
DebugLog.txt [2-3, 2-6](#)

V

voice, poor quality on PMC [5-10](#)
voice loops [5-22](#)
voice quality issues [6-11](#)
voice troubleshooting information,
accessing [xiii](#)

VTG

activates by itself [5-26](#)
feedback noise [5-11](#)
not activating in policy [5-27](#)
not appearing on PMC [5-27](#)
participants cannot hear each other [5-9](#)
slow activation [5-18](#)
users in one location cannot hear [5-8](#)
voice interruptions [5-12](#)

VTY lines [5-18](#)

W

WARN error type [3-2](#)