



Introduction

Quality of service (QoS) commands are used to configure quality of service, a measure of performance for a transmission system that reflects its transmission quality and service availability.

For QoS configuration information and examples, refer to the *Cisco IOS Quality of Service Solutions Configuration Guide*.

