



Introduction

This book describes the commands used to configure and monitor IP multicast capabilities and features. The commands in this book are organized alphabetically.

For IP multicast configuration tasks and examples, refer to the “IP Multicast” part in the *Cisco IOS IP Configuration Guide*, Release 12.3.

