



# Introduction

---

This document describes the commands used to configure IP Switching features such as CEF, dCEF and Fast Switching, in Cisco IOS software.



**Note**

---

Prior to Cisco IOS release 12.3(14)T the commands for configuring IP Switching features were presented in the *Cisco IOS Switching Services Command Reference Book*.

---

Refer to the configuration chapters indicated here for configuration guidelines:

For guidelines about configuring this feature...	Refer to the following <i>Cisco IOS Configuration Guide</i> ...
IP Switching features	<ul style="list-style-type: none"><li>• “<a href="#">Cisco IOS Switching Services Configuration Guide, Release 12.3</a>”</li></ul>



**Note**

---

A separate IP Switching configuration guide for all Cisco IOS IP Switching features will be published at a later date.

---

