



Introduction

This command reference document describes the commands used to configure LAN switching and Multilayer switching features in Cisco IOS software.

The commands for configuring LAN Emulation (LANE) features are presented in the *Cisco IOS ATM Command Reference, 12.3(14)T*.



Note

Prior to Cisco IOS release 12.3(14)T the commands for configuring LANE, LAN switching and multilayer switching features were presented in the *Cisco IOS Switching Services Command Reference Book*.

For guidelines about configuring this Cisco IOS feature...	Refer to the following <i>Cisco IOS Configuration Guide</i> ...
LAN Switching	<ul style="list-style-type: none">• “Cisco IOS Switching Services Configuration Guide, Release 12.3”
Multilayer Switching	
LAN Emulation	



Note

Separate configuration guides for Cisco IOS LAN switching, multilayer switching, and LANE features will be published at a later date.
