



Introduction

This document describes the commands used to configure broadband features with Cisco IOS software.

Prior to Cisco IOS Release 12.3(14)T, the commands for configuring broadband features were presented in the *Cisco IOS Wide-Area Networking Command Reference*.

For information about configuration, refer to the *Cisco IOS Broadband Access Aggregation and DSL Configuration Guide*.