



Introduction

This document describes the commands used to configure Cisco IOS Performance Routing (PfR). For information about PfR configuration, refer to the *Cisco IOS Performance Routing Configuration Guide*.

