



## INDEX

---

<b>AR</b>	Cisco IOS XR Advanced System Command Reference
<b>HR</b>	Cisco IOS XR Interface and Hardware Component Command Reference
<b>IR</b>	Cisco IOS XR IP Addresses and Services Command Reference
<b>MCR</b>	Cisco IOS XR Multicast Command Reference
<b>MNR</b>	Cisco IOS XR System Monitoring Command Reference
<b>MPR</b>	Cisco IOS XR MPLS Command Reference
<b>QR</b>	Cisco IOS XR Modular Quality of Service Command Reference
<b>RR</b>	Cisco IOS XR Routing Command Reference
<b>SBR</b>	Cisco IOS XR Session Border Controller Command Reference
<b>SMR</b>	Cisco IOS XR System Management Command Reference
<b>SR</b>	Cisco IOS XR System Security Command Reference
<b>VFR</b>	Cisco IOS XR Virtual Firewall Command Reference

---

### A

aaa accounting default command	<a href="#">VFR-204</a>
aaa authentication login command	<a href="#">VFR-206</a>
aaa group server command	<a href="#">VFR-208</a>
access-group (global) command	<a href="#">VFR-74</a>
access-group command	<a href="#">VFR-72</a>
access-list extended command	<a href="#">VFR-76</a>
access-list remark command	<a href="#">VFR-82</a>
access-list resequence command	<a href="#">VFR-84</a>
add-object command	<a href="#">VFR-172</a>
alias command	<a href="#">VFR-156</a>
appl-parameter http advanced-options command	<a href="#">VFR-90</a>
associate-context command	<a href="#">VFR-256</a>
attribute user-profile command	<a href="#">VFR-210</a>

---

### B

banner motd command	<a href="#">VFR-372</a>
baseDN command	<a href="#">VFR-211</a>

---

### C

capture command	<a href="#">VFR-374</a>
case-sensitive command	<a href="#">VFR-310</a>
changeto command	<a href="#">VFR-174</a>
checkpoint command	<a href="#">VFR-376</a>
class command	<a href="#">VFR-92</a>
class-map command	<a href="#">VFR-26</a>
class-map type ftp inspect command	<a href="#">VFR-28</a>
class-map type http inspect command	<a href="#">VFR-30</a>
class-map type management command	<a href="#">VFR-32</a>
clear access-list command	<a href="#">VFR-85</a>
clear accounting log command	<a href="#">VFR-212</a>
clear buffer stats command	<a href="#">VFR-377</a>
clear conn command	<a href="#">VFR-286</a>
clear cores command	<a href="#">VFR-379</a>
clear debug-logfile command	<a href="#">VFR-380</a>
clear fifo stats command	<a href="#">VFR-381</a>
clear ft command	<a href="#">VFR-258</a>
clear icmp statistics command	<a href="#">VFR-288</a>
clear interface command	<a href="#">VFR-157</a>
clear logging command	<a href="#">VFR-490</a>
clear netio stats command	<a href="#">VFR-382</a>
clear processes log command	<a href="#">VFR-383</a>
clear screen command	<a href="#">VFR-384</a>
clear ssh command	<a href="#">VFR-351</a>
clear stats command	<a href="#">VFR-289</a>
clear startup-config command	<a href="#">VFR-385</a>
clear tcp statistics command	<a href="#">VFR-290</a>
clear telnet command	<a href="#">VFR-352</a>
clear udp statistics	<a href="#">VFR-291</a>
clear user command	<a href="#">VFR-175</a>
clear vnet stats command	<a href="#">VFR-387</a>
clear xlate command	<a href="#">VFR-388</a>
configure command	<a href="#">VFR-390</a>

connection advanced-options command [VFR-95](#)  
 context command [VFR-176](#)  
 copy capture command [VFR-391](#)  
 copy core command [VFR-393](#)  
 copy disk0 command [VFR-395](#)  
 copy ftp command [VFR-397](#)  
 copy image command [VFR-399](#)  
 copy running-config command [VFR-401](#)  
 copy sftp command [VFR-403](#)  
 copy statup-config command [VFR-405](#)  
 copy tftp command [VFR-407](#)

---

## D

deadtime command [VFR-213](#)  
 debug command [VFR-409](#)  
 default-interface-name command [VFR-2](#)  
 delete command [VFR-411](#)  
 deny (ftp) command [VFR-97](#)  
 deny command [VFR-96](#)  
 description (context) command [VFR-178](#)  
 description (interface) [VFR-158](#)  
 description (policy-map) command [VFR-98](#)  
 description command [VFR-34](#)  
 dir command [VFR-412](#)  
 domain command [VFR-179](#)

---

## E

end command [VFR-414](#)  
 exceed-mss command [VFR-312](#)  
 exit (config) command [VFR-416](#)  
 exit command [VFR-415](#)

---

## F

failure-action command [VFR-4](#)  
 filter search-user command [VFR-215](#)

firewall (interface) command [VFR-8](#)  
 firewall command [VFR-6](#)  
 follow-active command [VFR-159](#)  
 format disk0 command [VFR-418](#)  
 fragment chain command [VFR-292](#)  
 fragment min-mtu command [VFR-293](#)  
 fragment timeout command [VFR-294](#)  
 ft auto-sync command [VFR-259](#)  
 ft group command [VFR-261](#)  
 ft interface command [VFR-261](#), [VFR-263](#)  
 ft-interface command [VFR-265](#)  
 ft peer command [VFR-266](#)  
 ft switchover command [VFR-267](#)

---

## G

gunzip command [VFR-420](#)

---

## H

heartbeat command [VFR-269](#)  
 hostname command [VFR-421](#)  
 hw-module service firewall location command [VFR-10](#)

---

## I

icmp-guard command [VFR-295](#)  
 inservice command [VFR-271](#)  
 inspect command [VFR-100](#)  
 interface command [VFR-160](#)  
 interface FirewallManagement command [VFR-11](#)  
 interface vasi command [VFR-524](#)  
 ip address command [VFR-161](#)  
 ip df command [VFR-297](#)  
 ip options command [VFR-297](#), [VFR-298](#)  
 ip ttl command [VFR-299](#)

**L**

ldap-server host command [VFR-217](#)  
 ldap-server port command [VFR-219](#)  
 ldap-server timeout command [VFR-221](#)  
 length-exceed command [VFR-314](#)  
 limit-resource command [VFR-182](#)  
 line vty command [VFR-352, VFR-353](#)  
 logging buffered command [VFR-491](#)  
 logging console command [VFR-493](#)  
 logging device-id command [VFR-495](#)  
 logging enable command [VFR-497](#)  
 logging facility command [VFR-498](#)  
 logging fastpath command [VFR-499](#)  
 logging history command [VFR-500](#)  
 logging host command [VFR-502](#)  
 logging message command [VFR-504](#)  
 logging monitor command [VFR-506](#)  
 logging persistent command [VFR-508](#)  
 logging queue command [VFR-510](#)  
 logging rate-limit command [VFR-511](#)  
 logging reject-newconn command [VFR-513](#)  
 logging rp command [VFR-515](#)  
 logging standby command [VFR-517](#)  
 logging timestamp command [VFR-518](#)  
 logging trap command [VFR-519](#)

**M**

mask-reply command [VFR-103](#)  
 match [VFR-116](#)  
 match access-list command [VFR-36](#)  
 match any command [VFR-38](#)  
 match content (policy map) command [VFR-104](#)  
 match content command [VFR-39](#)  
 match content length (policy map) command [VFR-107](#)  
 match content length command [VFR-41](#)  
 match content-type-verification command [VFR-109](#)  
 match destination-address command [VFR-43](#)

match header (policy map) command [VFR-111](#)  
 match header command [VFR-45](#)  
 match header length (policy map) command [VFR-114](#)  
 match header length command [VFR-48](#)  
 match header mime-type (policy map) command [VFR-116](#)  
 match header mime-type command [VFR-50](#)  
 match port command [VFR-52](#)  
 match port-misuse (policy map) command [VFR-118](#)  
 match port-misuse command [VFR-54](#)  
 match protocol command [VFR-56](#)  
 match request-method (ftp) command [VFR-60](#)  
 match request-method (ftp policy map) command [VFR-122](#)  
 match request-method (policy map) command [VFR-120](#)  
 match request-method command [VFR-58](#)  
 match source-address command [VFR-62](#)  
 match strict-http command [VFR-124](#)  
 match transfer-encoding (policy map) command [VFR-126](#)  
 match transfer-encoding command [VFR-64](#)  
 match url (policy map) command [VFR-128](#)  
 match url command [VFR-66](#)  
 match url length (policy map) command [VFR-130](#)  
 match url length command [VFR-68](#)  
 member command [VFR-181](#)  
 mkdir disk0 command [VFR-422](#)  
 move disk0 command [VFR-423](#)

**N**

nagle command [VFR-315](#)  
 nat dynamic command [VFR-132](#)  
 nat-pool command [VFR-162](#)  
 nat static command [VFR-134](#)  
 normalization command [VFR-300](#)

**P**

parameter-map type command [VFR-317](#)  
 peer command [VFR-272](#)

peer ip command [VFR-273](#)  
 permit (http) command [VFR-137](#)  
 permit command [VFR-136](#)  
 ping command [VFR-424](#)  
 policy-map multi-match command [VFR-139](#)  
 policy-map type inspect ftp command [VFR-141](#)  
 policy-map type inspect http command [VFR-143](#)  
 policy-map type inspect management command [VFR-145](#)  
 preempt command [VFR-274](#)  
 priority command [VFR-276](#)

---

## R

radius-server attribute nas-ipaddr command [VFR-223](#)  
 radius-server host command [VFR-227](#)  
 radius-server key command [VFR-230](#)  
 radius-server retransmit command [VFR-232](#)  
 radius-server timeout command [VFR-234](#)  
 random-sequence-number command [VFR-319](#)  
 reserved-bits command [VFR-320](#)  
 reset command [VFR-147](#)  
 resource-class command [VFR-184](#)  
 rmdir disk0 command [VFR-425](#)  
 role command [VFR-186](#)  
 rule command [VFR-188](#)

---

## S

server command [VFR-236](#)  
 service firewall attach location command [VFR-13](#)  
 service-location command [VFR-526](#)  
 service-policy command [VFR-149](#)  
 session-limit command [VFR-354](#)  
 set content-maxparse-length command [VFR-322](#)  
 set header-maxparse-length command [VFR-323](#)  
 set ip tos command [VFR-324](#)  
 set secondary-cookie-delimiters command [VFR-325](#)  
 set tcp ack-delay command [VFR-327](#)

set tcp mss command [VFR-329](#)  
 set tcp syn-retry command [VFR-331](#)  
 set tcp timeout command [VFR-332](#)  
 set tcp window-scale command [VFR-334](#)  
 set timeout inactivity command [VFR-336](#)  
 show aaa command [VFR-238](#)  
 show access-list command [VFR-86](#)  
 show accounting log command [VFR-239](#)  
 show acl-merge command [VFR-87](#)  
 show banner motd command [VFR-426](#)  
 show buffer command [VFR-427](#)  
 show capture command [VFR-428](#)  
 show checkpoint command [VFR-430](#)  
 show clock command [VFR-431](#)  
 show conn command [VFR-302](#)  
 show context command [VFR-190](#)  
 show copyright command [VFR-432](#)  
 show debug command [VFR-433](#)  
 show domain command [VFR-192](#)  
 show fifo command [VFR-435](#)  
 show file command [VFR-436](#)  
 show fragment command [VFR-304](#)  
 show ft group command [VFR-277](#)  
 show ft history command [VFR-280](#)  
 show ft idmap command [VFR-284](#)  
 show ft memory command [VFR-281](#)  
 show ft peer command [VFR-282](#)  
 show ft stats command [VFR-283](#)  
 show icmp statistics command [VFR-305](#)  
 show interface command [VFR-164](#)  
 show interfaces vasi command [VFR-528](#)  
 show ip command [VFR-438](#)  
 show ldap-server command [VFR-240](#)  
 show logging command [VFR-521](#)  
 show login timeout command [VFR-338](#)  
 show nat-fabric command [VFR-165](#)  
 show netio command [VFR-440](#)  
 show np command [VFR-441](#)  
 show parameter-map command [VFR-339](#)

show processes command [VFR-444](#)  
 show radius-server command [VFR-242](#)  
 show resource allocation command [VFR-193](#)  
 show resource usage command [VFR-194](#)  
 show role command [VFR-196](#)  
 show running config command [VFR-446](#)  
 show security internal event-history command [VFR-448](#)  
 show service-policy command [VFR-151](#)  
 show service role command [VFR-15](#)  
 show services firewall attachments command [VFR-17](#)  
 show services firewall interfaces command [VFR-19](#)  
 show services vasi status command [VFR-530](#)  
 show snmp command [VFR-470](#)  
 show ssh command [VFR-355](#)  
 show stats command [VFR-450](#)  
 show statup-config command [VFR-449](#)  
 show system command [VFR-452](#)  
 show tacacs-server command [VFR-244](#)  
 show tcp statistics command [VFR-306](#)  
 show tech-support command [VFR-453](#)  
 show telnet command [VFR-357](#)  
 show terminal command [VFR-359](#)  
 show udp statistics command [VFR-307](#)  
 show user-account command [VFR-198](#)  
 show users command [VFR-200](#)  
 show vnet command [VFR-456](#)  
 show xlate command [VFR-167](#)  
 shutdown command [VFR-169](#)  
 sleep command [VFR-457](#)  
 slowstart command [VFR-340](#)  
 snmp-server community command [VFR-475](#)  
 snmp-server contact command [VFR-477](#)  
 snmp-server enable traps command [VFR-478](#)  
 snmp-server location command [VFR-482](#)  
 snmp-server trap link ietf command [VFR-483](#)  
 snmp-server trap-source interface command [VFR-485](#)  
 ssh command [VFR-360](#)  
 ssh key command [VFR-362](#)  
 ssh maxsessions command [VFR-364](#)

syn-data command [VFR-341](#)  
 system internal snapshot service command [VFR-458](#)

---

## T

tacacs-server deadtime command [VFR-246](#)  
 tacacs-server key command [VFR-250](#)  
 tacacs-server timeout command [VFR-252](#)  
 tac-pac command [VFR-459](#)  
 tcp-options command [VFR-342](#)  
 telnet command [VFR-366](#)  
 telnet maxsessions command [VFR-367](#)  
 terminal command [VFR-369](#)  
 timeout xlate command [VFR-461](#)  
 traceroute command [VFR-462](#)

---

## U

undebbug all command [VFR-463](#)  
 untar disk0 command [VFR-464](#)  
 urgent-flag command [VFR-346](#)  
 username command [VFR-201](#)

---

## W

write command [VFR-465](#)

---

## X

xml-show command [VFR-467](#)

