



Software Requirements

This chapter outlines the software requirements that must be fulfilled for the correct operation of the Cisco Transport Manager Equipment Module. All software mentioned in this section must be obtained independently of the Equipment Module.

The software required includes the following:

- Cisco Transport Manager
- ONS switch software (firmware)

Cisco Transport Manager

Table 2-1 outlines the supported versions of CTM.

Table 2-1 Supported Cisco Transport Manager Software Versions

Software	Versions
Cisco Transport Manager	2.1, 2.2

Switch Software

Table 2-2 outlines the supported versions of ONS switch software (firmware).

Table 2-2 Supported ONS Switch Software Versions

Software	Version
ONS-15454	2.2.0, 2.2.1, 2.2.2

