



CLR Commands

This chapter provides CLR (clear) commands for the Cisco ONS 15454, ONS 15327, ONS 15600 and ONS 15310-CL.

6.1 CLR-COND-SECU

Clear Security Condition

Usage Guidelines

Cisco ONS 15454, ONS 15327, ONS 15600, ONS 15310-CL

This command clears the specified standing condition.



Note

In Release 6.0, only INTRUSION-PSWD parameter value is supported.

Category

Security

Security

Superuser

Related Commands

ACT-USER	REPT ALM ENV	RTRV-ALM-ALL
ALW-MSG-SECU	REPT ALM EQPT	RTRV-ALM-BITS
ALW-USER-SECU	REPT ALM SECU	RTRV-ALM-ENV
CANC	REPT ALM SYNCN	RTRV-ALM-EQPT
CANC-USER	REPT EVT <MOD2ALM>	RTRV-ALM-SYNCN
CANC-USER-SECU	REPT EVT BITS	RTRV-CMD-SECU
DLT-USER-SECU	REPT EVT COM	RTRV-COND-<MOD2ALM>
ED-CMD-SECU	REPT EVT ENV	RTRV-COND-ALL
ED-PID	REPT EVT EQPT	RTRV-COND-BITS
ED-USER-SECU	REPT EVT FXFR	RTRV-COND-ENV
ENT-USER-SECU	REPT EVT IOSCFG	RTRV-COND-EQPT
INH-MSG-SECU	REPT EVT SECU	RTRV-COND-SYNCN
INH-USER-SECU	REPT EVT SESSION	RTRV-DFLT-SECU
REPT ALM <MOD2ALM>	REPT EVT SYNCN	RTRV-USER-SECU
REPT ALM BITS	RTRV-ALM-<MOD2ALM>	SET-ATTR-SECUDFLT
REPT ALM COM		

Input Formats

CLR-COND-SECU:[<TID>]::<CTAG>[::<SECUALMTYPE>];

Input Examples

CLR-COND-SECU:CISCO::123::INTRUSION-PSWD:

Input Parameters

Table 6-1 CLR-COND-SECU Input Parameters

Parameter and Values	Description
SECUALMTYPE	Secure alarm type. Defaults to INTRUSION-PSWD Parameter type is SECUALMTYPE—security alarm type
INTRUSION-PSWD	Condition raised after an invalid password is used during login. Condition is raised only if the password is used a specified number of times.