



CLR Commands

This chapter provides CLR (clear) commands for the Cisco ONS 15454 SDH.

6.1 CLR-COND-SECU

Clear Security Condition

Usage Guidelines

This command clears the specified standing condition.

**Note**

In Software Release 6.0 and later, only the INTRUSION-PSWD parameter value is supported.

Category

Security

Security

Superuser

Input Format

CLR-COND-SECU:[<TID>]::<CTAG>[::<SECUALMTYPE>];

Input Example

CLR-COND-SECU:CISCO::123::INTRUSION-PSWD:

Input Parameters**Table 6-1** *CLR-COND-SECU Input Parameters*

Parameter and Values	Description
SECUALMTYPE	Secure alarm type. Defaults to INTRUSION-PSWD Parameter type is SECUALMTYPE—security alarm type
<ul style="list-style-type: none">INTRUSION-PSWD	Condition raised after an invalid password is used during login. Condition is raised only if the password is used a specified number of times.