



# DISC Commands

---

This chapter provides DISC (disconnect) commands for the Cisco ONS 15454 SDH.

## 9.1 DISC-TACC

Disconnect Test Access

---

### Usage Guidelines

This command disconnects the TAP and puts the connection back to its original state (no splits). For more information on TACC, refer to the [Cisco ONS SONET TL1 Reference Guide](#).

For this command to be applicable, you must first create the TAP using the ED-<VC\_PATH> or ED-VC12 command.

The following actions will return error messages:

- If you send this command to an already disconnected connection, a SADC error message is returned.
- If the system cannot release TAP, an SRTN error message is returned.



### Note

---

If the test access connection is intrusive, the original state of the facility/path is restored after this command is executed. Test access connections are dropped automatically if the TL1 session is terminated or is timed out.

---

---

### Category

Troubleshooting and Test Access

---

### Security

Maintenance

---

### Input Format

DISC-TACC:[<TID>]:<TAP>:<CTAG>;

---

### Input Example

DISC-TACC:CISCO:8:123;

## Input Parameters

Table 9-1 DISC-TACC Input Parameters

Parameter and Values	Description
TAP	The Test Access Path number. The TAP number must be an integer with a range of 1 to 999. String  <b>Note</b> This command only supports disconnecting one TAP at a time