



CLR Commands

This chapter provides clear (CLR) commands for the Cisco ONS 15454, ONS 15327, ONS 15310-CL, ONS 15310-MA, and ONS 15600.

6.1 CLR-COND-SECU

(Cisco ONS 15454, ONS 15327, ONS 15310-CL, ONS 15310-MA, ONS 15600) The Clear Security Condition (CLR-COND-SECU) command clears the specified standing condition.

Usage Guidelines	In Software Release 6.0 and later, only the INTRUSION-PSWD parameter value is supported.	
Category	Security	
Security	Superuser	
Input Formats	CLR-COND-SECU:[<TID>]::<CTAG>[:<SECUALMTYPE>];	
Input Examples	CLR-COND-SECU:CISCO::123::INTRUSION-PSWD:	
Input Parameters	<SECUALMTYPE>	Secure alarm type. Defaults to INTRUSION-PSWD. The parameter type is security alarm type (SECUALMTYPE).
	INTRUSION-PSWD	Condition raised after an invalid password is used during login. Condition is raised only if the password is used a specified number of times.

