



CHAPTER 6

CLR Commands

This chapter provides clear (CLR) commands for the Cisco ONS 15454, ONS 15327, ONS 15310-CL, ONS 15310-MA, and ONS 15600.

6.1 CLR-COND-SECU

(Cisco ONS 15454, ONS 15327, ONS 15310-CL, ONS 15310-MA, ONS 15600) The Clear Security Condition (CLR-COND-SECU) command clears the specified standing condition.

Usage Guidelines In Software Release 6.0 and later, only the INTRUSION-PSWD parameter value is supported.

Category Security

Security Superuser

Input Formats CLR-COND-SECU:[<TID>]::<CTAG>[::<SECUALMTYPE>];

Input Examples CLR-COND-SECU:CISCO::123::INTRUSION-PSWD:

Input Parameters	<SECUALMTYPE>	Secure alarm type. Defaults to INTRUSION-PSWD. The parameter type is security alarm type (SECUALMTYPE).
	<ul style="list-style-type: none"> INTRUSION-PSWD 	Condition raised after an invalid password is used during login. Condition is raised only if the password is used a specified number of times.

