



SIP 3xx Redirect Responses

This section describes how Cisco Unified Border Element (SP Edition) can be configured to process Session Initiation Protocol (SIP) 3xx responses. 3xx is a class of the response code used in SIP to indicate that further action needs to be taken in order to complete the request. The sender of the request should retry the request, using one or more alternative Uniform Resource Identifiers (URIs), which are presented in the 3xx response.



Note

For Cisco IOS XE Release 2.4, this feature is supported in the unified model only.

Cisco Unified Border Element (SP Edition) was formerly known as Integrated Session Border Controller and may be commonly referred to in this document as the session border controller (SBC).

For a complete description of the commands used in this chapter, refer to the *Cisco Unified Border Element (SP Edition) Command Reference: Unified Model* at:

http://www.cisco.com/en/US/docs/ios/sbc/command/reference/sbcu_book.html.

For information about all Cisco IOS commands, use the Command Lookup Tool at <http://tools.cisco.com/Support/CLILookup> or a Cisco IOS master commands list.

Feature History for SIP 3xx Redirect Responses

Release	Modification
Cisco IOS XE Release 2.4	This feature was introduced on the Cisco IOS XR along with support for the unified model.

Contents

This module contains the following sections:

- [Information About 3xx Redirect Responses in SIP, page 45-2](#)
- [How to Configure Cisco Unified Border Element \(SP Edition\) to Process SIP 3xx Responses, page 45-3](#)
- [Examples of Configuring Cisco Unified Border Element \(SP Edition\) to Process SIP 3xx Responses, page 45-5](#)

Information About 3xx Redirect Responses in SIP

This section contains the following subsections:

- [3xx Responses, page 45-2](#)
- [Diversion Headers, page 45-3](#)

3xx Responses

3xx responses are usually only expected in session-initiating requests, INVITEs. However, the SIP specification does not preclude sending 3xx responses for other request types. A number of alternative URIs are supplied on the 3xx responses in Contact headers.

The 3xx class of responses includes any response code in the range of 300-399 and indicates a redirection of the call. The redirection requires further action to be taken to complete the request. The following 3xx response codes are defined in SIP.

- **300 Multiple Choices.** The address in the request resolved to several choices, each with its own specific location. The user or user agent (UA) can select a preferred communication end point and redirect the request to that location.
- The response may include a message body containing a list of resource characteristics and location(s), from which the user or UA can choose the most appropriate one, if allowed by the Accept request header field. However, no MIME types have been defined for this message body.
- The choices should also be listed as Contact fields. The response may contain several Contact fields or a list of addresses in a Contact field. UAs may use the Contact header field value for automatic redirection or ask the user to confirm a choice.
- **301 Moved Permanently.** The user can no longer be found at the address in the Request-URI, and the requesting client should retry at the new address given by the Contact header field. The requestor should update any local directories, address books, and user location caches with this new value, and redirect future requests to the addresses listed.
- **302 Moved Temporarily.** The requesting client should retry the request at the new address(es) given by the Contact header field. The Request-URI of the new request uses the value of the Contact header field in the response.

The duration of the validity of the Contact URI can be specified through an **Expires** header field or an **Expires** parameter in the Contact header field. Both proxies and UAs may cache this URI for the duration of the expiration time. If there is no explicit expiration time, the address is valid only once for recursing, and must not be cached for future transactions.

If the URI cached from the Contact header field fails, the Request-URI from the redirected request may be tried again only once.

- **305 Use Proxy.** The requested resource must be accessed through the proxy given by the Contact field. The Contact field gives the URI of the proxy. The recipient is expected to repeat this single request via the proxy. 305 responses must only be generated by the user agent servers (UASs).

380 Alternative Service. The call was not successful, but alternative services are possible. The alternative services are described in the message body of the response. There are no formats currently defined for this information.

In each case, the request should be retried to one of the supplied alternative URIs. The request can be retried by either the originating UA, or by an intermediate back-to-back user agent (B2BUA) or proxy on behalf of the originating UA (and without notifying it).

Cisco Unified Border Element (SP Edition) is a B2BUA, and, therefore, in some deployments it may be necessary for Cisco Unified Border Element (SP Edition) to retry the request instead of sending a negative response back to the initiator of the request.

Diversion Headers

The Diversion header enables the called SIP user agent to identify from whom the call was diverted and why it was diverted. The header notifies the original caller:

- That the call has been redirected to a destination that differs from the original target
- The number to which the call has been redirected
- The reason for the redirection

The diversion header is attached by networking elements that change the final destination of a request.

How to Configure Cisco Unified Border Element (SP Edition) to Process SIP 3xx Responses

This section contains the steps for configuring Cisco Unified Border Element (SP Edition) to process SIP 3xx responses.

Configuring Cisco Unified Border Element (SP Edition) to Process SIP 3xx Responses

SUMMARY STEPS

1. **configure terminal**
2. **sbc *sbc-name***
3. **sbe**
4. **adjacency sip *adjacency-name***
5. **redirect-mode *mode***
6. **attach**
7. **exit**
8. **redirect-limit *limit***
9. **end**
10. **show sbc *sbc-name* sbe adjacencies**
11. **show sbc *sbc-name* sbe redirect-limit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: Router# configure terminal	Enables global configuration mode.
Step 2	sbc service-name Example: Router(config)# sbc mysbc	Enters the mode of an SBC service. Use the <i>service-name</i> argument to define the name of the service.
Step 3	sbe Example: Router(config-sbc)# sbe	Enters the mode of the signaling border element (SBE) function of the SBC.
Step 4	adjacency sip adjacency-name Example: Router(config-sbc-sbe)# adjacency sip SipToIsp42	Enters the mode of an SBE SIP adjacency. Use the <i>adjacency-name</i> argument to define the name of the service.
Step 5	redirect-mode mode Example: Router(config-sbc-sbe-adj-sip) redirect-mode recurse	Configures the behavior of the SBC on receipt of a 3xx response to an INVITE from the SIP adjacency. redirect-mode pass-through—SBC passes all 3xx responses back to the caller (the default mode). redirect-mode recurse—On 300, 301, 302, and 305 INVITE responses (under the redirect-limit, see Step 8), SBC resends the INVITE to the first listed contact address. Otherwise, SBC passes 3xx responses back. no redirect-mode—The no version of this command returns the adjacency to the default behavior.
Step 6	attach Example: Router(config-sbc-sbe-adj-sip)# attach	Attaches the adjacency.
Step 7	exit Example: Router(config-sbc-sbe-adj-sip)# exit	Exits the adjacency-sip mode and returns to the SBE mode.
Step 8	redirect-limit limit Example: Router(config-sbc-sbe)# redirect-limit 4	Configures the maximum number of redirections that the SBC performs on a given call. redirect-limit limit—A numeric value, the maximum number of redirections performed before the call is failed (the range is 0-100, the default is 2). no redirect-limit—The no version of this command returns the adjacency to the default behavior.

	Command or Action	Purpose
Step 9	end Example: Router(config-sbc-sbe)# end	Exits the SBE mode and returns to Privileged EXEC mode.
Step 10	show sbc sbc-name sbe adjacencies Example: Router# show sbc mysbc sbe adjacencies	Lists the adjacencies configured on SBEs.
Step 11	show sbc sbc-name sbe redirect-limit Example: Router# show sbc mysbc sbe redirect-limit	Displays the current limit on the maximum number of redirections a call can undergo.

Examples of Configuring Cisco Unified Border Element (SP Edition) to Process SIP 3xx Responses

This section provides two simple configurations for processing SIP 3xx responses.

The following command configures the adjacency “SipToIsp42” to recurse on 300, 301, 302, and 305 INVITE responses.

```
Router(config)# sbc mySbc sbe adjacency sip SipToIsp42
Router(config-sbc-sbe-adj-sip)# redirect-mode recurse
Router(config-sbc-sbe-adj-sip)# end
```

The following command configures the SBE to perform maximum 4 SIP 3xx redirections per call.

```
Router(config)# sbc mySBC
Router(config-sbc)# sbe
Router(config-sbc-sbe)# redirect-limit 4
Router(config-sbc-sbe)# end
```

