



# CHAPTER 1

## Before You Begin

---

Use the following table to find the installation and configuration steps that are required for your implementation of the Cisco ASA 5580 adaptive security appliance.

To Do This...	See...
<b>Install the chassis</b>	<a href="#">Chapter 3, “Installing the ASA 5580”</a>
<b>Connect interface cables</b>	<a href="#">Chapter 3, “Installing the ASA 5580”</a>
<b>Perform initial setup of the adaptive security appliance</b>	<a href="#">Chapter 4, “Configuring the Adaptive Security Appliance”</a> <i>Cisco ASDM User Guide</i>
<b>Configure the adaptive security appliance for your implementation</b>	<a href="#">Chapter 5, “Scenario: Configuring Connections for a Cisco AnyConnect VPN Client”</a> <a href="#">Chapter 6, “Scenario: SSL VPN Clientless Connections”</a> <a href="#">Chapter 7, “Scenario: Site-to-Site VPN Configuration”</a> <a href="#">Chapter 8, “Scenario: IPsec Remote-Access VPN Configuration”</a>

<b>To Do This...</b>	<b>See...</b>
<b>Configure optional and advanced feature</b>	<i>Cisco Security Appliance Command Line Configuration Guide</i>
<b>Operate the system on a daily basis</b>	<i>Cisco Security Appliance Command Reference</i> <i>Cisco Security Appliance Logging Configuration and System Log Messages</i> <i>Cisco ASDM User Guide</i>