

Send documentation comments to mdsfeedback-doc@cisco.com.



E Commands

The commands in this chapter apply to the Cisco MDS 9000 Family of multilayer directors and fabric switches. All commands are shown here in alphabetical order regardless of command mode. Please see the Command Mode section to determine the appropriate mode for each command. For more information, see the *Cisco MDS 9000 Family Configuration Guide*.

- end
- exit

Send documentation comments to mdsfeedback-doc@cisco.com.

end

To exit any of the configuration modes and return to EXEC mode, use the **end** command

end

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Configuration mode

Usage Guidelines You can also press **Ctrl-Z** to exit configuration mode.

Examples The following example changes the name to george. Entering the **end** command causes the system to exit configuration mode and return to EXEC mode.

```
switch-config# hostname george
switch-config# end
switch#
```

Related Commands	Command	Description
	hostname	Specifies or modifies the host name for the network server.
	exit	Exits configuration mode, or any of the configuration modes

Send documentation comments to mdsfeedback-doc@cisco.com.

exit

To exit any configuration mode or close an active terminal session and terminate the EXEC, use the `exit` command at the system prompt.

exit

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Available in all command modes except switchport.

Usage Guidelines Use the **exit** command at the EXEC levels to exit the EXEC mode. Use the **exit** command at the configuration level to return to privileged EXEC mode. Use the **exit** command in interface configuration mode to return to configuration mode. You also can press **Ctrl-Z**, or use the **end** command, from any configuration mode to return to EXEC mode.



Note

The **exit** command is associated with privilege level 0. If you configure AAA authorization for a privilege level greater than 0, this command will not be included in the command set for that privilege level.



Note

This command does not work at the **switchport#** prompt.

Examples The following example displays an exit from the interface configuration mode for VRRP to return to the interface configuration mode:

```
switch-config-if-vrrp# exit
switch-config-if#
```

The following example displays an exit from the interface configuration mode to return to the configuration mode:

```
switch-config-if# exit
switch-config#
```

The following example shows how to exit an active session (log-out):

```
switch# exit
```

Related Commands	Command	Description
	disconnect	Disconnects a line
	end	Returns you to EXEC mode.
