



## Initial Configuration Commands

---

```
switchname myswitch1
no switchname
snmp-server
no snmp-server
snmp-server contact NewUser
no snmp-server contact NewUser
snmp-server location SanJose
no snmp-server location SanJose
snmp-server name NewName
no snmp-server name NewName
show module
clock set <HH:MM:SS> <DD> <Month in words> <YYYY>
clock timezone
show timezone
clock summer-time
no clock summer-time
ntp tstamp-check 1
ntp server ipaddr

copy running-config startup-config
interface
ip address
no shutdown
show interface command.

ip default-gateway 1.1.1.4
no telnet server enable
telnet server enable
show running-config
show startup-config command:
copy <scheme> ://<server address> system: running-config
copy <scheme>://<url> nvram: startup-config

dir
cd
pwd
delete
```

