



---

## Numerics

### 16-port modules

BB\_credits [18-8](#)

### 32-port modules

BB\_credits [18-8](#)

configuration guidelines [18-5](#)

---

## A

### AAA

description [27-1](#)

distributing with CFS (procedure) [27-11](#)

enabling distribution with CFS (procedure) [27-10](#)

local authentication [27-11](#)

RADIUS [27-5](#)

TACACS+ [27-7](#)

### access control

iSCSI enforcement [20-17](#)

iSCSI mechanisms [20-16](#)

Access Control Lists. See ACLs

accounting [27-3](#)

### ACLs

associating with an interface (procedure) [28-6](#)

configuration guidelines [28-1](#)

creating complex ACLs (procedure) [28-5](#)

creating with IP-ACL Wizard (procedure) [28-4](#)

deleting (procedure) [28-7](#)

removing from an interface (procedure) [28-6](#)

administrator passwords, recovering [25-7](#)

advanced mode in Fabric Manager client [3-2](#)

### AFIDs

configuring (procedure) [16-9](#)

default (procedure) [16-9](#)

description [16-4](#)

### aliases

creating zones with (procedure) [15-6](#)

deleting (procedure) [15-13](#)

description [15-6](#)

switching between global device aliases and FC aliases [2-10](#)

viewing (procedure) [15-7](#)

authentication, authorization, and accounting. See AAA

autonomous fabric ID

See AFIDs

AutoNotify [34-1](#)

### auto port mode

description [18-4](#)

interface configuration [18-1](#)

### auto-topology

configuration guidelines [16-5](#)

IVR [16-4](#)

modifying (procedure) [16-9](#)

---

## B

### BB\_credits

16-port modules [18-8](#)

32-port modules [18-8](#)

configuring [18-8](#)

reason codes [B-1](#)

Berkeley Packet Filter. See BPF

### bootflash

file system [10-1](#)

space requirements [10-2](#)

### BPF

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).***

library [35-11](#)

See also libpcap freeware

## B ports

enabling (procedure) [19-17](#)

functionality [18-4](#)

interface modes [18-1](#), [18-4](#)

interoperability mode [19-15](#)

SAN extenders [19-16](#)

bridge port. See B port

buffer-to-buffer credits. See BB\_credits

## C

### Call Home

alerts [34-3](#)

alerts (procedure) [34-3](#)

configuring (procedure) [34-2](#)

description [34-1](#)

device ID format [34-5](#)

event triggers [34-3](#)

message contents [34-5](#)

message severity levels [34-3](#)

profiles [34-2](#)

profiles (procedure) [34-3](#)

### CFS

committing changes (procedure) [12-5](#)

description [12-1](#)

disabling (isolating) or enabling distribution on a switch  
(procedure) [12-6](#)

enabling (procedure) [12-3](#)

example using Device Manager [12-9](#)

example using Fabric Manager [12-7](#)

MDS SAN-OS features [12-1](#)

merge support (procedure) [12-8](#)

merging [12-7](#)

Cisco.com IDs [34-2](#)

Cisco Fabric Services. See CFS

Cisco Traffic Analyzer

configuring with Performance Manager  
(procedure) [8-8](#)

description [8-3](#)

installing (procedure) [8-4](#)

claim certificate [9-2](#)

### common roles

creating (procedure) [25-2](#)

deleting (procedure) [25-3](#)

description [25-2](#)

editing rules (procedure) [25-3](#)

communities.properties file, editing [26-4](#)

### CompactFlash

devices [10-8](#)

disk [10-1](#)

### configuraiton files

saving (procedures) [11-1](#)

### configuration files

copying (procedure) [11-2](#)

Control Unit Port. See CUP

counted licenses [9-2](#)

cross-VSAN communication [16-13](#)

### crypto map

any keyword [29-12](#)

applying to interface [29-16](#)

AutoPeer option [29-14](#)

configuration guidelines [29-9](#)

entries [29-13](#)

managing entries (procedure) [29-16](#)

mirror image [29-10](#)

### CUP

description [22-1](#)

management [22-20](#)

### custom reports [5-4](#)

generating (procedure) [5-11](#)

viewing (procedure) [5-11](#)

## D

### databases

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).***

- See zone databases
- databases. See zone databases
- default zones
  - description [15-14](#)
  - interoperability [24-5](#)
  - setting policy (procedure) [15-15](#)
- See also zones
- destination IDs
  - fctrace [24-2](#)
  - PortChannels [17-1](#)
- detachable tables [3-13](#)
- device alias [1-8, 2-8](#)
- device grouping (procedure) [3-15](#)
- device IDs
  - Call Home format [34-6](#)
- Device Manager
  - description [4-1](#)
  - launching (procedure) [4-2](#)
  - port status [4-6](#)
  - preferences [4-8](#)
  - tabs [4-5](#)
  - using interface (figure) [4-3](#)
  - viewing license information [9-10](#)
- DHCHAP
  - authentication modes [30-4](#)
  - changing group list (procedure) [30-6](#)
  - changing hash algorithm (procedure) [30-5](#)
  - changing timeout value (procedure) [30-8](#)
  - configuring [30-3](#)
  - configuring authentication mode (procedure) [30-5](#)
  - configuring password [30-6](#)
  - configuring password (procedure) [30-7](#)
  - configuring remote password (procedure) [30-7](#)
  - description [30-2](#)
  - enabling (procedure) [30-3](#)
  - using with Cisco MDS SAN-OS [30-3](#)
- digital signature algorithm. See DSA key pairs
- discovering a fabric, best practices [7-3](#)
- disruptive upgrades [10-3](#)

- documentation
  - related [xxxv](#)
- domain IDs
  - failure [B-2](#)
  - interoperability [24-5](#)
  - non-unique and IVR NAT [16-3](#)
  - unique [16-6](#)
- domain overlap [B-2](#)
- DPVM
  - autolearn entries [14-3](#)
  - databases [14-2](#)
  - description [14-1](#)
  - modifying databases (procedure) [14-5](#)
  - requirements [14-2](#)
  - using DPVM Setup Wizard (procedure) [14-4](#)
- Dynamic Port VSAN Membership. See DPVM

---

## E

- EISL, PortChannel links [17-1](#)
- ELP failure [B-2](#)
- enclosures [32-2](#)
- enclosures (procedure) [3-15](#)
- Enterprise package [9-3](#)
- E ports
  - 32-port guidelines [18-5](#)
  - classes of service [18-2](#)
  - configuring [19-18](#)
  - interface modes [18-1](#)
  - isolation [B-2](#)
  - recovering from isolation [15-15](#)
- error disabled code, interface [B-1](#)
- ESC failure [B-2](#)
- ESI
  - non-resp threshold [20-26](#)
- Ethereal freeware
  - analyzer [35-8](#)
  - information [35-7](#)
- Ethernet PortChannels [19-21](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).***

evaluation license [9-2](#)

events

description [5-3](#)

Device Manager [32-10](#)

Fabric Manager [32-10](#)

Fabric Manager Web Services [32-10](#)

exchange IDs, load balancing [17-1, 24-2](#)

exchange link parameter failure. See ELP failure

expiry alerts, licenses [9-12](#)

exporting

Performance Manager reports as CSV [33-9](#)

Performance Manager reports as XML [33-8](#)

zone databases [15-15](#)

## F

fabric, removing from monitoring [2-8](#)

Fabric Analyzer

capture filters [35-11](#)

configuring [35-9](#)

defining display filters [35-11](#)

description [35-7](#)

displaying captured frames [35-10](#)

permitted filters [35-12](#)

fabric binding

activating (procedure) [22-23](#)

clearing statistics (procedure) [22-25](#)

compare to port security [22-20](#)

configuring (procedure) [22-22](#)

copying to configuration file (procedure) [22-23](#)

creating config database (procedure) [22-24](#)

deactivating (procedure) [22-23](#)

deleting from config database (procedure) [22-24](#)

description [22-20](#)

enabling (procedure) [22-22](#)

enforcing [22-21](#)

viewing active database (procedure) [22-24](#)

viewing EFMD statistics (procedure) [22-25](#)

viewing violations (procedure) [22-24](#)

Fabric Manager

description [1-1](#)

detachable tables [3-13](#)

downgrade to release 1.3(x) [1-9](#)

downgrade to release 2.x [1-9](#)

installation [1-6](#)

installation (procedure) [1-7](#)

integrating with other tools [1-11](#)

launching (procedure) [1-10](#)

running behind a firewall [1-12](#)

uninstalling [1-13](#)

upgrade [1-9](#)

viewing license information [9-8](#)

Fabric Manager Client

advanced mode [3-2](#)

description [3-1](#)

filtering [3-12](#)

icons (table) [3-5](#)

Information pane icons (table) [3-8, 3-9, 4-4](#)

launching [3-2](#)

setting preferences [3-13](#)

troubleshooting tools [3-17](#)

using interface (figure) [3-3](#)

wizards [3-16](#)

Fabric Manager graphics (table) [3-5](#)

Fabric Manager Server

authentication [7-2](#)

configuring Performance Manager (procedure) [2-4](#)

continuously monitoring a fabric (procedure) [2-7](#)

description [2-2](#)

full fabric rediscovery [2-9](#)

installation overview [2-2](#)

installing Fabric Manager Web Services  
(procedure) [2-6](#)

licensing [2-3, 9-12](#)

password [2-9](#)

polling period [2-9](#)

properties file [2-8](#)

removing a fabric from monitoring (procedure) [2-8](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).***

- setting the seed switch (procedure) [2-4](#)
- Fabric Manager Web Services
  - Admin tab [5-4](#)
  - creating report templates (procedure) [5-10](#)
  - custom reports [5-4](#)
  - description [5-1](#)
  - events [5-3](#)
  - filter tree [5-2](#)
  - generating custom reports (procedure) [5-11](#)
  - guest user [5-9](#)
  - installation (procedures) [5-4](#)
  - inventory [5-3](#)
  - launching (procedure) [5-7](#)
  - Performance tab [5-3](#)
  - RADIUS authentication [7-4](#)
  - recovering passwords [5-9](#)
  - TACACS+ authentication [7-4](#)
  - using with SSL [5-6](#)
  - viewing custom reports (procedure) [5-11](#)
- FabricWare
  - FibreChannel support [1](#)
  - roles [2](#)
  - security [2](#)
  - support in Fabric Manager (table) [3](#)
  - syslog and SNMP traps [2](#)
  - zone support [1](#)
- FC aliases, configuring zones [15-3](#)
- FC IDs
  - allocating [24-4](#)
  - allocating flat FC IDs [24-4](#)
  - configuring persistent FC IDs (procedure) [18-9](#)
  - configuring zones [15-2](#)
- FCIP
  - active mode [19-14](#)
  - checking trunk status (procedure) [19-10](#)
  - configuring peers [19-13](#)
  - configuring with FCIP Wizard (procedure) [19-5](#)
  - description [19-2](#)
  - Gigabit Ethernet ports [19-1](#)
  - high availability [19-18](#)
  - initiating an IP connection [19-14](#)
  - interfaces [19-3, 19-9](#)
  - link end points [19-3](#)
  - link failures [19-19](#)
  - links [19-3, 19-13](#)
  - modifying links and profiles (procedure) [19-9](#)
  - profiles [19-3, 19-8](#)
  - TCP connections [19-3](#)
  - verifying interfaces and Extended Link Protocol (procedure) [19-10](#)
- FCIP compression
  - configuring (procedure) [19-7](#)
  - description [19-5](#)
  - modifying (procedure) [19-11](#)
- FCIP tape acceleration
  - description [19-11](#)
  - enabling (procedure) [19-13](#)
- FCIP write acceleration
  - configuring (procedure) [19-7](#)
  - description [19-4](#)
  - modifying (procedure) [19-11](#)
- FCP, routing requests with iSCSI [20-4](#)
- fcping
  - description [24-2](#)
  - starting (procedure) [24-3](#)
- FC-SP
  - description [30-1](#)
  - enabling (procedure) [30-3](#)
  - enabling on ISLs [30-8](#)
- fctrace
  - description [24-2](#)
  - path discovery [24-2](#)
  - starting (procedure) [24-2](#)
- Fibre Channel over IP. See FCIP
- Fibre Channel PortChannels [19-21](#)
- Fibre Channel Security Protocol. See FC-SP
- Fibre Channel time out values [24-1](#)
- Fibre Channel write acceleration

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).***

configuration (procedure) [23-5](#)  
 description [23-4](#)

FICON

- allowing host control of switch (procedure) [22-13](#)
- allowing host to configure FICON (procedure) [22-13](#)
- calculating flow load balance (procedure) [22-26](#)
- code-page option [22-12](#)
- configuration files [22-16](#)
- configure port blocking or port prohibiting (procedure) [22-15](#)
- creating VSANs (procedure) [22-10](#)
- description [22-1](#)
- director history (procedure) [22-12](#)
- displaying port configuration (procedure) [22-15](#)
- displaying RLIR (procedure) [22-25](#)
- enabling (procedure) [22-10](#)
- fabric binding [22-20](#)
- FC ID allocation [22-8](#)
- FC ID last byte requirement [22-12](#)
- managing configuration files (procedure) [22-18](#)
- port blocking [22-14](#)
- port numbering (table) [22-7](#)
- port prohibiting [22-14](#)
- port swap [22-18](#)
- port swap (procedure) [22-19](#)
- uninstalled ports [22-8](#)
- viewing port attributes (procedure) [22-16](#)
- VSAN requirements [22-9](#)

File Transfer Protocol. See FTP

FL ports

- classes of service [18-3](#)
- fctrace [24-2](#)
- interface modes [18-1](#)
- nonparticipating code [B-2](#)

F ports

- classes of service [18-2](#)
- interface modes [18-1](#)

FSPF interoperability [24-5](#)

FSP not present [B-1](#)

FTP

Fx ports

- 32-port default [18-6](#)
- interface modes [18-4](#)

---

## G

Gigabit Ethernet ports [19-1](#)

global alias [1-8, 2-8](#)

grace period [9-2](#)

---

## H

hard zoning

- See also zones [15-14](#)

hard zoning, description [15-14](#)

HBA [20-3](#)

high availability

- Ethernet PortChannel [20-24](#)
- features [20-21](#)
- iSCSI statically imported targets [20-10](#)
- licensing [9-4](#)
- PortChannels [17-1](#)
- software upgrade [10-3](#)
- VRRP [19-20, 20-23](#)

Host Bus Adaptor. See HBA

---

## I

IDs

- contract IDs [34-5](#)
- image version and IDs [10-1](#)
- serial IDs [34-6](#)
- server IDs [34-6](#)
- site IDs [34-5](#)

IKE

- description [29-4](#)
- supported transforms and algorithms [29-6](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).***

- terms [29-4](#)
- viewing configuration [29-9](#)
- Windows and Linux support [29-7](#)
- system images
- images. See kickstart images
- inactive code, interface [B-1](#)
- in-band management [1-5](#)
- incremental licenses [9-2](#)
- Information pane [3-8, 3-9, 4-4](#)
- intelligent storage services
  - description [23-1](#)
  - disabling (procedure) [23-3](#)
  - disabling with force option [23-3](#)
  - enabling (procedure) [23-2](#)
- interfaces
  - administrative states [18-5](#)
  - BB\_credits [18-8](#)
  - configuring BB\_credits or performance buffers (procedure) [18-8](#)
  - configuring Fibre Channel (procedure) [18-6](#)
  - configuring Gigabit Ethernet (procedure) [18-7, 19-2](#)
  - configuring trunking mode (procedure) [18-4](#)
  - description [18-1](#)
  - enabling or disabling (procedure) [18-7](#)
  - managing attributes for ports [18-7](#)
  - modes [18-1](#)
  - nonoperational reason codes [B-1](#)
  - operational state [18-5](#)
  - performance buffers [18-8](#)
  - reason codes [18-5](#)
  - SFT types [18-9](#)
  - states [18-5](#)
- internal bootflash
  - description [10-8](#)
  - Flash devices [10-8](#)
  - See also bootflash
- Internet storage name service. See iSNS
- interoperability [24-4](#)
- interop mode, configuring (procedure) [24-6](#)
- inter-VSAN routing. See IVR
- inventory
  - description [5-3](#)
  - Fabric Manager Client [32-3](#)
  - Fabric Manager Web Services [32-3](#)
- IP Access Control Lists. See ACLs
- IPFC interface configuration [18-9](#)
- IP filters
  - description [28-2](#)
  - using IP-ACL Wizard (procedure) [28-4](#)
- IPsec
  - compatibility [29-3](#)
  - configuring with FCIP Wizard (procedure) [19-6](#)
  - crypto map [29-9](#)
  - description [29-3](#)
  - enabling with FCIP Wizard (procedure) [29-7](#)
  - global lifetime values for SAs [29-17](#)
  - requirements [29-2](#)
  - SA establishment [29-14](#)
  - SA lifetime negotiation [29-15](#)
  - supported transforms [29-5](#)
  - terms [29-4](#)
  - transform sets [29-12](#)
  - viewing configuration (procedure) [29-9](#)
  - Windows and Linux support [29-7](#)
- IQN formats [20-8](#)
- iSCSI
  - as member of a zone (procedure) [20-16](#)
  - configuring trespass option (procedure) [20-11](#)
  - description [20-1 to 20-5](#)
  - discovery [20-17](#)
  - drivers [20-4](#)
  - enabling (procedure) [20-5](#)
  - Fibre Channel targets [20-2](#)
  - Gigabit Ethernet ports [19-1](#)
  - modifying VSANS assigned (procedure) [20-13](#)
  - overriding global interface authentication [20-18](#)
  - physical targets [20-2](#)
  - QoS (procedure) [20-20](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).***

- revert to primary port (procedure) [20-10](#)
- routing requests [20-4](#)
- session creation [20-17](#)
- using iSCSI Wizard (procedure) [20-5 to 20-7](#)
- virtual Fibre Channel hosts [20-11](#)
- iSCSI authentication
  - configuring (procedure) [20-18](#)
  - configuring RADIUS (procedure) [20-19](#)
  - description [20-17](#)
- iSCSI hosts
  - configuring accessibility [20-17](#)
  - multiple VSANs [20-13](#)
- iSCSI initiators
  - access list [20-17](#)
  - dynamic mapping [20-12](#)
  - identifying [20-12](#)
  - statically mapped (procedure) [20-13](#)
  - static mapping [20-12](#)
  - static mapping, manual [20-13](#)
  - static mapping, system assignment [20-13](#)
- iSCSI proxy initiators
  - configuring (procedure) [20-16](#)
  - description [20-14](#)
- iSCSI targets
  - access control [20-16](#)
  - advertising [20-9](#)
  - dynamic importing [20-7](#)
  - dynamic importing (procedure) [20-8](#)
  - secondary access [20-10](#)
  - static importing [20-7](#)
  - static importing (procedure) [20-9](#)
- ISL
  - PortChannel links [17-1](#)
  - statistics [33-2](#)
- iSMS servers
  - enabling [20-26](#)
- iSNS
  - creating profile (procedure) [20-25](#)
  - description [20-24](#)
- ESI [20-26](#)
- tagging a profile for an interface (procedure) [20-25](#)
- IVR
  - auto-topology [16-4](#)
  - border switch [16-3](#)
  - border switch, guidelines [16-7](#)
  - configuring (procedure) [16-10](#)
  - configuring zones and zone sets (procedure) [16-14](#)
  - default zone policy [16-13](#)
  - description [16-1](#)
  - domain ID guidelines [16-6](#)
  - edge switch [16-3](#)
  - edge VSAN [16-3](#)
  - Fibre Channel header modifications [16-3](#)
  - interoperability [16-17](#)
  - modifying [16-8](#)
  - path [16-2](#)
  - recovering the full topology (procedure) [16-17](#)
  - recovering the full zone database [16-16](#)
  - sharing resources [16-2](#)
  - terminology [16-2](#)
  - transit VSAN, guidelines [16-7](#)
  - using IVR Zone Wizard [16-7](#)
  - virtual domains [16-12 to 16-13](#)
  - VSAN topology [16-4](#)
  - zones (definition) [16-2](#)
  - zone set activation (procedure) [16-16](#)
  - zone sets (definition) [16-2](#)
- IVR NAT
  - border switch, guidelines [16-5](#)
  - configuration guidelines [16-5](#)
  - description [16-3](#)
  - modifying (procedure) [16-9](#)
  - service groups, guidelines [16-6](#)
  - transit VSANs, guidelines [16-5](#)
  - using IVR Zone Wizard [16-7](#)
- IVR NAT auto-topology [16-4](#)
- IVR topology
  - activating (procedure) [16-12](#)



***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).***

clearing manual entries [16-12](#)  
 creating manually [16-11](#)  
 enabling auto-topology [16-7](#)

## K

kickstart images  
   description [10-1](#)  
   KICKSTART variable [10-1](#)

## L

launching management software [1-10](#)  
 libpcap freeware [35-7](#)  
 license  
   enforcing [9-1](#)  
   Fabric Manager Server package [9-4](#)  
   factory-installed [9-5](#)  
   feature based [9-2](#)  
   high availability [9-4](#)  
   host ID [9-2](#)  
   installation options [9-5](#)  
   installing with License Wizard [9-7](#)  
   Mainframe package [9-4](#)  
   obtaining a license key file [9-6](#)  
   SAN extension package [9-3](#)  
   terminology [9-1](#)  
 licenses  
   expiry alerts [9-12](#)  
   moving between switches [9-12](#)  
   uninstalling [9-10](#)  
   updating [9-11](#)  
   viewing with Fabric Manager Web Services  
     (procedure) [9-9](#)  
 link failures [B-1](#)  
 load balancing  
   description [17-1](#)  
   FSPF [19-19](#)  
   PortChannel [19-19](#)

local capture [35-9](#)  
 log files, configuring [32-8](#)  
 logging  
   severity levels [32-7](#)  
   system messages [32-4](#)  
 Logical Domains pane [3-10](#)  
 logical units. See LUs  
 logs  
   Device Manager [32-9](#)  
   Fabric Manager Web Services [32-9](#)  
   RMON [34-16](#)  
   SNMP events [34-13](#)  
 loop monitoring [24-4](#)  
 loop port [24-4](#)  
 LUN zoning  
   configuring [15-20](#)  
   description [15-19](#)  
 LUs  
   exporting [20-11](#)  
   importing targets [20-7](#)

## M

main menu [3-7](#)  
 management protocols supported (table) [1-3](#)  
 mapping  
   iSCSI hosts [20-11](#)  
   PortChannels [19-21](#)  
 module-based licensing [9-2](#)  
 MPS-14/2 module  
   functions [29-1](#)  
   IPsec support [29-2](#)  
 multiple fabrics [32-3](#)  
 Multiprotocol Services module. See MPS-14/2 module  
 mutual CHAP authentication  
   configuring for iSCSI [20-19](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).***

## N

name server interoperability [24-6](#)

### NASB

configuring (procedure) [23-13](#)

description [23-11](#)

permitting default zoning (procedure) [23-12](#)

native VSAN [16-2](#)

network administrator [27-2](#)

Network-Assisted Serverless Backup. See NASB

network operator [27-2](#)

new and changed information (table) [xxvii](#)

### NL ports

fctrace [24-2](#)

interface modes [18-4](#)

zone enforcement [15-13](#)

node-locked license [9-2](#)

nondisruptive upgrades [10-3](#)

### N ports

fctrace [24-2](#)

zone enforcement [15-13](#)

Nx ports, hard zoning [15-14](#)

## O

offline code, interface [B-1](#)

out-of-band management [1-5](#)

## P

PAA-2 [8-3](#)

passive mode, IP connection [19-14](#)

### passwords

creating strong passwords [25-5](#)

recovering [25-7](#)

### peers

configuring [19-13](#)

configuring (procedure) [19-14](#)

### performance

historical monitoring [33-2](#)

ISL statistics (procedure) [33-2](#)

monitoring in Device Manager (procedure) [33-1](#)

per-port monitoring (procedure) [33-2](#)

real-time monitoring [33-1](#)

### Performance Manager

architecture [6-1](#)

authentication [7-3](#)

collections [33-3](#)

configuring flows and collections (procedure) [33-5](#)

configuring with Traffic Analyzer [8-8, 33-10](#)

creating a flow [33-3](#)

creating a flow (procedure) [33-3](#)

creating collections (procedure) [33-5](#)

data collection [6-2](#)

data interpolation [6-2](#)

description [1-3](#)

events [33-7](#)

exporting as CSV [33-9](#)

exporting as XML [33-8](#)

reports [33-6](#)

starting collections [33-6](#)

thresholds [33-4](#)

top 10 reports [33-7](#)

top 10 reports (procedure) [33-8](#)

using thresholds [6-2](#)

verifying collections [2-6](#)

performance reports, description [5-3](#)

permanent license [9-2](#)

Physical Attributes pane [3-11](#)

Port Analyzer Adapter 2. See PAA-2

### PortChannels

description [17-1](#)

down state [B-2](#)

interfaces using iSCSI [20-9](#)

interoperability [24-5](#)

IQN formats [20-8](#)

load balancing [19-19](#)

modifying (procedure) [17-5](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).***

- trunking comparison [17-1](#)
- using the PortChannel Wizard (procedure) [17-2](#)
- port group [18-5](#)
- port modes
  - auto [18-4](#)
  - IPS [19-1](#)
- port security
  - \*(wildcard) [31-6](#)
  - activating with auto-learn (procedure) [31-3](#)
  - activating without auto-learning (procedure) [31-10](#)
  - auto-learn [31-1](#)
  - configuring (procedure) [31-3](#)
  - configuring manually [31-6](#)
  - configuring manually (procedure) [31-7](#)
  - copying active to config database (procedure) [31-11](#)
  - databases [31-8](#)
  - deleting entries from database (procedure) [31-7](#)
  - description [31-1](#)
  - displaying settings (procedure) [31-4](#)
  - displaying statistics (procedure) [31-4](#)
  - displaying violations (procedure) [31-4](#)
  - enable or disable auto-learning (procedure) [31-5](#)
  - enabling (procedure) [31-3](#)
  - enforcing [31-2](#)
  - example [31-5](#)
  - reactivating the database (procedure) [31-11](#)
- preferences
  - Device Manager [4-8](#)
  - Fabric Manager Client [3-13](#)
- preshared key [27-6](#)
- product authorization key [9-2](#)
- proof of purchase [9-2](#)
- protocol analysis [35-7](#)
- adding a server (procedure) [27-5](#)
- description [27-5](#)
- secret key [27-1](#)
- setting global preshared key (procedure) [27-6](#)
- setting preshared key [27-6](#)
- specifying SNMPv3 on AAA servers [27-7](#)
- vendor-specific attributes protocol options [27-6](#)
- reason codes [B-1](#)
- reconfigure fabric [B-1](#)
- recovering databases. See zone databases [15-18](#)
- recovering passwords [25-7](#)
- redundancy
  - Ethernet PortChannels [19-21](#)
  - Fibre Channel PortChannels [19-21](#)
- remote capture [35-9](#)
- Remote Capture Protocol. See RPCAP
- report templates [5-10](#)
- reserved words in user accounts [25-5](#)
- RMON
  - defining an event (procedure) [34-15](#)
  - description [34-13](#)
  - enabling alarms (procedure) [34-14](#)
  - setting alarms (procedure) [34-13](#)
  - viewing alarms (procedure) [34-15](#)
  - viewing log (procedure) [34-16](#)
- roles
  - additional [27-2](#)
  - common [25-2](#)
  - deleting (procedure) [25-3](#)
  - network administrator [27-2](#)
  - network operator [27-2](#)
- RPCAP
  - Ethereal communication [35-8](#)

## R

- R\_A\_TOV time [B-1](#)
- RADIUS
  - AAA solutions [27-1](#)

## S

- SAN discovery [32-1](#)
- SAN extension tuner
  - data patterns [21-2](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).***

- license requirements [21-2](#)
- SAN operating system. See SAN-OS
- SAN-OS [10-1](#)
- SANTap
  - configuring (procedure) [23-10](#)
  - description [23-7 to 23-10](#)
  - proxy mode-1 [23-9](#)
  - proxy mode-2 [23-10](#)
  - transparent mode [23-8](#)
- SCSI, routing requests using iSCSI [20-4](#)
- SCSI flow services
  - configuring (procedure) [23-4](#)
  - description [23-3](#)
  - Fibre Channel write acceleration [23-4](#)
- SCSI flow statistics
  - clearing (procedure) [23-6](#)
  - description [23-5](#)
  - enabling (procedure) [23-6](#)
- SCSI routing [20-1](#)
- SD ports [18-3](#)
- security control
  - local [27-1](#)
  - remote [27-1](#)
- service groups
  - configuring (procedure) [16-9](#)
  - IVR [16-4](#)
- SFPs, showing types [18-9](#)
- shutdown state [18-5](#)
- SMARTnet [34-2](#)
- SNMP
  - access control [26-2](#)
  - access groups [26-6](#)
  - adding community strings (procedure) [26-3](#)
  - community strings [26-2](#)
  - configuring event destinations [34-12](#)
  - configuring event security (procedure) [34-12](#)
  - configuring notifications (traps or informs) (procedure) [26-7](#)
  - deleting community strings (procedure) [26-4](#)
  - description [26-1](#)
  - event destinations [34-12](#)
  - events [34-11](#)
  - filtering events (procedure) [34-11](#)
  - notifications [26-6](#)
  - server contact [34-1](#)
  - synchronized to CLI [26-2](#)
  - trap receivers [34-12](#)
  - users with multiple roles (procedure) [26-6](#)
  - versions [26-1](#)
  - viewing event log [34-13](#)
- SNMPv3 security features [26-2](#)
- software images
  - description [10-1](#)
  - upgrade prerequisites [10-2](#)
  - upgrade requirements [10-2](#)
  - upgrading [10-1](#)
  - variables [10-1](#)
- Software Installation Wizard (procedure) [10-4](#)
- software upgrades [10-3](#)
- soft zoning [15-14](#)
- source IDs
  - Call Home event format [34-6](#)
  - frame loop back [24-2](#)
  - load balancing [17-1](#)
- SPAN, monitoring traffic [8-2](#)
- SSH
  - enabling (procedure) [25-7](#)
  - generating server key pair (procedure) [25-7](#)
  - host key pair [25-6](#)
  - overwriting key pair [25-7](#)
  - using with FabricWare [2](#)
- SSM [23-1](#)
  - disabling intelligent storage services (procedure) [23-3](#)
  - enabling intelligent storage services (procedure) [23-2](#)
  - provisioning [23-1](#)
  - provisioning (procedure) [23-2](#)
- status bar [3-11](#)
- Storage management solutions architecture [1-4](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).***

Storage Services Module. See SSM

ST ports [18-1](#), [18-4](#)

supervisor and switching modules in Device Manager [4-7](#)

syslog. See system messages

syslog server

    configuring [32-8](#)

    verifying [32-9](#)

system images

    description [10-1](#)

    SYSTEM variable [10-1](#)

system messages

    configuring a syslog server [32-8](#)

    configuring logging [32-7](#)

    description [32-4](#)

    enabling for a feature (procedure) [32-8](#)

    facilities and severity levels [32-4](#)

    severity levels for console session [32-7](#)

    viewing from Device Manager [32-9](#)

    viewing from Fabric Manager Web Services [32-9](#)

## T

TACACS+

    adding a server (procedure) [27-8](#)

    description [27-7](#)

    supported servers [27-9](#)

TCP connections

    FCIP profiles [19-8](#)

    specifying [19-14](#)

TCP ports recognized in ACLs [28-3](#)

Telnet [25-6](#)

TE ports

    classes of service [18-3](#)

    fctrace [24-2](#)

    interface modes [18-1](#)

    interoperability [24-5](#)

    recovering from isolation [15-15](#)

Threshold Manager [34-13](#)

TL ports

    classes of service [18-3](#)

    interface modes [18-1](#)

topology map

    customizations [32-2](#)

    description [32-1](#)

    enclosures [32-2](#)

    mapping multiple fabrics [32-3](#)

    saving custom layout (procedure) [32-2](#)

TOV

    interoperability [24-5](#)

    ranges [24-1](#)

Traffic Analyzer. See Cisco Traffic Analyzer

transit VSANs

    configuration guidelines [16-5](#)

    description [16-3](#), [16-11](#)

troubleshooting

    analyzing switch health [35-3](#)

    analyzing zone merge [35-13](#)

    Cisco Fabric Analyzer [35-7](#)

    locating other switches [35-15](#)

    loopback tests [35-4](#)

    monitoring oversubscription [35-16](#)

    show tech support [35-14](#)

    system messages [32-4](#)

    testing end-to-end connectivity [35-6](#)

    tools [35-1](#)

    using Fabric Configuration tool (procedure) [35-5](#)

    using ping [35-12](#)

    using traceroute (procedure) [35-13](#)

    with protocol analyzer [35-3](#)

    with Traffic Analyzer [35-2](#)

trunking interoperability [24-5](#)

## U

UDP ports in ACLs [28-3](#)

uninstalling management software [1-13](#)

uninstalling permanent licenses [9-10](#)

updating licenses [9-11](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).***

upgrades. See disruptive upgrades  
 upgrades. See nondisruptive upgrades  
 upgrading management software [1-9](#)  
 user ID for authentication [27-2](#)  
 users

creating (procedure) [25-5](#)  
 deleting (procedure) [25-6](#)  
 reserved words [25-5](#)  
 viewing (procedure) [25-6](#)

## V

VE ports [19-2](#)  
 virtual E ports. See VE ports  
 virtual Fibre Channel hosts [20-11](#)  
 virtual iSCSI targets [20-2](#)  
 virtual ISL [19-3](#)  
 virtual N port  
   dynamic mapping [20-12](#)  
 volatile file system [10-9](#)  
 VRRP  
   high availability [19-20](#)  
   IQN formats [20-8](#)  
   switchover [19-20](#)  
 VSA. See RADIUS

VSAN IDs  
   configuring FICON [22-3](#)  
   multiplexing traffic [18-3](#)  
   range [13-1](#)

VSANs  
   configuring (procedure) [13-2](#)  
   default [13-2](#)  
   deleting (procedure) [13-3](#)  
   description [13-1](#)  
   editing policy or scope (procedure) [25-4](#)  
   FC IDs [13-1](#)  
   features [13-1](#)  
   interop mode [24-5](#)  
   IPFC interface and fctrace [24-2](#)

isolated [13-2](#)  
 mismatch [B-2](#)  
 multiple zones [15-9](#)  
 policy [25-3](#)  
 trunking [17-1](#)  
 trunking port [18-3](#)

## W

world wide names. See WWNs  
 WWNs  
   address pool [20-12](#)  
   configuring [24-3](#)  
   suspended connection [B-2](#)

## Z

zone databases  
   copying (procedure) [15-18](#)  
   importing [15-15](#)  
   migrating a non-MDS database [15-18](#)  
 zone members  
   adding to zone [15-5](#)  
   default [15-14](#)  
   displaying [15-6](#)  
 zones  
   access control [15-8](#)  
   active [15-9](#)  
   adding to zone set (procedure) [15-11](#)  
   adding zone members [15-5](#)  
   analyzing merge [35-13](#)  
   assigning members [15-2](#)  
   assigning members for Cisco FabricWare [15-3](#)  
   backing up and restoring (procedure) [15-22](#)  
   cloning [15-12](#)  
   configuring [15-2](#)  
   configuring (procedure) [15-5](#)  
   configuring a LUN-based zones (procedure) [15-20](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).***

- configuring for Cisco FabricWare [15-3](#)
- creating read-only zones (procedure) [15-22](#)
- creating with aliases (procedure) [15-6](#)
- default policy [15-2](#)
- deleting (procedure) [15-13](#)
- description [15-1](#)
- edit full zone database [15-4](#)
- enforcing [15-13](#)
- fabric pWWNs [15-2](#)
- FC aliases [15-3](#)
- features [15-1](#)
- LUN zoning [15-19](#)
- port IDs [15-2](#)
- pWWNs [15-2](#), [15-3](#)
- QoS or broadcast attributes (procedure) [15-19](#)
- read-only [15-21](#)
- traffic priority [15-18](#)
- See also default zones
- See also hard zoning
- See also soft zoning
- zone sets
  - activating (procedure) [15-12](#)
  - adding zones (procedure) [15-11](#)
  - cloning [15-12](#)
  - configuration guidelines [15-9](#)
  - considerations [15-9](#)
  - creating (procedure) [15-11](#)
  - deactivating (procedure) [15-12](#)
  - deleting (procedure) [15-13](#)
  - description [15-8](#)
  - distributing [15-17](#)
  - exporting (procedure) [15-17](#)
  - importing (procedure) [15-16](#)
  - propagating [15-17](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).***