

Send documentation comments to mdsfeedback-doc@cisco.com



CHAPTER 9

G Commands

The commands in this chapter apply to the Cisco MDS 9000 Family of multilayer directors and fabric switches. All commands are shown here in alphabetical order regardless of command mode. See “[About the CLI Command Modes](#)” section on page 1-3 to determine the appropriate mode for each command. For more information, refer to the *Cisco MDS 9000 Family CLI Configuration Guide*.

group

Send documentation comments to mdsfeedback-doc@cisco.com

group

To configure a Modular Exponentiation (MODP) Diffie-Hellman (DH) group for an IKE protocol policy, use the **group** command in IKE policy configuration submode. To revert to the default, use the **no** form of the command.

group {1 | 2 | 5}

no group

Syntax Description	1 Specifies 768-bit MODP DH group. 2 Specifies 1024-bit MODP DH group. 5 Specifies 1536-bit MODP DH group.
---------------------------	---

Defaults	1.
-----------------	----

Command Modes	IKE policy configuration submode.
----------------------	-----------------------------------

Command History	Release	Modification
	2.0(x)	This command was introduced.

Usage Guidelines	To use this command, the IKE protocol must be enabled using the crypto ike enable command.
-------------------------	---

Examples	The following example shows how to configure the DH group for the IKE protocol:
	<pre>switch# config terminal switch(config)# crypto ike domain ipsec switch(config-ike-ipsec)# policy 1 switch(config-ike-ipsec-policy)# group 1</pre>

Related Commands	Command	Description
	crypto ike domain ipsec	Enters IKE configuration mode.
	crypto ike enable	Enables the IKE protocol.
	policy	Configures IKE policy parameters.
	show crypto ike domain ipsec	Displays IKE information for the IPsec domain.

Send documentation comments to mdsfeedback-doc@cisco.com

gzip

To compress (zip) a specified file using LZ77 coding, use the **gzip** command in EXEC mode.

gzip {bootflash: | slot0: | volatile:} filename

Syntax Description	bootflash: Source location for the file to be compressed and destination of the compressed file. slot0: Source location for the file to be compressed and destination of the compressed file. volatile: Source location for the file to be compressed and destination of the compressed file. This is the default directory. filename The name of the file to be compressed.
---------------------------	---

Defaults	None.
-----------------	-------

Command Modes	EXEC mode.
----------------------	------------

Command History	Release	Modification
	1.1(1)	This command was introduced.

Usage Guidelines	This command is useful in compressing large files. The output of the show tech-support command can be directed to a file and compressed for further use. The gzip command replaces the source file with a compressed .gz file.
-------------------------	--

Examples	This example directs the output of the show tech-support command to a file (Samplefile) and then zips the file and displays the difference in the space used up in the volatile: directory:
-----------------	--

```

switch# show tech-support > Samplefile
Building Configuration ...
switch# dir
    1525859      Jul 04 00:51:03 2003  Samplefile
Usage for volatile://
    1527808 bytes used
    19443712 bytes free
    20971520 bytes total
switch# gzip volatile:Samplefile
switch# dir
    266069      Jul 04 00:51:03 2003  Samplefile.gz
Usage for volatile://
    266240 bytes used
    20705280 bytes free
    20971520 bytes total

```

Related Commands

gzip

Send documentation comments to mdsfeedback-doc@cisco.com

Command	Description
gunzip	Uncompresses LZ77 coded files.

Send documentation comments to mdsfeedback-doc@cisco.com

gunzip

To uncompress (unzip) LZ77 coded files, use the **gunzip** command in EXEC mode.

gunzip {bootflash: | slot0: | volatile:} filename

Syntax Description	bootflash: Source location for the compressed file and destination of the uncompressed file. slot0: Source location for the compressed file and destination of the uncompressed file. volatile: Source location for the compressed file and destination of the uncompressed file. This is the default directory. filename The name of the compressed file.
---------------------------	--

Defaults	None.
-----------------	-------

Command Modes	EXEC mode.
----------------------	------------

Command History	Release	Modification
	1.1(1)	This command was introduced.

Usage Guidelines	This command is useful in uncompressing large files. The gunzip command replaces the compressed.gz source file with an uncompressed file.
-------------------------	--

Examples	This example unzips a compressed file on volatile: directory and displays the space used:
<pre>switch# dir 266069 Jul 04 00:51:03 2003 Samplefile.gz Usage for volatile:// 266240 bytes used 20705280 bytes free 20971520 bytes total switch# gunzip Samplefile switch# dir 1525859 Jul 04 00:51:03 2003 Samplefile Usage for volatile:// 1527808 bytes used 19443712 bytes free 20971520 bytes total</pre>	

Related Commands	Command	Description
	gzip	Compresses a specified file using LZ77 coding.

■ gunzip

Send documentation comments to mdsfeedback-doc@cisco.com