

Send comments to nexus5k-docfeedback@cisco.com



S Commands

This chapter describes the Cisco NX-OS Virtual Router Redundancy Protocol (VRRP) commands that begin with S.

Send comments to nexus5k-docfeedback@cisco.com

shutdown (VRRP)

To disable a Virtual Router Redundancy Protocol (VRRP) configuration, use the **shutdown** command. To enable a VRRP configuration, use the **no** form of this command.

shutdown

no shutdown

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	Disabled
------------------------	----------

Command Modes	VRRP configuration mode
----------------------	-------------------------

Command History	Release	Modification
	5.0(3)N1(1)	This command was introduced.

Usage Guidelines	Shut down the virtual router before configuring the virtual router parameters; you can only configure the virtual router after it is in the administrative shut down state. Enter the no shutdown command to update the virtual router state after completing configuration.
-------------------------	---

Examples	This example shows how to shut down a VRRP group:
-----------------	---

```
switch# configure terminal
switch(config)# interface ethernet 2/3
switch(config-if)# no switchport
switch(config-if)# vrrp 45
switch(config-if-vrrp)# shutdown
switch(config-if-vrrp)# address 6.6.6.45
switch(config-if-vrrp)# no shutdown
switch(config-if-vrrp)#
```

Related Commands	Command	Description
	feature vrrp	Enables VRRP.
	show vrrp	Displays VRRP configuration information.
	clear vrrp	Clears all the software counters for the specified virtual router.