



INDEX

A

administrator role [1-1](#)

C

configuring a user with SAN administrator role
example of [1-3](#)

D

displaying user role configurations
example of [1-5](#)

E

enabling FCoE feature for the SAN administrator role
example of [1-4](#)

examples

- configuring a user with SAN administrator role [1-3](#)
- displaying user role configurations [1-5](#)
- enabling FCoE feature for the SAN administrator role [1-4](#)
- modifying the SAN administrator default role [1-4](#)
- verifying the new SAN administrator role configuration [1-5](#)
- verifying the SAN administrator role configuration [1-3](#)

M

mapping

- features to roles [1-2](#)

modifying the SAN administrator default role

example of [1-4](#)

R

RBAC

- SAN administrator role [1-1](#)

Role-Based Access Control (RBAC)

- SAN administrator role [1-1](#)

role-feature mapping [1-2](#)

S

SAN administrator role

- description [1-1](#)
- overview [1-1](#)

V

verifying the new SAN administrator role configuration
example of [1-5](#)

verifying the SAN administrator role configuration
example of [1-3](#)

Send comments to nexus5k-docfeedback@cisco.com