



T Commands

This chapter describes the Cisco NX-OS FabricPath commands that begin with T.

topology

To configure a Layer 2 topology for FabricPath Intermediate System-to-Intermediate System (ISIS), use the **topology** command. To return to the default setting, use the **no** form of this command.



Note

The Cisco Nexus switch supports only two topologies; the default or base topology (topology 0), and another optional topology (for example, topology 1).

topology *topology-number*

no topology [*topology-number*]

Syntax Description

<i>topology-number</i>	Topology number. The range is form 1 to 63.
------------------------	---

Command Default

None

Command Modes

FabricPath IS-IS configuration mode

Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

Usage Guidelines

This command requires an Enhanced Layer 2 license.

Examples

This example shows how to configure a FabricPath IS-IS topology:

```
switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# fabricpath domain default
switch(config-fabricpath-isis)# topology 1
switch(config-fabricpath-isis)#
```

Related Commands

Command	Description
fabricpath domain default	Enables FabricPath Layer 2 IS-IS.