



E Commands

This chapter describes the Cisco NX-OS security commands that begin with E.

enable

To enable a user to move to a higher privilege level after being prompted for a secret password, use the **enable** command.

enable *level*

Syntax Description	<i>level</i>	Privilege level to which the user must log in. The only available level is 15.
--------------------	--------------	--

Command Default	Privilege level 15
-----------------	--------------------

Command Modes	EXEC configuration mode
---------------	-------------------------

Command History	Release	Modification
	6.0(2)N1(1)	This command was introduced.

Usage Guidelines	To use this command, you must enable the cumulative privilege of roles for command authorization on TACACS+ servers using the feature privilege command.
------------------	---

Examples	This example shows how to enable the user to move to a higher privilege level after being prompted for a secret password:
----------	---

```
switch# enable 15
switch#
```

Related Commands	Command	Description
	enable secret	Enables a secret password for a specific privilege level.
	feature privilege	Enables the cumulative privilege of roles for command authorization on TACACS+ servers.
	show privilege	Displays the current privilege level, username, and status of cumulative privilege support.
	username	Enables a user to use privilege levels for authorization.

enable secret

To enable a secret password for a specific privilege level, use the **enable secret** command. To disable the password, use the **no** form of this command.

enable secret [**0** | **5**] *password* [**all** | **priv-lvl** *priv-lvl*]

no enable secret [**0** | **5**] *password* [**all** | **priv-lvl** *priv-lvl*]

Syntax Description	0	(Optional) Specifies that the password is in clear text.
	5	(Optional) Specifies that the password is in encrypted format.
	<i>password</i>	Password for user privilege escalation. It contains up to 64 alphanumeric, case-sensitive characters.
	all	(Optional) Adds or removes all privilege level secrets.
	priv-lvl <i>priv-lvl</i>	(Optional) Specifies the privilege level to which the secret belongs. The range is from 1 to 15.

Command Default	Disabled
-----------------	----------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	6.0(2)N1(1)	This command was introduced.

Usage Guidelines	To use this command, you must enable the cumulative privilege of roles for command authorization on TACACS+ servers using the feature privilege command.
------------------	---

Examples	This example shows how to enable a secret password for a specific privilege level:
----------	--

```
switch# configure terminal
switch(config)# feature privilege
switch(config)# enable secret 5 def456 priv-lvl 15
switch(config)# username user2 priv-lvl 15
switch(config)#
```

Related Commands	Command	Description
	enable	Enables the user to move to a higher privilege level after being prompted for a secret password.
	feature privilege	Enables the cumulative privilege of roles for command authorization on TACACS+ servers.

Command	Description
show privilege	Displays the current privilege level, username, and status of cumulative privilege support.
username	Enables a user to use privilege levels for authorization.