



## New and Changed Information

This chapter provides release-specific information for each new and changed feature in the *Cisco DCNM Fundamentals Configuration Guide*. The latest version of this document is available at the following Cisco website:

[http://www.cisco.com/en/US/docs/switches/datacenter/sw/4\\_0/dcnm/fundamentals/configuration/guide/dcnm\\_fund\\_config.html](http://www.cisco.com/en/US/docs/switches/datacenter/sw/4_0/dcnm/fundamentals/configuration/guide/dcnm_fund_config.html)

To check for additional information about Cisco DCNM Release 4.0, see the *Cisco DCNM Release Notes* available at the following Cisco website:

[http://www.cisco.com/en/US/docs/switches/datacenter/sw/4\\_0/dcnm/release/notes/dcnm\\_4\\_0\\_relnotes.html](http://www.cisco.com/en/US/docs/switches/datacenter/sw/4_0/dcnm/release/notes/dcnm_4_0_relnotes.html)

**Table 1** summarizes the new and changed features for the *Cisco DCNM Fundamentals Configuration Guide* and tells you where they are documented.

**Table 1** *New and Changed Features for Release 4.0*

Feature	Description	Changed in Release	Where Documented
Global Preferences dialog box	Explains the purpose of the fields in the Global Preferences dialog box in the DCNM client and how to configure the fields.	4.0(3)	<a href="#">Chapter 4, “Using the DCNM Client”</a>
NX-OS device configuration requirements	Contains revised information for how to configure an NX-OS device to enable discovery, management, and monitoring by DCNM.	4.0(3)	<a href="#">Chapter 1, “Overview”</a>
Upgrading the DCNM Server Software	Explains how to upgrade the DCNM server software and PostgreSQL database.	4.0(2)	<a href="#">Chapter 2, “Installing and Launching the DCNM Server”</a>
Windows Service	Describes how the DCNM server is run as a service in the Windows Server 2003 operating system.	4.0(2)	<a href="#">Chapter 2, “Installing and Launching the DCNM Server”</a>
Event Filter	Filters events by date, time, and severity.	4.0(2)	<a href="#">Chapter 7, “Managing Events”</a>
DCNM Licensed Devices	Controls which devices you can use with licensed DCNM features.	4.0(2)	<a href="#">Chapter 9, “Administering the DCNM Server”</a>

***Send document comments to [nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com)***