

## New and Changed Information

This chapter provides release-specific information for each new and changed feature in the *Cisco NX-OS Quality of Service Configuration Guide, Release 4.0*. The latest version of this document is available at the following Cisco website:

[http://www.cisco.com/en/US/docs/switches/datacenter/sw/4\\_0/nx-os/security/configuration/guide/sec\\_nx-os\\_config.html](http://www.cisco.com/en/US/docs/switches/datacenter/sw/4_0/nx-os/security/configuration/guide/sec_nx-os_config.html)

To check for additional information about Cisco NX-OS Release 4.0, see the *Cisco NX-OS Release Notes* available at the following Cisco website:

[http://www.cisco.com/en/US/docs/switches/datacenter/sw/4\\_0/nx-os/release/notes/401\\_nx-os\\_release\\_note.html](http://www.cisco.com/en/US/docs/switches/datacenter/sw/4_0/nx-os/release/notes/401_nx-os_release_note.html)

**Table 1** summarizes the new and changed features for the *Cisco NX-OS Quality of Service Configuration Guide, Release 4.0*, and tells you where they are documented.

**Table 1**      **New and Changed Features for Release 4.0**

Feature	Description	Changed in Release	Where Documented
Ignore variable for default command.	The <i>ignore</i> variable is no longer supported for the <b>default</b> command.	4.0(2)	<a href="#">Chapter 4, “Configuring Marking”</a>
Tunnel interfaces	You can apply QoS policies to tunneled interfaces.	4.0(3)	<a href="#">Chapter 2, “Using Modular QoS CLI”</a>
Type queuing default-in-policy	WRR weights changed for default in queuing policy from 50/50 to 80/20.	4.0(3)	<a href="#">Chapter 2, “Using Modular QoS CLI”</a>

***Send document comments to [nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com).***